

# SUNIX | RS-422/485 Control Card

## Quick Installation Guide (Universal)

Ver.1

Please visit <https://www.sunix.com> with product model for detail and latest manual/driver update

### Introduction

SUNIX RS-422/485 Serial Card allows users to expand RS-422/485 ports on PC-based system. The RS-422/485 COM ports can be attached to a housing or slot bracket. Each serial port achieves data rates up to 921.6 Kbps and utilizes 16C950 UART with an on-chip 128-bytes hardware FIFO buffer for reliable, high-speed serial I/O. With SUNIX patented Auto-Switching RS-422/485 and RS-485 AHDC™ technology, user can easily manage different serial interfaces selection and RS-485 signal direction control. We provided with 2KV IEC6100-4-5 Level 3 Surge Suppressor and  $\pm 15KV$  IEC61000-4-2 ESD Discharge Transceiver. Besides, board supports a wide variety of operating systems, including Windows, Linux, DOS, and UNIX. It is the best serial communicating solution for industrial and harsh environment applications.


### 1. Hardware Installation

#### SAFETY FIRST

To avoid damages, please make sure to remove any power connection before card installation, and follow the detailed steps given below before inserting the card into your computer.


#### 1-1 PCI Express Card

- Step 1:** Turn your PC's power off, and shut off the power to any peripheral.
- Step 2:** Remove the power plug from the plug socket.
- Step 3:** Remove the cover from the computer case.
- Step 4:** If fitted, Remove the metal cover plate on the rear of a free PCIe slot.
- Step 5:** Insert PCI Express Industrial I/O Control Board into the free PCIe slot and screw it firmly on the bracket side.
- Step 6:** Place the cover back onto the computer.
- Step 7:** Insert the plug into the plug socket.




#### 1-2 M.2 PCIe Card

- Step 1:** Remove the screw attached to the motherboard.
- Step 2:** Insert M.2 Card tightly into the M.2 slot with 20° angle.  
(SUNIX M.2 Card supports Key-M and Key-B slot)
- Step 3:** Push the M.2 card down to the screw hole.
- Step 4:** Lock screw on M.2 card that you remove from motherboard in step1.
- Step 5:** Connect ribbon cable between M.2 card and extension board.
- Step 6:** Secure the extension board to PC chassis.



#### 1-3 Mini PCIe Card


- Step 1:** Remove the screw attached to the motherboard.
- Step 2:** Insert Mini PCIe Card tightly into the Mini PCIe slot.
- Step 3:** Push the Mini PCIe Card down to the screw hole.
- Step 4:** Lock screw on Mini PCIe Card that you remove from motherboard in step1.
- Step 5:** Connect ribbon cable between Mini PCIe Card and extension board.
- Step 6:** Secure the extension board to PC chassis.



### 2. Pin Assignment

D-Sub 9-pin male with nuts on cable

	PIN	DB9M	DB25M	Pin Header
RS-422 or 4-Wire RS-485	Tx+	2	3	3
	Tx-	1	8	1
	Rx+	3	2	5
	Rx-	4	20	7
	GND	5	7	9
2-Wire RS-485	Data+	2	3	3
	Data-	1	8	1
	GND	5	7	9




SUNIX 4 ports DB44 Female Pin Assignment

	PIN	1	2	3	4
RS-422 or 4-Wire RS-485	Tx+	32	36	40	44
	Tx-	17	22	26	30
	Rx+	3	7	11	15
	Rx-	1	5	9	13
	GND	GND	GND	GND	GND
2-Wire RS-485	Data+	32	36	40	44
	Data-	17	22	26	30
	GND	GND	GND	GND	GND

SUNIX 8 ports DB44 Female Pin Assignment

	1	2	3	4	5	6	7	8
RS-422 or 4-Wire RS-485	32	2	36	6	40	10	44	14
	17	18	22	34	26	38	30	42
	3	31	7	35	11	39	15	43
	1	16	5	20	9	24	13	28
	GND	GND	GND	GND	GND	GND	GND	GND
2-Wire RS-485	32	2	36	6	40	10	44	14
	17	18	22	34	26	38	30	42
	GND	GND	GND	GND	GND	GND	GND	GND




SUNIX 16 ports DB78 Female Pin Assignment

RS-422 or 4-Wire RS-485	PIN	1	2	3	4	5	6	7	8
	Tx+	60	21	43	4	65	26	48	9
	Tx-	40	1	62	23	45	6	67	28
	Rx+	61	22	44	5	66	27	49	10
	Rx-	41	2	63	24	46	7	68	29
	GND	GND	GND	GND	GND	GND	GND	GND	GND
	PIN	9	10	11	12	13	14	15	16
	Tx+	70	31	53	14	75	36	58	19
	Tx-	50	11	72	33	55	16	77	38
	Rx+	71	32	54	15	76	37	59	20
Rx-	51	12	73	34	56	17	78	39	
GND	GND	GND	GND	GND	GND	GND	GND	GND	
2-Wire RS-485	PIN	1	2	3	4	5	6	7	8
	Data+	60	21	43	4	65	26	48	9
	Data-	40	1	62	23	45	6	67	28
	GND	GND	GND	GND	GND	GND	GND	GND	GND
	PIN	9	10	11	12	13	14	15	16
	Data+	70	31	53	14	75	36	58	19
	Data-	50	11	72	33	55	16	77	38
	GND	GND	GND	GND	GND	GND	GND	GND	GND
	Tx+	60	21	43	4	65	26	48	9
	Tx-	40	1	62	23	45	6	67	28

## 4. Driver Installation

- 1) You can download the latest driver from SUNIX official website (<https://www.sunix.com>)
- 2) Please plug the card into the available I/O slot
- 3) Unzip the software file and run setup.exe under Windows operating system.



## 5. Hardware Installation



You can use Windows "Device Manager" to verify proper installation.

- 1) Select Device Manager in the Windows Control Panel.

**Start > Control Panel > Device Manager**

\* The number of COM ports will depend on what products you bought.

- 2) In the Device Manager window, you would read **SUNIX PCI Express Industrial I/O Control Board** under **Multifunction adapters** catalog



Multifunction adapters  
SUNIX 4-Port Serial Card

## 6-1. Configure Serial Port Settings

After the board and drivers are installed, please refer to following instructions to configure Serial COM settings.

1. Please launch the "Device Manager".
2. Right click the "SUNIX Serial Card" item from the "Multifunction adapters" sub-tree and click "Properties".




Multifunction adapters  
SUNIX 4-Port Serial Card

3. On the "Port Control" tab, select a port to configure.

\* Click "OK" to approve the settings for the selected port.

\* Click "Set to All" to approve the settings for all COM ports.




## 6-2. COM Port Number Settings

Under Port Number, select a COM number to assign to the serial port.


Click "OK" to approve the settings for the selected port.

**Note:** In order to prevent system resource conflict, do not select "in use" port.



## 6-3. COM I/O Resource

User can read the COM "IO Range" and "IRQ" located in system by selecting COM port.



IRQ and I/O address is automatically assigned by the mainboard PCI (PCI Express) BIOS automatically (before COM card driver installing). User can NOT assign legacy ISA address (3F8, 3E8, 2F8, 2E8) for the specific COM port. But for IRQ setting, user can set specific IRQ value for this PCI Express bus slot via mainboard's BIOS settings (not via SUNIX driver). But all COM ports will share one IRQ value.


## 6-4. FIFO Settings

Select an Rx FIFO Trigger and Tx FIFO Size.

The default Rx FIFO Trigger is 112 bytes. The default Tx FIFO Size is 128 bytes.

Click "Set to All" to change this setting for all serial ports on the board.

Then click "OK" to save the settings.



**Receive FIFO interrupt trigger level:**

When the level of data in the receiver FIFO reaches this value, a receiver data interrupt is triggered.


**Transmit FIFO interrupt trigger level:**

When the level of data in the transmit FIFO falls below this value, a transmitter interrupt is triggered. Setting this value to zero will not trigger an interrupt until the transmitter is completely idle.

The FIFO trigger levels can be fine tuned to gain optimum performance, depending on system performance, baud rate used, levels of serial traffic etc.

## 6-5. Advanced Settings for RS-422/485 Communication


User can control RS-422/485 communication in Advanced Port Control page through "Advanced" settings.



## Clock Rate


This is the "Data Rate" value for on board crystal frequency of input clock. The baud rate can optionally be adjusted according to the data rate required. The clock pre-divisor is used to divide the input clock prior to baud rate generation.

This parameter must match with the oscillator (crystal) frequency on the board. System default is 14745600 Hz. We do NOT recommend for modification without SUNIX instruction. User can click "Defaults" button back to manufactory settings.



## UART Type (Default: Auto RS-422/485)

User can select RS-422 or RS-485 interface for each COM port of this board.



## 7. Troubleshooting

Q 1. System fails to find the Industrial I/O Control Board.

Ans: It may cause by following issue:

- a. The board is not properly plugged into the PCIe (M.2 / Mini PCIe) slot.
- b. Please clean the golden finger.
- c. The M.2 slot is defective. Please try other slots until you find one that works.
- d. The mainboard does not have an available IRQ for the PCIe (M.2 / Mini PCIe) board.  
Enter the PC's BIOS and make sure an IRQ setting is available in the PCI/PnP settings.
- e. The board itself might be defective.  
You can try another mainboard testing this board working or not.

Q 2. There is a blue screen when I entry operation system.

Ans: It may cause by following issue:

- a. The possible reason is an IRQ or I/O address conflict with other PCIe bus adapters, such as LAN or serial boards, or with the system BIOS.  
Refer to the corresponding problem in the previous FAQ for solutions.
- b. Please check driver update from your vendor.

Copyright - Copyright© 2022 SUNIX Co., Ltd. All Rights Reserved. No part of this publication may be reproduced, transcribed, stored in a retrieval system, translated into any language, or transmitted in any form or by any means, photocopying, manual, or otherwise, without prior written permission from SUNIX. Disclaimer - SUNIX shall not be liable for any incidental or consequential damages resulting from the performance or use of this equipment. SUNIX makes no representations or warranties regarding the contents of this manual. Information in this manual has been carefully checked for reliability; however, no guarantee is given as to the correctness of this content. In the interest of continued product improvement, this company reserves the right to revise the manual or include change in the specifications of the product described within it at any time without notice and without obligation to notify any person of such revision or changes. The information contained in this manual is provided for general use by the customers. Trademarks - SUNIX is a registered trademark of SUNIX Group. All other trademarks or registered marks in this manual belong to their respective owners. BSMI 聲明 - 限用物質含有情況標示資訊網站請參考下列網址: <http://www.sunix.com.tw> 操作說明: 選擇頁面之產品/型號/文件下載區 (RoHS文件)

E-mail for technical support: [info@sunix.com](mailto:info@sunix.com)

Website for product information: [www.sunix.com](http://www.sunix.com)

Tel: +886-2-8913-1987

Fax: +886-2-8913-1986

Made in China

771-Q42248500-S01

