

iTXL-3955A (MKLPCCI)

Thin Mini-ITX Motherboard

User's Manual 1st Ed

Copyright Notice

This document is copyrighted, 2018. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the original manufacturer. Information provided in this manual is intended to be accurate and reliable. However, the original manufacturer assumes no responsibility for its use, or for any infringements upon the rights of third parties that may result from its use.

The material in this document is for product information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, GIGAIPC assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein.

GIGAIPC reserves the right to make changes in the product design without notice to its users.

Acknowledgement

All other products' name or trademarks are properties of their respective owners.

- AMD® is trademark of Advanced Micro Devices.
- Microsoft Windows is a registered trademark of Microsoft Corp.
- Intel, Pentium, Celeron, and Xeon are registered trademarks of Intel Corporation
- Core, Atom are trademarks of Intel Corporation
- ITE is a trademark of Integrated Technology Express, Inc.
- IBM, PC/AT, PS/2, and VGA are trademarks of International Business Machines Corporation.

All other product names or trademarks are properties of their respective owners.

Packing List

Before setting up your product, please make sure the following items have been shipped:

Item	Quantity
iTXL-3955A MB	1
SATA power cable	1
I/O Bracket	1

If any of these items are missing or damaged, please contact your distributor or sales representative immediately.

About this Document

This User's Manual contains all the essential information, such as detailed descriptions and explanations on the product's hardware and software features (if any), its specifications, dimensions, jumper/connector settings/definitions, and driver installation instructions (if any), to facilitate users in setting up their product.

Users may refer to the GIGAIPC.com for the latest version of this document.

Safety Precautions

Please read the following safety instructions carefully. It is advised that you keep this manual for future references

1. All cautions and warnings on the device should be noted.
2. Make sure the power source matches the power rating of the device.
3. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
4. Always completely disconnect the power before working on the system's hardware.
5. No connections should be made when the system is powered as a sudden rush of power may damage sensitive electronic components.
6. If the device is not to be used for a long time, disconnect it from the power supply to avoid damage by transient over-voltage.
7. Always disconnect this device from any AC supply before cleaning.
8. While cleaning, use a damp cloth instead of liquid or spray detergents.
9. Make sure the device is installed near a power outlet and is easily accessible.
10. Keep this device away from humidity.
11. Place the device on a solid surface during installation to prevent falls
12. Do not cover the openings on the device to ensure optimal heat dissipation.

13. Watch out for high temperatures when the system is running.
14. Do not touch the heat sink or heat spreader when the system is running
15. Never pour any liquid into the openings. This could cause fire or electric shock.
16. As most electronic components are sensitive to static electrical charge, be sure to ground yourself to prevent static charge when installing the internal components. Use a grounding wrist strap and contain all electronic components in any static-shielded containers.
17. If any of the following situations arises, please the contact our service personnel:
 - i. Damaged power cord or plug
 - ii. Liquid intrusion to the device
 - iii. Exposure to moisture
 - iv. Device is not working as expected or in a manner as described in this manual
 - v. The device is dropped or damaged
 - vi. Any obvious signs of damage displayed on the device
18. **DO NOT LEAVE THIS DEVICE IN AN UNCONTROLLED ENVIRONMENT WITH TEMPERATURES BEYOND THE DEVICE'S PERMITTED STORAGE TEMPERATURES (SEE CHAPTER 1) TO PREVENT DAMAGE.**

FCC Statement

Warning!



This device complies with Part 15 FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation.

Caution:

There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions and your local government's recycling or disposal directives.

Attention:

Il y a un risque d'explosion si la batterie est remplacée de façon incorrecte. Ne la remplacer qu'avec le même modèle ou équivalent recommandé par le constructeur. Recycler les batteries usées en accord avec les instructions du fabricant et les directives gouvernementales de recyclage.

China RoHS Requirements (CN)

产品中有毒有害物质或元素名称及含量
GIGAIPC Main Board/ Daughter Board/ Backplane

部件名称	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路板 及其电 子组件	○	○	○	○	○	○
外部信号 连接器 及线材	○	○	○	○	○	○
○: 表示该有毒有害物质在该部件所有均质材料中的含量均在 SJ/T 11363-2006 标准规定的限量要求以下。 X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 SJ/T 11363-2006 标准规定的限量要求。 备注: 此产品所标示之环保使用期限, 系指在一般正常使用状况下。						

China RoHS Requirement (EN)

Poisonous or Hazardous Substances or Elements in Products GIGAIPC Main Board/ Daughter Board/ Backplane

Component	Poisonous or Hazardous Substances or Elements					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent Chromium (Cr(VI))	Polybrominated Biphenyls (PBB)	Polybrominated Diphenyl Ethers (PBDE)
PCB & Other Components	O	O	O	O	O	O
Wires & Connectors for External Connections	O	O	O	O	O	O
O : The quantity of poisonous or hazardous substances or elements found in each of the component's parts is below the SJ/T 11363-2006-stipulated requirement. X: The quantity of poisonous or hazardous substances or elements found in at least one of the component's parts is beyond the SJ/T 11363-2006-stipulated requirement. Note: The Environment Friendly Use Period as labeled on this product is applicable under normal usage only						




Table Contents

Thin Mini-ITX Motherboard	1
User's Manual 1st Ed	1
Copyright Notice	2
Acknowledgement	3
Packing List.....	4
About this Document	5
Safety Precautions	6
FCC Statement.....	8
China RoHS Requirements (CN).....	9
China RoHS Requirement (EN)	10
 Chapter 1 - Product Specifications	 13
1.1 Specifications	15
 Chapter 2 – Hardware Information	 17
2.1 Jumpers and Connectors	18
2.1.1 Rear I/O Connector	20
2.2.1 DC_IN1 (DC In Jack).....	21
2.2.2 DC_IN2 (ATX 2x2 pin power connector).....	22
2.2.3 LSW (LVDS resolution jumper)	23
2.2.4 AT_CN (AT/ATX power mode select jumper)	24
2.2.5 F_Audio (Front audio header)	25
2.2.6 LVDS (LVDS connector).....	26
2.2.7 BKL_CN (Back light brightness control connector).....	27
2.2.8 USB30 (USB 3.0 header).....	28

2.2.9	COM1~4 (Serial port)	29
2.2.10	TPM_LPC (Trusted Platform Module Connector).....	30
2.2.11	SYS_PANEL (Front panel header)	31
2.2.12	SATAPW1~2 (SATA 6Gb/s power connector)	32
2.2.13	GPIO_CNT (General Propose input/output header)	33
2.2.14	SYS_FAN	34
2.2.15	SPK_OUT (Speaker out connector)	35
2.2.16	EDP (Embedded Display Port Connector)	36
2.2.17	JCOM31, JCOM41 (COM31 & COM41 RI# pin RI#/5V/12V Select)	37
2.2.18	CLR_CMOS	38
2.2.19	JRS31, JRS32, JRS41, JRS42 (RS31, RS32, RS41, RS42 select jumper for serial port)	39
2.2.20	JRS33, JRS34, JRS43, JRS44 (RS33, RS34, RS43, RS44 select jumper for serial port)	40
2.2.21	JCOM32/42 (RS-232/RS-422/RS-485 select).....	41

Chapter 1

Chapter 1 - Product Specifications



1.1 Specifications

Motherboard	iTXL-3955A (MKLPCCI)
Form Factor	Thin Mini-ITX form factor
	170W x 170D (mm)
CPU	Intel® Celeron® Processor 3955U, 2M Cache, 2.00 GHz
	2 MB SmartCache
Socket	1 x FCBGA1356
Chipset	—
Memory	2 x DDR4 SO-DIMM sockets supporting up to 32 GB of system memory
	Dual channel memory architecture Support for DDR4 2133 MHz memory modules
Ethernet	2 x GbE LAN ports (Intel® i219LM and Intel® i211AT)
Video	Integrated Graphics Processor - Intel® HD Graphics 510
	1 x HDMI port, supporting a maximum resolution of 4096 x 2160@24 Hz 1 x DP port, supporting a maximum resolution of 4096 x 2160@60 Hz 1 x LVDS/ 1 x eDP port (Auto switch), supporting a maximum resolution of 1920 x 1080@60 Hz * Support for HDMI 1.4 version
Audio	Realtek ALC269 High Definition Audio
Storage	2 x SATA 6Gb/s ports
Raid	—
Expansion Slots	1 x Mini PCIe (Full Size)
	1 x M.2 slot: - M-key - SATA 6Gb/s - Supports NGFF- 2242/2280 cards

Motherboard	iTXL-3955A (MKLPCCI)
Internal I/O	1 x 2-pin ATX main power connector 2 x SATA 6Gb/s connectors 2 x USB 3.0 headers 1 x Front panel header 1 x Front panel audio header 1 x Speaker out header 1 x LVDS connector 1 x LCD_VCC Pin header 1 x Back Light Switch 1 x System fan header 1 x CPU fan header 2 x COM Headers (RS-232) 2 x COM headers (RS-232/422/485 and RI/5V/12V) 2 x SATA Power 1 x eDP 1 x GPIO (4 in/ 4 out)
Rear I/O	2 x Audio jacks (Line out, Mic in) 1 x HDMI 1 x Display Port 2 x RJ45 2 x USB2.0 2 x USB3.0 1 x DC IN (12V)
TPM	1 x TPM Header
OS Compatibility	Windows 10 (x64) Windows 7 (x64)
PSU Connectors	1 x 12V DC-in 1 x 4-pin ATX power connector
Operating Properties	Operating temperature: 0°C to 60°C Operating humidity: 0-90% (non-condensing) Non-operating temperature: -20°C to 70°C Non-operating humidity: 0%-95% (non-condensing)


Chapter 2

Chapter 2 – Hardware Information




No	Code	Description
1	DC_IN1	DC In Jack
2	DC_IN2	ATX 2x2 pin power connector
3	LSW	LVDS resolution jumper
4	AT_CN	AT/ATX power mode select jumper
5	F_AUDIO	Front audio header
6	LVDS	LVDS connector
7	BKL_CN	Back light brightness control connector
8	USB30	USB 3.0 header
9	COM1~4	Serial port
10	TPM_LPC	Trusted Platform Module Connecto
11	SYS_PANEL	Front panel header
12	SATAPW1~2	SATA 6Gb/s power connector
13	GPIO_CNT	General Purpose input/output header
14	SYS_FAN	System fan connector
15	SPK_OUT	Speaker out connector
16	EDP	Embedded Display Port connector
17	JCOM31/41	COM31/41 RI# pin RI#/5V/12V Select
18	CLR_CMOS	Clear CMOS jumper
19	JRS31 JRS32 / JRS41 JRS42	RS31, RS32/ RS41, RS42 select jumper for serial port
20	JRS33 JRS34/ JRS43 JRS44	RS33, RS34/ RS43, RS44 select jumper for serial port
21	JCOM32/42	COM3/COM4 RS-232/RS-422/RS-485 Select

2.1.1 Rear I/O Connector



No	Code	Description
1	DC_IN1	1 x DC IN (12V)
2	DP Port	1 x Display Port
3	HDMI Port	1 x HDMI
4	USB3 Port	2 x USB3.0
5	USB2 Port	2 x USB2.0
6	RJ-45 Port	2 x RJ45
7	Mic in	1 x Audio jacks (Mic in)
8	Line out	1 x Audio jacks (Line out)

2.2.1 DC_IN1 (DC In Jack)




Power Connector

Connector PN	Vendor
WTJ-020-88JSB	KYOYAKU

2.2.2 DC_IN2 (ATX 2x2 pin power connector)

2




Power Connector	

Pin No.	Definition
1	GND
2	GND
3	+12V
4	+12V

Connector PN	Vendor
740-81-04TW56	PINREX
25104A0400B3-93LF	ATRC

2.2.3 LSW (LVDS resolution jumper)




LVDS Resolution Jumper			
Jumper Setting	Resolution	Jumper Setting	Resolution
	800 x 600 18bit		1366 x 768 24bit
	1024 x 768 18bit		1440 x 900 24bit
	1024 x 768 24bit		1400 x 1050 24bit
	1024 x 600 18bit		1600 x 900 24bit
	1280 x 800 18bit		1680 x 1050 24bit
	1024 x 600 18bit		1600 x 1200 24bit
	1280 x 1024 24bit		1920 x 1080 24bit
	1366 x 768 18bit		1920 x 1200 24bit

Connector PN	Vendor
222-97-04GBE1	PINREX

2.2.4 AT_CN (AT/ATX power mode select jumper)

4




AT/ATX power mode select jumper
 1

Connector PN	Vendor
PH03N33BAAA00	HORNGTONG

Pin No.	Definition
1	AT MODE
2	Detect
3	ATX MODE
Jumper setting	
1-2 Close : AT mode.	
2-3 Close : ATX mode.(Default setting)	

2.2.5 F_Audio (Front audio header)





Front Audio Connector	
2	1
10	9

Connector PN	Vendor
725-81-10TW00	PINREX
A2004WV-2X05P46	JOINT-TECH

Pin No.	Definition	Pin No.	Definition
1	MIC_L	6	GND
2	GND	7	FAUDIO_JD
3	MIC_R	8	No Connect
4	Detect	9	HPOUT_L
5	HPOUT_R	10	GND

2.2.6 LVDS (LVDS connector)

6




Pin No.	Definition	Pin No.	Definition
1	3.3V	21	A5+
2	5V	22	A4+
3	3.3V	23	A5-
4	5V	24	A4-
5	SPECO	25	GND
6	SPEDO	26	GND
7	GND	27	A7+
8	GND	28	A6+
9	A1+	29	A7-
10	A0+	30	A6-
11	A1-	31	GND
12	A0-	32	GND
13	GND	33	CLK2+
14	GND	34	CLK1+
15	A3+	35	CLK2-
16	A2+	36	CLK1-

Pin No.	Definition	Pin No.	Definition
17	A3-	37	GND
18	A2-	38	GND
19	GND	39	12V
20	GND	40	12V

Connector PN	Vendor
712-76-40GWE0	PINREX
A1252WV-SF-2X20PD01	JOINT-TECH

2.2.7 BKL_CN (Back light brightness control connector)

7




Back light brightness control connector		
5		1

Connector PN	Vendor
85205-0270L	ACES
A1250WV-S-02PC	JOINT-TECH

Pin No.	Definition
1	5V
2	PWM
3	Back Light Enable
4	GND
5	12V

2.2.8 USB30 (USB 3.0 header)

8





USB 3.0 Header	
Pin No.	Definition
1	Power
2	P1_RX-
3	P1_RX+
4	GND
5	P1_TX-
6	P1_TX+
7	GND
8	P1_D-
9	P1_D+
10	OC

Pin No.	Definition
11	P2_D+
12	P2_D-
13	GND
14	P2_TX+
15	P2_TX-
16	GND
17	P2_RX+
18	P2_RX-
19	Power
20	No Pin

Connector PN	Vendor
52X-80-20GU65	PINREX
WUIR-19A9N4BU3W	WINWIN

2.2.9 COM1~4 (Serial port)




Connector PN	Vendor
725-81-10TW00	PINREX
A2004WV-2X05P46	JOINT-TECH

Pin No.	Definition	Pin No.	Definition
1	RXD	6	GND
2	DCD	7	CTS
3	DTR	8	RTS
4	TXD	9	No Connect
5	DSR	10	RI/ 5V/ 12V

2.2.10 TPM_LPC (Trusted Platform Module Connector)

10



TPM Module Connector	
2	14
1	13


Pin No.	Definition
1	LPCCCLK
2	3VDUAL
3	PFM RST
4	VCC3
5	LAD0
6	IRQ_SERIAL
7	LAD1
8	TPM_DET
9	LAD2

Pin No.	Definition
10	NC
11	LAD3
12	GND
13	LFRAME
14	GND

Connector PN	Vendor
52M-90-14GBE7	PINREX

2.2.11 SYS_PANEL (Front panel header)

11




System Panel Header	
2	10
1	9

Connector PN	Vendor
210-92-05G111	PINREX

Pin No.	Definition
1	HDD LED+
2	Power LED+
3	HDD LED-
4	Power LED-
5	GND
6	Power Button+
7	Reset Button
8	Power Button-
9	No Connect
10	No Pin

2.2.12 SATAPW1~2 (SATA 6Gb/s power connector)

12




Hard Disk Power Connector	
	

Pin No.	Definition
1	12V
2	GND
3	GND
4	5V


Connector PN	Vendor
743-81-04TW00	PINREX
WF04Q2-3BJQ000	HORNGTONG

2.2.13 GPIO_CNT (General Propose input/output header)

13



GPIO Connector




Pin No.	Definition
1	GPO1
2	GPI1
3	GPO2
4	GPI2
5	GPO3
6	GPI3
7	GPO4
8	GPI4
9	SMB_CLK

Pin No.	Definition
10	SMB_DATA
11	5V
12	GND

Connector PN	Vendor
725-81-12TW00	PINREX
A2004WV-2X06P46	JOINT-TECH

2.2.14 SYS_FAN

14




System FAN	
	1 4

Pin No.	Definition
1	GND
2	12V
3	Detect
4	Speed Control

Connector PN	Vendor
744-81-045R11	PINREX
WF04R22RJQ105	HORNGTONG

2.2.15 SPK_OUT (Speaker out connector)

15



Audio Amplifier Connector



Connector PN

721-81-045W00
A2001WV-04P146


Vendor

PINREX
JOINT-TECH

Pin No.	Definition
1	Speaker Out L+
2	Speaker Out L-
3	Speaker Out R-
4	Speaker Out R+

2.2.16 EDP (Embedded Display Port Connector)

16



Embedded Display Port connector


Pin No.	Definition	Pin No.	Definition
1	GND	11	eDP_1+
2	GND	12	eDPAUX-
3	eDP_0-	13	GND
4	eDP_3-	14	eDPAUX+
5	eDP_0+	15	eDP_2-
6	eDP_3+	16	GND
7	GND	17	eDP_2+
8	eDPSW	18	HDP
9	eDP_1-	19	5V
10	GND	20	3.3V

Note: Please ensure pin 8 is connected to Ground.

Connector PN	Vendor
A1252WV-SF-2X10PN6BG1G00L	JOINT-TECH
50286-02071-001	ACES

2.2.17 JCOM31, JCOM41 (COM31 & COM41 RI# pin
RI#/5V/12V Select)

17




JCOM31, JCOM41 Jumper	
	1-2 Close: 5V (Power COM)
	3-4 Close: RI (Stand COM)
	5-6 Close: 12V (Power COM)

Connector PN	Vendor
220-97-03GB01	PINREX
PH06N53BAZ000	HORNGTONG

2.2.18 CLR_CMOS

19




Clear COMS Jumper	
1	2

Connector PN	Vendor
210-91-02GB01	PINREX
PH02R23BAZ000	HORNGTONG

Pin No.	Definition
1	Clear CMOS
2	GND
Open: Normal Operation (Default setting) Close: Clear COMS data.	

2.2.19 JRS31, JRS32, JRS41, JRS42 (RS31, RS32, RS41, RS42 select jumper for serial port)

19



JRS31, JRS32, JRS41, JRS42

JRS32  JRS31

JRS42  JRS41

1-2 Close:
RS-485

2-3 Close:
RS-232 (Default-setting)

Connector PN


PH03N33BAAA00

Vendor

HORNGTONG

2.2.20 JRS33, JRS34, JRS43, JRS44 (RS33, RS34, RS43, RS44 select jumper for serial port)

20




JRS33, JRS34, JRS43, JRS44
JRS34   JRS33
JRS44   JRS43
1-2 Close: RS-422
2-3 Close: RS-232 (Default-setting)

Connector PN	Vendor
PH03N33BAAA00	HORNGTONG

2.2.21 JCOM32/42 (RS-232/RS-422/RS-485 select)

21



JCOM32/42 Jumper	
	1-2 Close: RS-232
	3-4 Close: RS-422
	5-6 Close: RS-485

Pin No.	Definition
1	RX232
2	RX
3	RX422
4	RX
5	RX485
6	RX

Connector PN	Vendor
222-97-03GBE1	PINREX

