


# U8/U10

Intel LGA 1700/1200/115X  
 AMD Socket AM5/AM4


## INSTALLATION GUIDE

### 安装指南

Intel Components &amp; Tool/Intel 安装所需零件及工具




**1.** Cooler/散热器\* **2.** Fan/风扇 **3.** Intel Retention Bracket Pair/ Intel脚架组 **4.** Fan Installation Screws/风扇安装螺丝 **5.** Retention Bracket Installation Screws/脚架安装螺丝 **6.** LGA1700 Screws/螺丝 **7.** LGA1200/115X Screws/螺丝 **8.** Thermal grease/导热膏 **9.** Philips Head Screw Driver (Not Included)/十字螺丝刀(产品未附, 需自行准备)




Intel LGA 1700/1200/115X Installation

**Step3:**  
 Remove the cooler protect sticker and install the cooler on the CPU. Tighten the screw until stop/  
 撕去散热器保护贴纸, 安装散热器, 锁螺丝至停止




**Step 6:**  
 Connect the 4 Pin fan connector to the motherboard/  
 连接4 Pin风扇接头至主板




AMD AM5/AM4 Installation

**Step3:**  
 Apply the thermal grease/  
 涂Thermal grease




**Step4:**  
 Remove the cooler protect sticker and install the cooler. Tighten the screw until stop/  
 撕去散热器保护贴纸, 安装散热器, 锁螺丝至停止




Intel LGA 1700/1200/115X Installation


**Step1:**  
 Install the Intel retention bracket/  
 安装Intel脚架




**Step2:**  
 Install the fan/安装风扇



AMD Components &amp; Tool/AMD 安装所需零件及工具




**1.** Cooler/散热器\* **2.** Fan/风扇 **3.** AMD Retention Bracket Pair/ AMD脚架组 **4.** Fan Installation Screws/风扇安装螺丝 **5.** Retention Bracket Installation Screws/脚架安装螺丝 **6.** AMD Heatsink Installation Screws/AMD散热器安装螺丝 **7.** AMD Heatsink Installation Spring/ AMD散热器安装弹簧 **8.** Thermal grease/导热膏 **9.** Philips Head Screw Driver (Not Included)/十字螺丝刀(产品未附, 需自行准备)



AMD AM5/AM4 Installation

**Step5:**  
 Install the fan/安装风扇



**Step 6:**  
 Connect the 4 Pin fan connector to the motherboard/  
 连接4 Pin风扇接头至主板

