

IB908F

**Intel® Haswell-ULT
3.5" Disk Size SBC**

USER'S MANUAL

Version 1.1

Acknowledgments

AMI is a registered trademark of American Megatrends Inc.

PS/2 is a trademark of International Business Machines Corporation.

Intel and Intel® 4th Generation Mobile Core™ i MCP Processor are registered trademarks of Intel Corporation.

Microsoft Windows is a registered trademark of Microsoft Corporation.

NUVOTON is a registered trademark of NUVOTON Technology Corporation.

All other product names or trademarks are properties of their respective owners.

Table of Contents

Introduction	1
Product Description.....	1
Checklist.....	2
IB908F Specifications.....	2
Board Dimensions	4
Installations	5
Installing the Memory	6
Setting the Jumpers	7
Connectors on IB908F	11
BIOS Setup.....	23
Drivers Installation	49
Intel Chipset Software Installation Utility	50
VGA Drivers Installation	53
Realtek HD Audio Driver Installation	56
LAN Drivers Installation.....	58
Intel® Management Engine Interface	62
Intel® USB 3.0 Drivers.....	65
Appendix.....	68
A. I/O Port Address Map	68
B. Interrupt Request Lines (IRQ).....	69
C. Watchdog Timer Configuration	70

This page is intentionally left blank.

Introduction

Product Description

The IB908F is a 3.5-inch single board computer based on the Intel® Haswell-ULT MCP processors.

The IB908F platform is well-suited for low-power and high-performance designs in a broad range of markets including Industrial Control & Automation, Digital Signage, Thin Client, Electronic Gaming Machines, and SMB storage appliances.

IB908F Features:

- Supports Intel® 4th generation mobile Core™ i MCP processors
- Two DDR3L SO-DIMM, 1333/1600 MHz, Max. 16GB memory
- Integrated graphics for DVI-I, LVDS displays
- 2 x SATA III connector
- 2x COM port connector
- 2 x Mini-PCIe(x1) slot (*w/ USB/MSATA support*)
- 2x GbE (RJ-45) connector
- 1x 9V to 24V DC-IN power connector

Checklist

Your IB908F package should include the items listed below.


- The IB908F SBC
- This User's Manual
- 1 CD containing chipset drivers and flash memory utility
- Optional cable kit (containing DC in power cable/PW87, COM port cable / PK1H, SATA & HDD power cable/SATA-26 and USB 2.0 cable/USB-29)
- Other options: Audio-18 audio cable, HSIB908-BGA-1 heatsink

IB908F Specifications

Product Name	IB908F
Form Factor	3.5" SBC
CPU Type	- Intel® 4 th generation mobile Core™ i MCP processors (22nm monolithic) - TDP = 15W (DC) , FCBGA1168 @ solder side
CPU Speed	Intel® Core™ i7-4650U processor (1.7GHz) [IB908AF-4650] Intel® Core™ i5-4300U processor (1.9GHz) [IB908AF-4300] Intel® Core™ i3-4010U processor (1.7GHz) [IB908F-4010] Intel® Celeron® 2980U processor (1.6GHz) [IB908F-2980]
Cache	Up to 4MB
Chipset	Integrated in Intel® 4 th Generation Core™ i U-series processor
BIOS	AMI BIOS
Memory	Intel® 4 th Gen. Core™ i U-series processor integrated memory controller - DDR3L (1.35V) @ 1600 MHz, SO-DIMM [204-pin vertical] x 2 - Max. 16GB, Non-ECC
Display	Intel® 4 th Gen. Core™ i U-series processor integrated Gfx, supports 3 independent displays, Direct X 11.1, OpenGL 3.2, Open CL 1.2 - DVI-I x 1 (Thru DD#1 w/ Level shifter [ASM1442K] for DVI + DP to VGA [NXP PTN3392])
LVDS	- LVDS(Thru eDP, via NXP PTN3460 bridge IC) 24-bit dual channels LVDS interface w/DF20 socket x2
LAN	Intel® I218LM GbE PHY (IB908AF-4650& IB908AF-4300) or I218V GbE PHY (IB908F-4010 & IB908F-2980) Intel® I211AT as 2 nd GbE
USB	- Intel® 4 th Gen. Core™ i U-series processor integrated USB 2.0 host controller, supports 4 x USB 2.0: 2-ports onboard pin header + 2 port thru MiniPCIe - Intel® 4 th Gen. Core™ i U-series processor integrated USB 3.0 host controller, supports 2 x USB 3.0 in the rear panel

Serial ATA Ports	Intel® 4 th Gen. Core™ i U-series processor built-in SATA controller 2 x SATA 3.0 (6Gbps) and 2 x mSATA via MiniPCIe slots (w/NXP CBTL02043A switching IC)
Audio	Intel® 4 th Gen. Core™ i U-series processor built-in High Definition Audio controller + Realtek ALC269Q-VC2-GR Codec [6mm x 6mm @ MQFN48] w/ class-D speaker amplifier(2W per channel @ 5V power supply)
LPC I/O	Nuvoton NCT6102D [128-pin LQFP, 14 mm x 14mm x 1.4mm] COM1 (RS232/422/485) [EXAR SP339EER1 232/422/485 transceiver for jumper-less]; COM2 (RS232 only) [SIPEX SP3243EBER, QFN32] [Hardware Monitor] 2 x Thermal inputs 2 x Voltage monitoring 1 x CPU Fan (PWM Fan type, 4-pin connector)
Digital IO	4 in & 4 out
iAMT(9.5)	For IB908AF-4650 / IB908AF-4300
Expansion Slots	1x mSATA/mPCIe(x1) w/ USB signal [Half-sized] 1x mSATA/mPCIe(x1) w/ USB signal [Full-sized]
Edge Connector	DVI-I x 1 RJ45 x2 for LAN#1 & #2 USB 3.0 stack connector x 1 for USB1 / 2 [Blue color] DB9 x 1 for COM #1
Onboard Header/Connector	DF20-20 socket connector x 2 for 24-bit dual channel LVDS 2 ports x SATA III [Blue color] 2x4 pins header x 1 for 2 USB 2.0 ports [DF11] 2x6 pins box header x1 for Audio [DF11] 1x4 pins box header x1 for Speaker out 2x5 pins box header x1 for COM2 2x5 pins headers x 1 for LPC (Debug purposes only) 5 pins box header x1 for smart battery 4 pins box header x1 for backlight/brightness control 4 pins power connector x1 for SATA HDD 2 pins power connector x1 for DC-in [180 degree vertical type]
Watchdog Timer	Yes (256 segments, 0, 1, 2...255 sec/min)
Power Input	+9V ~ +24V DC-in
RoHS	Yes
Board Size	102mm x 147mm
OS supported	Windows 8 / Embedded; Windows 7 / Embedded Linux
Others	Heatsink i-SMART (Auto-scheduler & Power fail resume function) EEPROM 24C02(Reserved for designing, M-SO8 package)

Board Dimensions



Installations

This section provides information on how to use the jumpers and connectors on the IB908F in order to set up a workable system. The topics covered are:

Installing the Memory	6
Setting the Jumpers	7
Connectors on IB908F	11


Installing the Memory

The IB908F board supports TWO DDR3L memory socket for a maximum total memory of 16GB DDR3L memory type.

Installing and Removing Memory Modules

To install the DDR3L modules, locate the memory slot on the board and perform the following steps:

1. Hold the DDR3L module so that the key of the DDR3L module aligned with that on the memory slot.
2. Gently push the DDR3L module in an upright position until the clips of the slot close to hold the DDR3L module in place when the DDR3L module touches the bottom of the slot.
3. To remove the DDR3L module, press the clips with both hands.




Setting the Jumpers

Jumpers are used on IB908F to select various settings and features according to your needs and applications. Contact your supplier if you have doubts about the best configuration for your needs. The following lists the connectors on IB908F and their respective functions.


Jumper Locations on IB908F.....	8
J3: Clear CMOS Contents.....	9
J4: Clear ME Contents.....	9
J7: Flash Descriptor Security Override (Factory use only).....	10
J9: LVDS Panel Power Selection	10

Jumper Locations on IB908F




Jumpers on IB908F	Page
J3: Clear CMOS Contents	9
J4: Clear ME Contents	9
J9: LVDS Panel Power Selection.....	10

J3: Clear CMOS Contents



J3	Setting	Function
	Pin 1-2 Short/Closed	Normal
	Pin 2-3 Short/Closed	Clear CMOS

J4: Clear ME Contents






J4	Setting	Function
	Pin 1-2 Short/Closed	Normal
	Pin 2-3 Short/Closed	Clear ME RTC REGISTER

J7: Flash Descriptor Security Override (Factory use only)

J7	Flash Descriptor Security Override
Open	Disabled (Default)
Close	Enabled

J9: LVDS Panel Power Selection





J9	Setting	Panel Voltage
 1 2 3	Pin 1-2 Short/Closed	3.3V (default)
 1 2 3	Pin 2-3 Short/Closed	5V

Connectors on IB908F

Connector Locations on IB908F.....	12
CN3, CN4: Gigabit LAN	13
<i>CN3: Intel® Clarkville I218V/I218LM GbE PHY</i>	<i>13</i>
<i>CN4: Intel® Pearsonville I211AT as 2nd GbE</i>	<i>13</i>
CN5: USB 1/2 Connector	13
CN6: VGA DVI-I Connector.....	13
CN7: DB9 Connector	13
CN1, CN2: SATA Connectors.....	14
JP1: LCD Backlight Connector	14
JP2: USB3/4 Connector.....	14
J2: Audio Connector (DF11 Connector).....	15
JP3, JP5: LVDS Connectors (LVDS1,LVDS2).....	15
JP4: SPI Flash Connector (factory use only)	16
J5: Amplifier Connector	16
J7: Factory use only	16
JP6: SATA HDD Power Connectors	17
JP7: Debug 80 Port Connector (factory use only)	17
J12: Smart Battery	18
J13: Board Input Power Connector.....	18
J14: Front Panel Connector	19
J15: Mini PCIE Connector (Supports mSATA)	20
J16: Mini PCIE Connector (Half Size/ Supports mSATA).....	20
J17: COM2/RS232 Serial Port	20
J19: Digital I/O Connector.....	21
CPU_FAN1: CPU Fan Power Connector	21

Connector Locations on IB908F





CN3, CN4: Gigabit LAN

CN3: Intel® Clarkville I218V/I218LM GbE PHY

CN4: Intel® Pearsonville I211AT as 2nd GbE

CN5: USB 1/2 Connector


CN6: VGA DVI-I Connector

CN7: DB9 Connector

(COM1) is a DB-9 connector.


Signal Name	Pin #	Pin #	Signal Name
DCD, Data carrier detect	1	6	DSR, Data set ready
RXD, Receive data	2	7	RTS, Request to send
TXD, Transmit data	3	8	CTS, Clear to send
DTR, Data terminal ready	4	9	RI, Ring indicator
GND, ground	5	10	Not Used

COM1 is jumper-less for RS-232, RS-422 and RS-485 and is to be configured with BIOS Selection.




Pin #	Signal Name		
	RS-232	R2-422	RS-485
1	DCD	TX-	DATA-
2	RX	TX+	DATA+
3	TX	RX+	NC
4	DTR	RX-	NC
5	Ground	Ground	Ground
6	DSR	NC	NC
7	RTS	NC	NC
8	CTS	NC	NC
9	RI	NC	NC
10	NC	NC	NC

CN1, CN2: SATA Connectors




JP1: LCD Backlight Connector




Pin #	Signal Name
1	+12V
2	Backlight Enable
3	Brightness Control
4	Ground

JP2: USB3/4 Connector



Signal Name	Pin #	Pin #	Signal Name
Vcc	1	2	Ground
D0-	3	4	D1+
D0+	5	6	D1-
Ground	7	8	Vcc


J2: Audio Connector (DF11 Connector)



Signal Name	Pin #	Pin #	Signal Name
LINEOUT_R	2	1	LINEOUT_L
Ground	4	3	JD_FRONT
LINEIN_R	6	5	LINEIN_L
Ground	8	7	JD_LINEIN
MIC-R	10	9	MIC_L
Ground	12	11	JD_MIC1


JP3, JP5: LVDS Connectors (LVDS1, LVDS2)

The LVDS connectors (Hirose DF20G-20DP-1V) on board consist of the first channel (LVDS1) and second channel (LVDS2).




Signal Name	Pin #	Pin #	Signal Name
TX0N	2	1	TX0P
Ground	4	3	Ground
TX1N	6	5	TX1P
Ground	8	7	Ground
TX2N	10	9	TX2P
Ground	12	11	Ground
CLKN	14	13	CLKP
Ground	16	15	Ground
TX3N	18	17	TX3P
Power	20	19	Power

JP4: SPI Flash Connector (factory use only)




J5: Amplifier Connector




Pin #	Signal Name
1	OUTL+
2	OUTL-
3	OUTR-
4	OUTR+


J6, J8: DDR3L SO-DIMM Sockets



J7: Factory use only





JP6: SATA HDD Power Connectors




Pin #	Signal Name
1	+5V
2	Ground
3	Ground
4	+12V


JP7: Debug 80 Port Connector (factory use only)



JP11: MCU Flash Connector (factory use only)




J12: Smart Battery



Pin #	Signal Name
1	RST#
2	ICHSWI#
3	Ground
4	SMB_DATA
5	SMB_CLK


J13: Board Input Power Connector



Pin #	Signal Name
1	+9V to +24V
2	GND

J14: Front Panel Connector

The following table shows the pin outs of the 2x4 pin header



Signal Name	Pin #	Pin #	Signal Name
Ground	1	2	PWR_SW
PWR_LED+	3	4	PWR_LED-
HDD_LED+	5	6	HDD_LED-
Ground	7	8	RESET

J14 provides connectors for system indicators that provide light indication of the computer activities and switches to change the computer status.

J14 is an 8-pin header that provides interfaces for the following functions.

ATX Power ON Switch: Pins 1 and 2

This 2-pin connector is an “ATX Power Supply On/Off Switch” on the system that connects to the power switch on the case. When pressed, the power switch will force the system to power on. When pressed again, it will force the system to power off.

Power LED: Pins 3 and 4

Pin #	Signal Name
3	LED(+)
4	LED(-)

Hard Disk Drive LED Connector: Pins 5 and 6


This connector connects to the hard drive activity LED on control panel. This LED will flash when the HDD is being accessed.

Pin #	Signal Name
5	LED(+)
6	LED(-)


Reset Switch: Pins 7 and 8

The reset switch allows the user to reset the system without turning the main power switch off and then on again. Orientation is not required when making a connection to this header.

J15: Mini PCIE Connector (Supports mSATA)




J16: Mini PCIE Connector (Half Size/ Supports mSATA)




** The gap of height between J15 & J16 is following PCI Express Mini Card electromechanical spec. **

J17: COM2/RS232 Serial Port




Signal Name	Pin #	Pin #	Signal Name
DCD, Data carrier detect	1	2	RXD, Receive data
TXD, Transmit data	3	4	Data terminal ready
GND, ground	5	6	DSR, Data set ready
RTS, Request to send	7	8	CTS, Clear to send
RI, Ring indicator	9	10	Not Used

J19: Digital I/O Connector



Signal Name	Pin #	Pin #	Signal Name
GND	1	2	VCC
OUT3	3	4	OUT1
OUT2	5	6	OUT0
IN3	7	8	IN1
IN2	9	10	IN0

CPU_FAN1: CPU Fan Power Connector



Pin #	Signal Name
1	Ground
2	+12V
3	Rotation detection
4	Control

This page is intentionally left blank.

BIOS Setup

This chapter describes the different settings available in the BIOS that comes with the board. The topics covered in this chapter are as follows:

BIOS Introduction	24
BIOS Setup	24
Advanced Settings	26
Chipset Settings	39
Boot Settings.....	45
Security Settings	47
Save & Exit Settings	48

BIOS Introduction

The BIOS (Basic Input/Output System) installed in your computer system's ROM provides critical low-level support for a standard device such as disk drives, serial ports and parallel ports. It also adds virus and password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

BIOS Setup

The BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS ROM of the system stores the Setup utility. When you turn on the computer, the BIOS is immediately activated. Pressing the key immediately allows you to enter the Setup utility. If you are a little bit late pressing the key, POST (Power On Self Test) will continue with its test routines, thus preventing you from invoking the Setup. If you still wish to enter Setup, restart the system by pressing the "Reset" button or simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys. You can also restart by turning the system Off and back On again. The following message will appear on the screen:

```
Press <DEL> or <ESC> to Enter Setup
```

In general, you press the arrow keys to highlight items, <Enter> to select, the <PgUp> and <PgDn> keys to change entries, <F1> for help and <Esc> to quit.

When you enter the Setup utility, the Main Menu screen will appear on the screen. The Main Menu allows you to select from various setup functions and exit choices.

Main Settings

Aptio Setup Utility – Copyright © 2011 American Megatrends, Inc.

Main	Advanced	Chipset	Boot	Security	Save & Exit
BIOS Information					Choose the system default language
Total memory		8176 MB (DDR3)			
Memory Frequency		1600 Mhz			
System Date				[Tue 10/29/2013]	→ ← Select Screen
System Time				[15:27:20]	↑ ↓ Select Item
Access Level				Administrator	Enter: Select
					+ - Change Field
					F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save
					ESC: Exit

System Date

Set the Date. Use Tab to switch between Data elements.

System Time

Set the Time. Use Tab to switch between Data elements.

Advanced Settings

This section allows you to configure and improve your system and allows you to set up some system features according to your preference.

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
	<ul style="list-style-type: none"> ▶ PCI Subsystem Settings ▶ ACPI Settings ▶ Wake up event setting ▶ CPU Configuration ▶ SATA Configuration ▶ Shutdown Temperature Configuration ▶ ISmart Controller ▶ USB Configuration ▶ NCT6102D Super IO Configuration ▶ NCT6102D H/W Monitor 				→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

PCI Subsystem Settings

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
	PCI Bus Driver Version		V 2.0502		→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit
	PCI Common Settings				
	PCI Latency Timer		32 PCI Bus Clocks		
	VGA Palette Snoop		Disabled		
	PERR# Generation		Disabled		
	SERR# Generation		Disabled		
	▶ PCI Express Settings				

PCI Latency Timer

Value to be programmed into PCI Latency Timer Register.

VGA Palette Snoop

Enables or disables VGA Palette Registers Snooping.

PERR# Generation

Enables or disables PCI device to generate PERR#.

SERR# Generation

Enables or disables PCI device to generate SERR#.

PCI Express Settings

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit	
PCI Express Device Register Settings						
Relaxed Ordering			Disabled		→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit	
Extended Tag			Disabled			
No Snoop			Enabled			
Maximum Payload			Auto			
Maximum Read Request			Auto			
PCI Express Link Register Settings						
ASPM Support			Disabled			
WARNING: Enabling ASPM may cause PCI-E devices to fail						
Extended Synch			Disabled			
Link Training Retry			5			
Link Training Timeout (uS)			100			
Unpopulated Links			Keep Link ON			
Restore PCIE Registers			Disabled			

Relaxed Ordering

Enables or disables PCI Express Device Relaxed Ordering.

Extended Tag

If ENABLED allows device to use 8-bit Tag field as a requester.

No Snoop

Enables or disables PCI Express Device No Snoop option.

Maximum Payload

Set Maximum Payload of PCI Express Device or allow System BIOS to select the value.

Maximum Read Request

Set Maximum Read Request Size of PCI Express Device or allow System BIOS to select the value.

ASPM Support

Set the ASPM Level: Force L0s – Force all links to L0s State:
 AUTO – BIOS auto configure: DISABLE – Disables ASPM.

Extended Synch

If ENABLED allows generation of Extended Synchronization patterns.

Link Training Retry

Defines number of Retry Attempts software will take to retrain the link if previous training attempt was unsuccessful.

Link Training Timeout (uS)

Defines number of Microseconds software will wait before polling 'Link Training' bit in Link Status register. Value range from 10 to 1000 uS.

Unpopulated Links

In order to save power, software will disable unpopulated PCI Express links, if this option set to 'Disable Link'.

Restore PCIE Registers

On non-PCI Express aware OS's (Pre Windows Vista) some devices may not be correctly reinitialized after S3. Enabling this restore PCI Express device configuration on S3 resume

Warning: Enabling this may cause issues with other hardware after S3 resume.1

ACPI Settings

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
ACPI Settings					→ ← Select Screen
Enable Hibernation			Enabled	↑ ↓ Select Item	
ACPI Sleep State			S3 (Suspend to R...)	Enter: Select	
Lock Legacy Resources			Disabled	+- Change Field	
S3 Video Repost			Disabled	F1: General Help	
					F2: Previous Values
					F3: Optimized Default
					F4: Save
					ESC: Exit

Enable Hibernation

Enables or Disables System ability to hibernate (OS/S4 Sleep State). This option may be not effective with some OS.

ACPI Sleep State

Select ACPI sleep state the system will enter, when the SUSPEND button is pressed.

Lock Legacy Resources

Enabled or Disabled Lock of Legacy Resources.

S3 Video Repost

Enable or disable S3 Video Repost.

Wake up event settings

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
Wake on PCIE Wake Event				Disabled	→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

Wake on PCIE PME Wake Event

The options are Disabled and Enabled.

CPU Configuration

This section shows the CPU configuration parameters.

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
CPU Configuration					
Intel(R) CPU Core(TM)i3-4010U @ 1.70GHz					
CPU Signature			40651		
Processor Family			6		
Microcode Patch			16		
FSB Speed			100MHz		
Max CPU Speed			1700 MHz		
Min CPU Speed			800 MHz		
CPU Speed			800 MHz		
Processor Cores			2		
Intel HT Technology			Supported		
Intel VT-x Technology			Supported		
Intel SMX Technology			Not Supported		
64-bit			Supported		
EIST			Supported		
CPU C3 State			Supported		
CPU C6 State			Supported		
CPU C7 State			Supported		
L1 Data Cache			Supported		
L1 Code Cache			Supported		
L2 Cache			Supported		
L3Cache			Supported		
Hyper-threading			Enabled		→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit
Active Processor Cores			All		
Overclocking lock			Disabled		
Limit CPUID Maximum			Disabled		
Execute Disable Bit			Enabled		
Intel Virtualization Technology			Enabled		
CPU AES			Enabled		
EIST			Enabled		

Hyper-threading

Select the performance state that the BIOS will set before OS handoff.

Active Processor Cores

Number of cores to enable in each processor package.

Overclocking lock

Flex_RATIO(194)MSR

Limit CPUID Maximum

Disabled for Windows XP.

Execute Disable Bit

XD can prevent certain classes of malicious buffer overflow attacks when combined with a supporting OS

Intel Virtualization Technology

When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

CPU AES

Enabled/Disabled CPU Advanced Encryption Standard instructions

EIST

Enabled/Disabled Intel Speedstep.

SATA Configuration

SATA Devices Configuration.

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
	SATA Controller(s)		Enabled		
	SATA Mode Selection		AHCI		
	SATA Port0		Empty		
	Software Preserve		Unknown		
	Hot Plug		Disabled		
	SATA Port1		Empty		
	Software Preserve		Unknown		
	Hot Plug		Disabled		
	SATA Port2		Empty		
	Software Preserve		Unknown		→ ← Select Screen
	Hot Plug		Disabled		↑ ↓ Select Item
	SATA Port3		Empty		Enter: Select
	Software Preserve		Unknown		+ - Change Field
	Hot Plug		Disabled		F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save ESC: Exit

SATA Controller(s)

Enable / Disable Serial ATA Controller.

SATA Mode Selection

- (1) AHCI Mode.
- (2) RAID Mode.

Hot Plug

Designates this port as Hot Plugable.

Shutdown Temperature Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
	ACPI Shutdown Temperature		Disabled		→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

ACPI Shutdown Temperature

The default setting is Disabled.

ISmart Controller

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
	ISmart Controller				→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit
	Power-On after Power failure		Disable		
	Schedule Slot 1		None		
	Schedule Slot 2		None		

Power-On after Power failure

Enable or Disable.

Schedule Slot 1 / 2

Setup the hour/minute for system power on.

AMT Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
			Intel AMT	Enabled	
			BIOS Hotkey Pressed	Disabled	
			MEBx Selection Screen	Disabled	
			Hide Un-Configure ME Confirmation	Disabled	
			Un-Configure ME	Disabled	
			Amt Wait Timer	0	
			Activate Remote Assistance Process	Disabled	
			USB Configure	Enabled	
			PET Progress	Enabled	→ ← Select Screen
			AMT CIRA Timeout	0	↑ ↓ Select Item
			Watchdog	Disabled	Enter: Select
			OS Timer	0	+ - Change Field
			BIOS Timer	0	F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save ESC: Exit

AMT Configuration

This configuration is supported iAMT function. Options are Enabled and Disabled.

Note: iAMT H/W is always enabled. This option just controls the BIOS extension execution. If enabled, this requires additional firmware in the SPI device.

Unconfigure ME

Perform AMT/ME unconfigure without password operation.

Amt Wait Timer

Set timer to wait before sending ASF_GET_BOOT_OPTIONS.

Activate Remote Assistance Process

Trigger CIRA boot.

PET Progress

User can Enable/Disable PET Events progress to receive PET events or not.

Watchdog Timer

Enable/Disable Watchdog Timer.

NCT6102D Super IO Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
NCT6102D Super IO Configuration					
NCT6102D Super IO Chip		NCT6102D			
▶ Serial Port 0 Configuration					
▶ Serial Port 1 Configuration					
				→ ← Select Screen	
				↑ ↓ Select Item	
				Enter: Select	
				+- Change Field	
				F1: General Help	
				F2: Previous Values	
				F3: Optimized Default	
				F4: Save	
				ESC: Exit	

Serial Port Configuration

Set parameters of serial ports. User can Enable/Disable the serial port and Select an optimal settings for the Super IO Device.

NCT6102D H/W Monitor

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
PC Health Status					
Smart Fan Function			Disabled		
					→ ← Select Screen
					↑ ↓ Select Item
					Enter: Select
					+ - Change Field
					F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save
					ESC: Exit
SYS Temp			+40 C		
CPU Temp			+43 C		
CpuFan Speed			4166		
Vcore			+1.808 V		
+5V			+4.918 V		
+12V			+12.000 V		
1.35V			+1.376 V		

Smart Fan Function

This field enables or disables the smart fan feature. At a certain temperature, the fan starts turning. Once the temperature drops to a certain level, it stops turning again.

Temperatures/Voltages

These fields are the parameters of the hardware monitoring function feature of the board. The values are read-only values as monitored by the system and show the PC health status.

Chipset Settings

This section allows you to configure and improve your system and allows you to set up some system features according to your preference.

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
<ul style="list-style-type: none"> ▶ PCH-IO Configuration ▶ System Agent (SA) Configuration 					

PCH-IO Configuration

This section allows you to configure the North Bridge Chipset.

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
Intel PCH RC Version Intel PCH SKU Name Intel PCH Rev ID			1.6.2.0 Premium SKU 03/B1		
<ul style="list-style-type: none"> ▶ PCI Express Configuration ▶ USB Configuration ▶ PCH Azalia Configuration 					
PCH LAN Controller Wake on LAN SLP_S4 Assertion Width			Enabled Disabled 1-2 Seconds		→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

PCH LAN Controller

Enable or disable onboard NIC.

Wake on LAN

Enable or disable integrated LAN to wake the system. (The Wake On LAN cannot be disabled if ME is on at Sx state.)

SLP_S4 Assertion Width

Select a minimum assertion width of the SLP_S4# signal.

PCI Express Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit
PCI Express Configuration					
PCI Express Clock Gating			Disabled		
DMI Link ASPM Control			Disabled		
DMI Link Extended Synch Control			Disabled		
PCIe-USB Glitch W/A			Disabled		
PCIe Root Function Swapping			Disabled		
Subtractive Decode			Disabled		
▶ PCI Express Root Port 1					
▶ PCI Express Root Port 2					
▶ PCI Express Root Port 3					
▶ PCI Express Root Port 4					
▶ PCI-E Port 5 is assigned to LAN					
▶ PCI Express Root Port 6					
			→ ← Select Screen		
			↑ ↓ Select Item		
			Enter: Select		
			+- Change Field		
			F1: General Help		
			F2: Previous Values		
			F3: Optimized Default		
			F4: Save ESC: Exit		

PCI Express Clock Gating

Enable or disable PCI Express Clock Gating for each root port

DMI Link ASPM Control

The control of Active State Power Management on both NB side and SB side of the DMI link.

PCIe-USB Glitch W/A

PCIe-USB Glitch W/A for bad USB device(s) connected behind PCI/PEG port.

USB Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit
USB Configuration					
			USB Precondition	Disabled	→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit
			xHCI Mode	Auto	
			xHCI Idle L1	Enabled	
			USB Ports Per-Port Disable Control	Disabled	

USB Precondition

Precondition work on USB host controller and root ports for faster enumeration.

xHCI Mode

Mode of operation of xHCI controller.

USB Ports Per-Port Disable Control

Control each of the USB ports (0~13) disabling.

PCH Azalia Configuration

Main	Advanced	Chipset	Boot	Security	Save & Exit
PCH Azalia Configuration					
			Azalia	Auto	→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit
			Azalia PME	Disabled	

Azalia

Control Detection of the Azalia device.

Disabled = Azalia will be unconditionally be disabled.

Enabled = Azalia will be unconditionally be enabled.

Auto = Azalia will be enabled if present, disabled otherwise.

Azalia PME

Enable or disable power management capability of the audio controller.

System Agent (SA) Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
		System Agent Bridge Name	Haswell		
		System Agent RC Version	1.6.2.0		
		VT-d Capability	Supported		
		VT-d	Enabled		
		▶ Graphics Configuration			
					→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

VT-d

Check to enable VT-d function on MCH.

Graphics Configuration

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
		Graphics Configuration			
		IGFX VBIOS Version	2166		
		IGfx Frequency	400 MHz		
		Primary Display	Auto		
		Primary PEG	Auto		
		Primary PCIe	Auto		
		Internal Graphics	Auto		
		Aperture Size	256MB		
		DVMT Pre-Allocated	32M		
		DVMT Total Gfx Mem	256MB		
		▶ LCD Control			
					→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit

Primary Display

Select which of IGFX/PEG/PCI graphics device should be primary display or select SG for switchable Gfx.

Primary PEG

Select PEGO/PEG1/PEG2/PEG3 Graphics device should be Primary PEG.

Primary PCIE

Select PCIE0/PCIE1/PCIE2/PCIE3/PCIE4/PCIE5/PCIE6/PCIE7 Graphics device should be primary PCIE.

Internal Graphics

Keep IGD enabled based on the setup options.

DVMT Pre-Allocated

Select DVMT 5.0 Pre-Allocated (Fixed) graphics memory size used by the internal graphics device.

DVMT Total Gfx Mem

Select DVMT 5.0 total graphics memory size used by the internal graphics device.

LCD Control

Select the Video Device that will be activated during POST. This has no effect if external graphics present. Secondary boot display selection will appear based on your selection. VGA modes will be supported only on primary display.

LCD Control

Aptio Setup Utility

Main	Advanced	Chipset	Boot	Security	Save & Exit
LCD Control					→ ← Select Screen
Primary IGFX Boot Display			VBIOS Default		↑ ↓ Select Item
LCD Panel Type			1024x768 LVDS		Enter: Select
DC Output level			LEVEL4		+ - Change Field
LCD Chanel Type			Single		F1: General Help
LVDS BackLight brightness volt Control			3.3V		F2: Previous Values
Active LFP			No LVDS		F3: Optimized Default
Panel Color Depth			24 Bit		F4: Save & Exit
					ESC: Exit

Primary IGFX Boot Display

Select the Video Device, which will be activated during POST. This has no effect if external graphics present.

Secondary boot display selection will appear based on your selection.

VGA modes will be supported only on primary display.

LCD Panel Type

Select LCD panel used by Internal Graphics Device by selecting the appropriate setup item: 640x480 LVDS ~ 2048x1536 LVDS.

DC Output level

Backlight Brightness Control

LCD Chanel Type

Select LCD Chanel Type

LVDS Back Light Brightness Volt Control

LVDS Back Light Volt Control: 3.3V, 5V

Active LFP

Select the Active LFP Configuration.

No LVDS: VBIOS does not enable LVDS.

Int-LVDS: VBIOS enables LVDS driver by Integrated encoder.

SDVO LVDS: VBIOS enables LVDS driver by SDVO encoder.

eDP Port-A: LFP Driven by Int-DisplayPort encoder from Port-A.

Panel Color Depth

Select the LFP Panel Color Depth: 18 Bit, 24 Bit.

Boot Settings

This section allows you to configure the boot settings.

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
Boot Configuration					
Setup Prompt Timeout		1			
Bootup NumLock State		On			
Quiet Boot		Disabled			
Fast Boot		Disabled			
Boot Option Priorities					
▶ CSM16 Parameters					
CSM Parameters					
					→ ← Select Screen
					↑ ↓ Select Item
					Enter: Select
					+ - Change Field
					F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save
					ESC: Exit

Setup Prompt Timeout

Number of seconds to wait for setup activation key.
65535(0xFFFF) means indefinite waiting.

Bootup NumLock State

Select the keyboard NumLock state.

Quiet Boot

Enables/Disables Quiet Boot option.

Fast Boot

Enables/Disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.

Boot Option Priorities

Sets the system boot order.

CSM parameters

OpROM execution, boot options, filter, etc.

Aptio Setup Utility					
Main	Advanced	Chipset	Boot	Security	Save & Exit
			Launch CSM	Enabled	
			Boot option filter	UEFI and Legacy	
			Launch PXE OpROM policy	Do not launch	→ ← Select Screen
			Launch Storage OpROM policy	Legacy only	↑ ↓ Select Item
			Launch Video OpROM policy	Legacy only	Enter: Select
			Other PCI device ROM priority	Legacy OpROM	+ - Change Field
					F1: General Help
					F2: Previous Values
					F3: Optimized Default
					F4: Save
					ESC: Exit

Launch CSM

This option controls if CSM will be launched.

Boot option filter

This option controls what devices system can boot to.

Launch PXE OpROM policy

Controls the execution of UEFI and Legacy PXE OpROM.

Launch Storage OpROM policy

Controls the execution of UEFI and Legacy Storage OpROM.

Launch Video OpROM policy

Controls the execution of UEFI and Legacy Video OpROM.

Other PCI device ROM priority

For PCI devices other than Network, Mass storage or Video defines which OpROM to launch.

Save & Exit Settings

Main	Advanced	Chipset	Boot	Security	Save & Exit
Save Changes and Exit Discard Changes and Exit Save Changes and Reset Discard Changes and Reset Save Options Save Changes Discard Changes Restore Defaults Save as User Defaults Restore User Defaults				→ ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit	

Save Changes and Exit

Exit system setup after saving the changes.

Discard Changes and Exit

Exit system setup without saving any changes.

Save Changes and Reset

Reset the system after saving the changes.

Discard Changes and Reset

Reset system setup without saving any changes.

Save Changes

Save Changes done so far to any of the setup options.

Discard Changes

Discard Changes done so far to any of the setup options.

Restore Defaults

Restore/Load Defaults values for all the setup options.

Save as User Defaults

Save the changes done so far as User Defaults.

Restore User Defaults

Restore the User Defaults to all the setup options.

Drivers Installation

This section describes the installation procedures for software and drivers. The software and drivers are included with the board. If you find the items missing, please contact the vendor where you made the purchase. The contents of this section include the following:

Intel Chipset Software Installation Utility	50
VGA Drivers Installation.....	53
Realtek HD Audio Driver Installation	56
LAN Drivers Installation	58
Intel® Management Engine Interface	62
Intel® USB 3.0 Drivers	65

IMPORTANT NOTE:

After installing your Windows operating system, you must install first the Intel Chipset Software Installation Utility before proceeding with the drivers installation.

Intel Chipset Software Installation Utility

The Intel Chipset Drivers should be installed first before the software drivers to enable Plug & Play INF support for Intel chipset components. Follow the instructions below to complete the installation.

1. Insert the DVD that comes with the board. Click *Intel* and then *Intel(R) 8 Series Chipset Drivers*.



2. Click *Intel(R) Chipset Software Installation Utility*.



3. When the Welcome screen to the Intel® Chipset Device Software appears, click *Next* to continue.



4. Click *Yes* to accept the software license agreement and proceed with the installation process.



5. On the Readme File Information screen, click **Next** to continue the installation.



6. The Setup process is now complete. Click **Finish** to restart the computer and for changes to take effect.



VGA Drivers Installation

1. Insert the DVD that comes with the board. Click *Intel* and then *Intel(R) 8 Series Chipset Drivers*.




2. Click *Intel(R) Core(TM) i3/i5/i7 Graphics Driver*.



3. When the Welcome screen appears, click *Next* to continue.




4. Click *Yes* to agree with the license agreement and continue the installation.



5. On the screen shown below, click **Install** to continue.



6. Setup complete. Click **Finish** to restart the computer and for changes to take effect.



Realtek HD Audio Driver Installation


1. Insert the DVD that comes with the board. Click *Intel* and then *Intel(R) 8 Series Chipset Drivers*.




2. Click *Realtek High Definition Audio Driver*.



3. On the Welcome to the InstallShield Wizard screen, click **Yes** to proceed with and complete the installation process.



4. The InstallShield Wizard Complete. Click **Finish** to restart the computer and for changes to take effect.



LAN Drivers Installation


1. Insert the DVD that comes with the board. Click *Intel* and then *Intel(R) 8 Series Chipset Drivers*.



2. Click *Intel(R) PRO LAN Network Driver*.



3. Click **Install Drivers and Software**.




4. When the Welcome screen appears, click **Next**.




5. Click **Next** to to agree with the license agreement.




6. Click the checkbox for **Drivers** in the Setup Options screen to select it and click **Next** to continue.



7. The wizard is ready to begin installation. Click **Install** to begin the installation.



8. When InstallShield Wizard is complete, click **Finish**.



Intel® Management Engine Interface

1. Insert the DVD that comes with the board. Click *Intel* and then *Intel(R) 8 Series Chipset Drivers* and then *Intel(R) AMT 9.5 Drivers*.



- When the Welcome screen to the InstallShield Wizard for Intel® Management Engine Components, click the checkbox for **Install Intel® Control Center** & click **Next**.



- Click **Yes** to agree with the license agreement.



4. When the Setup Progress screen appears, click **Next**. Then, click **Finish** when the setup progress has been successfully installed.



Intel® USB 3.0 Drivers

1. Insert the DVD that comes with the board. Click *Intel* and then *Intel(R) 8 Series Chipset Drivers*.



2. Click *Intel(R) USB 3.0 Drivers*.



3. When the Welcome screen to the InstallShield Wizard for Intel® USB 3.0 eXtensible Host Controller Driver, click *Next*.



4. Click *Yes* to agree with the license agreement and continue the installation.



5. On the Readme File Information screen, click **Next** to continue the installation of the Intel® USB 3.0 eXtensible Host Controller Driver.

6. Setup complete. Click **Finish** to restart the computer and for changes to take effect.



Appendix

A. I/O Port Address Map

Each peripheral device in the system is assigned a set of I/O port addresses which also becomes the identity of the device. The following table lists the I/O port addresses used.

Address	Device Description
000h - 01Fh	DMA Controller #1
020h - 021h	Interrupt Controller #1
040h - 043h	Timer
060h - 060h	Keyboard Controller
070h - 077h	Real Time Clock, NMI
081h - 091h	DMA Page Register
0A0h - 0A1h	Interrupt Controller #2
081h - 091h	DMA Controller #2
040h - 05Fh	SMBus Controller
2F8h - 2FFh	Serial Port #2(COM2)
3C0h- 3DFh	Graphics adapter Controller
D000 - FFFh	PCI-e Root Ports
3F8h - 3FFh	Serial Port #1(COM1)

B. Interrupt Request Lines (IRQ)

Peripheral devices use interrupt request lines to notify CPU for the service required. The following table shows the IRQ used by the devices on board.

Level	Function
IRQ0	System Timer Output
IRQ1	Keyboard
IRQ3	Serial Port #2
IRQ4	Serial Port #1
IRQ8	Real Time Clock
IRQ10	SMBus Controller
IRQ19	SATA AHCI Controller

C. Watchdog Timer Configuration

The WDT is used to generate a variety of output signals after a user programmable count. The WDT is suitable for use in the prevention of system lock-up, such as when software becomes trapped in a deadlock. Under these sorts of circumstances, the timer will count to zero and the selected outputs will be driven. Under normal circumstance, the user will restart the WDT at regular intervals before the timer counts to zero.

SAMPLE CODE:

```
//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#include <dos.h>
#include <conio.h>
#include <stdio.h>
#include <stdlib.h>
#include "6106"
//-----
int main (int argc, char *argv[]);
void EnableWDT(int);
void DisableWDT(void);
//-----
int main (int argc, char *argv[])
{
    unsigned char bBuf;
    unsigned char bTime;
    char **endptr;

    char SIO;

    printf("6106 watch dog program\n");

    bTime = strtol (argv[1], endptr, 10);
    printf("System will reset after %d seconds\n", bTime);

    if (bTime)
    {
        else
        {
            if (bTime > 0 && bTime < 256)
            {
                A=2;

                unsigned char result;
                Set_6106_LD(0x08);

                gotoxy(1,12);

            }
        }
    }
}
```

```

return 0;
}
//-----
void EnableWDT(int interval)
{
    unsigned char bBuf;

    Set_6106_LD(0x08);
    Set_6106_Reg(0x30, 0x01);

    Set_6106_Reg(0xF1, interval);
}
//-----
void DisableWDT(void)
{
    unsigned char bBuf;

    Set_6106_LD(0x08);
    Set_6106_Reg(0x30, 0x00);
}
//-----

//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#include "6106.H"
#include <dos.h>
//-----
unsigned int 6106_BASE;
void Unlock_6106 (void);
void Lock_6106 (void);
//-----
unsigned int Init_6106(void)
{
    unsigned int result;
    unsigned char ucDid;

    6106_BASE = 0x4E;
    result = 6106_BASE;

    ucDid = Get_6106_Reg(0x20);
    if (ucDid == 0x07) //6106
    { goto Init_Finish; }

    6106_BASE = 0x2E;
    result = 6106_BASE;

    ucDid = Get_6106_Reg(0x20);
    if (ucDid == 0x07) //6106
    { goto Init_Finish; }

    6106_BASE = 0x00;
    result = 6106_BASE;

Init_Finish:
    return (result);
}

```

```
}
//-----
void Unlock_6106 (void)
{
    outportb(6106_INDEX_PORT, 6106_UNLOCK);
    outportb(6106_INDEX_PORT, 6106_UNLOCK);
}
//-----
void Lock_6106 (void)
{
    outportb(6106_INDEX_PORT, 6106_LOCK);
}
//-----
void Set_6106_LD( unsigned char LD)
{
    Unlock_6106();
    outportb(6106_INDEX_PORT, 6106_REG_LD);
    outportb(6106_DATA_PORT, LD);
    Lock_6106();
}
//-----
void Set_6106_Reg( unsigned char REG, unsigned char DATA)
{
    Unlock_6106();
    outportb(6106_INDEX_PORT, REG);
    outportb(6106_DATA_PORT, DATA);
    Lock_6106();
}
//-----
unsigned char Get_6106_Reg(unsigned char REG)
{
    unsigned char Result;
    Unlock_6106();
    outportb(6106_INDEX_PORT, REG);
    Result = inportb(6106_DATA_PORT);
    Lock_6106();
    return Result;
}
//-----
```