

EPS-CFS2

Intel® 8th/9th Coffee Lake Rugged w/Fan Embedded System

Quick Reference Guide

2nd Ed – 17 November 2020

Copyright Notice

Copyright © 2020 Avalue Technology Inc., ALL RIGHTS RESERVED.

FCC Statement



THIS DEVICE COMPLIES WITH PART 15 FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

- (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
- (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS "A" DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES.

THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS.

OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE.

A Message to the Customer

Avalue Customer Services

Each and every Avalue's product is built to the most exacting specifications to ensure reliable performance in the harsh and demanding conditions typical of industrial environments. Whether your new Avalue device is destined for the laboratory or the factory floor, you can be assured that your product will provide the reliability and ease of operation for which the name Avalue has come to be known.

Your satisfaction is our primary concern. Here is a guide to Avalue's customer services. To ensure you get the full benefit of our services, please follow the instructions below carefully.

Technical Support

We want you to get the maximum performance from your products. So if you run into technical difficulties, we are here to help. For the most frequently asked questions, you can easily find answers in your product documentation. These answers are normally a lot more detailed than the ones we can give over the phone. So please consult the user's manual first.

To receive the latest version of the user's manual; please visit our Web site at:

<http://www.avalue.com.tw/>

Content

| | | |
|-----------|---|----|
| 1. | Getting Started | 5 |
| 1.1 | Safety Precautions | 5 |
| 1.2 | EPS-CFS2 Packing List | 5 |
| 1.3 | EPS-CFS2 System Specifications | 6 |
| 1.4 | System Overview | 9 |
| 1.4.1 | Front View | 9 |
| 1.4.2 | Rear View | 9 |
| 1.5 | System Dimensions | 11 |
| 1.5.1 | Front & Top view | 11 |
| 2. | Hardware Configuration | 12 |
| 2.1 | EPS-CFS2 connector mapping | 13 |
| 2.1.1 | Serial Port 1 connector (COM1) | 13 |
| 2.1.2 | Serial Port 2 connector (COM2) | 13 |
| 2.1.3 | General purpose I/O connector (GPIO) | 14 |
| 2.2 | Installing SSD & Memory, Mini PCIe (EPS-CFS2) | 15 |
| 3. | BIOS Setup | 16 |
| 3.1 | Introduction | 17 |
| 3.2 | Starting Setup | 17 |
| 3.3 | Using Setup | 18 |
| 3.4 | Getting Help | 19 |
| 3.5 | In Case of Problems | 19 |
| 3.6 | BIOS setup | 20 |
| 3.6.1 | Main Menu | 20 |
| 3.6.1.1 | System Language | 21 |
| 3.6.1.2 | System Date | 21 |
| 3.6.1.3 | System Time | 21 |
| 3.6.2 | Advanced Menu | 21 |
| 3.6.2.1 | CPU Configuration | 22 |
| 3.6.2.1.1 | CPU – Power Management Control | 23 |
| 3.6.2.2 | PCH-FW Configuration | 24 |
| 3.6.2.2.1 | OEM Flags Settings | 25 |
| 3.6.2.2.2 | Firmware Update Configuration | 25 |
| 3.6.2.3 | Trusted Computing | 26 |
| 3.6.2.4 | APCI Settings | 26 |
| 3.6.2.5 | IT8528 Super IO Configuration | 27 |

EPS-CFS2

| | | |
|-------------|---|----|
| 3.6.2.5.1 | Serial Port 1 Configuration | 28 |
| 3.6.2.5.2 | Serial Port 2 Configuration | 28 |
| 3.6.2.6 | EC 8528 HW Monitor | 29 |
| 3.6.2.7 | S5 RTC Wake Settings | 29 |
| 3.6.2.8 | Serial Port Console Redirection | 30 |
| 3.6.2.8.1 | Legacy Console Redirection Settings | 31 |
| 3.6.2.9 | USB Configuration..... | 32 |
| 3.6.2.10 | Network Stack Configuration..... | 33 |
| 3.6.2.11 | NVMe Configuration | 33 |
| 3.6.3 | Chipset | 34 |
| 3.6.3.1 | System Agent (SA) Configuration | 34 |
| 3.6.3.1.1 | Memory Configuration | 35 |
| 3.6.3.1.2 | Graphics Configuration..... | 36 |
| 3.6.3.1.3 | DMI/OPI Configuration | 37 |
| 3.6.3.2 | PCH-IO Configuration..... | 37 |
| 3.6.3.2.1 | PCI Express Configuration..... | 38 |
| 3.6.3.2.1.1 | Intel I211 LAN Chip (PCI-E Port 6) | 38 |
| 3.6.3.2.1.2 | mPCIe/mSATA Slot (PEI-E Port 15)..... | 39 |
| 3.6.3.2.2 | SATA And RST Configuration..... | 40 |
| 3.6.3.2.3 | HD Audio Configuration | 41 |
| 3.6.3.3 | Board & Panel Configuration..... | 41 |
| 3.6.4 | Security | 42 |
| 3.6.4.1 | Secure Boot..... | 43 |
| 3.6.4.1.1 | Key Management | 44 |
| 3.6.5 | Boot | 48 |
| 3.6.6 | Save and exit | 49 |
| 3.6.6.1 | Save Changes and Reset | 49 |
| 3.6.6.2 | Discard Changes and Reset | 49 |
| 3.6.6.3 | Restore Defaults..... | 49 |
| 3.6.6.4 | Launch EFI Shell from filesystem device | 49 |

1. Getting Started

1.1 Safety Precautions

Warning!



Always completely disconnect the power cord from your chassis whenever you work with the hardware. Do not make connections while the power is on. Sensitive electronic components can be damaged by sudden power surges. Only experienced electronics personnel should open the PC chassis.

Caution!



Always ground yourself to remove any static charge before touching the CPU card. Modern electronic devices are very sensitive to static electric charges. As a safety precaution, use a grounding wrist strap at all times. Place all electronic components in a static-dissipative surface or static-shielded bag when they are not in the chassis.

1.2 EPS-CFS2 Packing List

- 1 x EPS-CFS2 Intel® 8th/9th Coffee Lake Rugged w/Fan Embedded System
- Other major components include the followings:
 - Screw kit
 - 120W AC-DC Adapter
 - Power Cord
 - Wall Mount Kit



If any of the above items is damaged or missing, contact your retailer.

1.3 EPS-CFS2 System Specifications

| System | |
|---------------------------|--|
| CPU | Intel® Core™ i7-8700T Processor (12M Cache, up to 4.00 GHz) Intel® Core™ i5-8500T Processor (9M Cache, up to 3.50 GHz) Intel® Core™ i3-8100T Processor (6M Cache, 3.10 GHz) Intel® Pentium® Gold G5400T Processor (4M Cache, 3.10 GHz) Intel® Celeron® G4900T Processor (2M Cache, 2.90 GHz) |
| SBC | ECM-CFS |
| BIOS | AMI uEFO BIOS, 256 Mbit SPI Flash ROM iAMT supported |
| System Chipset | Intel® Q370/H310 Express Chipset |
| System Memory | 1 x 260-Pin SO-DIMM Socket Up to 32GB DDR4 2400/2666MHz |
| Watchdog Timer | H/W Reset, 1sec. – 65535sec./min. 1sec. step |
| H/W Status Monitor | Monitoring System Temperature, Voltage and FAN Status with Auto Throttling Control |
| Expansion | |
| Expansion | 1 x Mini PCIe Socket (Q370 PCIe/SATA/USB 2.0) (H310 SATA/USB2.0) |
| Storage | |
| Combination | 1 x mSATA 2 x 2.5" Drive Bay (Internal) |
| Front I/O | |
| USB Port | 2 x USB 2.0 |
| Button | 1 x Power On/Off, 1 x Reset button |
| Rear I/O | |
| USB Port | 4 x USB 3.1 (w/Q370 Gen2; w/H310 Gen1) |
| Serial Port | 2 x RS-232 |
| LED | 2 x LED for PWR and HDD LED |
| LAN | 2 x Giga LAN w/LED |
| Audio | 1 x Mic-In, 1 x Line-Out |
| GPIO | 1 x 8-bit GPIO |
| Others | 2 x Antenna with Dust Cover |
| Display | |
| Chipset | Processor Graphics Intel® UHD Graphics 630 (i7-8700T, i5-8500T, i3-8100T) Intel® UHD Graphics 610 (Pentium G5400T, Celeron G4900T) |


| | |
|---------------------------------------|--|
| Display Interface | 2 x HDMI |
| Resolution | HDMI: Max. resolution 4096 x 2304 @ 30Hz |
| Multiple Display | Dual Display |
| Ethernet | |
| Chipset | 1 x Intel I211AT GbE controller 1 x Intel I219LM Gigabit Ethernet PHY |
| Ethernet Speed | 10/100/1000 Base-Tx compatible |
| Ethernet Interface | 2 x RJ45 w/LED |
| Audio | |
| Chipset | Realtek ALC892 Codec |
| Audio Interface | 1 x Mic-In 1 x Line-Out |
| Mechanical & Environmental | |
| Power Connector | Lockable DC Jack |
| Power Requirement | 12 Vdc |
| Power Type | AT/ATX (ATX is default setting) |
| ACPI | Single power ATX Support S0,S3, S4, S5 ACPI 5.0 Compliant |
| Dimension (W x L x H) | 170mm x 195mm x 65mm 206mm x 195mm x 71mm (w/wall mount) |
| Weight | 2.3kg (w/ package) 1.8kg (system) |
| Color | Black & Blue |
| Mounting Kit | Wall mount (standard) |
| Reliability | |
| Vibration Test | With SSD: 1.5 Grms, IEC 60068-2-64, Random, 5 ~ 500Hz, 30min/axis |
| Package vibration test | Without SSD: 2.16 Grms, IEC 60068-2-64, Random, 5 ~ 500Hz, 30min/axis |
| Shock | With SSD: 10g, IEC 60068-2-27, 11ms |
| Drop Test | ISTA 2A, IEC-60068-2-32 Test : Ed |
| Operating Temperature | With extended temperature peripherals: -10°C ~ 45°C (14°F ~ 113°F) with 0.5m/air flow With extended temperature peripherals: -10°C ~ 40°C (14°F ~ 104°F) with 0.2m/air flow |
| Operating Humidity | 40°C @ 95% Relative Humidity, Non-condensing |
| Storage Temperature | -40°C ~ 75°C (-40°F ~ 167°F) |
| Certification | CE, FCC Class B |
| OS Supported | Win 10/ Linux |




Note: Specifications are subject to change without notice.

1.4 System Overview

1.4.1 Front View



1.4.2 Rear View



Connectors


| Label | Function | Note |
|--------|---------------------------|------|
| Power | Power button | |
| USB2.0 | USB 2.0 connector x 2 | |
| USB3.1 | USB 3.1 connector x 4 | |
| COM1/2 | Serial port 1/2 connector | |

EPS-CFS2

| | |
|-----------------|-------------------------------|
| DC-IN | DC power-in connector |
| LAN1/2 | RJ-45 Ethernet 1/2 |
| HDMI1/2 | HDMI connector 1/2 |
| DC-IN | DC Power-in connector |
| HDD | HDD indicator |
| PWR | System power indicator |
| Mic-in | Mic-in audio jack |
| Line-out | Line-out audio jack |
| GPIO | General purpose I/O connector |

1.5 System Dimensions

1.5.1 Front & Top view



2. Hardware Configuration

Jumper and Connector Setting, BIOS Installing

For advanced information, please refer to:

- 1- ECM-CFS User's Manual.





Note: If you need more information, please visit our website:

<http://www.alue.com.tw>



2.1 EPS-CFS2 connector mapping

2.1.1 Serial Port 1 connector (COM1)





| Signal | PIN | PIN | Signal |
|--------|-----|-----|--------|
| DCD# | 1 | 6 | DSR# |
| RXD | 2 | 7 | RTS# |
| TXD | 3 | 8 | CTS# |
| DTR# | 4 | 9 | RI# |
| GND | 5 | | |

2.1.2 Serial Port 2 connector (COM2)




| Signal | PIN | PIN | Signal |
|--------|-----|-----|--------|
| DCD# | 1 | 6 | DSR# |
| RXD | 2 | 7 | RTS# |
| TXD | 3 | 8 | CTS# |
| DTR# | 4 | 9 | RI# |
| GND | 5 | | |

2.1.3 General purpose I/O connector (GPIO)

| Signal | PIN | PIN | Signal |
|----------|-----|-----|------------|
| DIO_GP20 | 1 | 7 | DIO_GP23 |
| DIO_GP10 | 2 | 8 | DIO_GP13 |
| DIO_GP21 | 3 | 9 | SMB_SCL_S0 |
| DIO_GP11 | 4 | 10 | SMB_SDA_S0 |
| DIO_GP22 | 5 | 11 | GND |
| DIO_GP12 | 6 | 12 | +5V |


2.2 Installing SSD & Memory, Mini PCIe (EPS-CFS2)



Step1. For SSD installation, please remove the top cover, Fix SSD using the 8 screws in the Accessory Kit.

Note:

Before installing SSD, the FAN cable must be removed first while opening the chassis.



Step2. For Memory and Mini PCIe installation, Unfasten 2 screws to remove the cover.

Step3. Insert Mini PCIe card into designated locations and fasten with 2 screws to complete MPCIE installation.

Step4. Slide the DDR4 SODIMM into the memory socket and press it down until properly seated.

Step5. Re-assemble your system back through previous steps to complete the installation.

3.BIOS Setup

3.1 Introduction

The BIOS setup program allows users to modify the basic system configuration. In this following chapter will describe how to access the BIOS setup program and the configuration options that may be changed.

3.2 Starting Setup

AMI BIOS™ is immediately activated when you first power on the computer. The BIOS reads the system information contained in the NVRAM and begins the process of checking out the system and configuring it. When it finishes, the BIOS will seek an operating system on one of the disks and then launch and turn control over to the operating system.

While the BIOS is in control, the Setup program can be activated in one of two ways:

By pressing <F2> or immediately after switching the system on, or

By pressing the <F2> or key when the following message appears briefly at the left-top of the screen during the POST (Power On Self Test).

Press <F2> or to enter SETUP

If the message disappears before you respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the "RESET" button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt>, and <Delete> keys.

3.3 Using Setup

In general, you use the arrow keys to highlight items, press <Enter> to select, use the PageUp and PageDown keys to change entries, press <F1> for help and press <Esc> to quit. The following table provides more detail about how to navigate in the Setup program using the keyboard.

| Button | Description |
|---------|---|
| ↑ | Move to previous item |
| ↓ | Move to next item |
| ← | Move to the item in the left hand |
| → | Move to the item in the right hand |
| Esc key | Main Menu -- Quit and not save changes into NVRAM Status Page Setup Menu and Option Page Setup Menu -- Exit current page and return to Main Menu |
| + key | Increase the numeric value or make changes |
| - key | Decrease the numeric value or make changes |
| F1 key | General help, only for Status Page Setup Menu and Option Page Setup Menu |
| F2 key | Previous Values |
| F3 key | Optimized defaults |
| F4 key | Save & Exit Setup |

- **Navigating Through The Menu Bar**

Use the left and right arrow keys to choose the menu you want to be in.



Note: Some of the navigation keys differ from one screen to another.

- **To Display a Sub Menu**

Use the arrow keys to move the cursor to the sub menu you want. Then press <Enter>. A “➤” pointer marks all sub menus.

3.4 Getting Help

Press F1 to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window press <Esc> or the F1 key again.

3.5 In Case of Problems

If, after making and saving system changes with Setup, you discover that your computer no longer is able to boot, the BIOS supports an override to the NVRAM settings which resets your system to its defaults.


The best advice is to only alter settings which you thoroughly understand. To this end, we strongly recommend that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both your systems manufacturer to provide the absolute maximum performance and reliability. Even a seemingly small change to the chipset setup has the potential for causing you to use the override.

3.6 BIOS setup

Once you enter the Aptio Setup Utility, the Main Menu will appear on the screen. The Main Menu allows you to select from several setup functions and exit choices. Use the arrow keys to select among the items and press <Enter> to accept and enter the sub-menu.

3.6.1 Main Menu

This section allows you to record some basic hardware configurations in your computer and set the system clock.



3.6.1.1 System Language

This option allows choosing the system default language.

3.6.1.2 System Date

Use the system date option to set the system date. Manually enter the day, month and year.

3.6.1.3 System Time


Use the system time option to set the system time. Manually enter the hours, minutes and seconds.



Note: The BIOS setup screens shown in this chapter are for reference purposes only, and may not exactly match what you see on your screen.
Visit the Avalue website (www.alue.com.tw) to download the latest product and BIOS information.


3.6.2 Advanced Menu

This section allows you to configure your CPU and other system devices for basic operation through the following sub-menus.




3.6.2.1 CPU Configuration

Use the CPU configuration menu to view detailed CPU specification and configure the CPU.



| Item | Options | Description |
|--|--|---|
| Intel (VMX) Virtualization Technology | Disabled Enabled[Default] | When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology. |
| Active Processor Cores | All[Default] 1 2 3 4 5 6 7 8 | Number of cores to enable in each processor package. |


3.6.2.1.1 CPU – Power Management Control



| Item | Option | Description |
|------------------------------------|--|--|
| Intel® SpeedStep™ | Enabled[Default], Disabled | Allows more than two frequency ranges to be supported. |
| Turbo Mode | Enabled[Default], Disabled | Enable/Disable processor Turbo Mode (requires Intel Speed Step or Intel Speed Shift to be available and enabled). |
| C States | Enabled[Default], Disabled | Enable/Disable CPU Power Management. Allows CPU to go to C states when it's not 100% utilized. |
| Enhanced C-states | Enabled[Default], Disabled | Enable/Disable C1E. When enabled, CPU will switch to minimum speed when all cores enter C-State. |
| C-State Auto Demotion | Disabled, C1 C3 C1 and C3[Default] | Configure C-State Auto Demotion. |
| C-State Un-demotion | Disabled, C1 C3 C1 and C3[Default] | Configure C-State Un-demotion. |
| Package C-State Demotion | Enabled Disabled[Default], | Package C-State Demotion. |
| Package C-State Un-demotion | Enabled Disabled[Default], | Package C-State Un-demotion. |
| Package C State Limit | C0/C1 C2 C3 C6 C7 C7S | Maximum Package C State Limit Setting. CPU Default: Leaves to Factory default value. Auto: Initializes to deepest available Package C State Limit. |


| | | |
|--|--|--|
| | C8 C9 C10 CPU Default Auto[Default] | |
|--|--|--|

3.6.2.2 PCH-FW Configuration



| Item | Options | Description |
|--------------------------|--|--|
| ME State | Disabled, Enabled[Default] | When Disabled ME will be put into ME Temporarily Disabled Mode. |
| AMT BIOS Features | Disabled, Enabled[Default] | When disable AMT BIOS Features are no longer supported and user is no longer able to access MEBx Setup. Note: This option does not disable Manageability Features in FW. |

3.6.2.2.1 OEM Flags Settings




| Item | Option | Description |
|-----------------------|--|--|
| Unconfigure ME | Disabled[Default], Enabled | OEMFlag Bit 15: Unconfigure ME with resetting MEBx password to default. |

3.6.2.2.2 Firmware Update Configuration




| Item | Option | Description |
|-----------------------|--|--|
| Unconfigure ME | Disabled[Default], Enabled | OEMFlag Bit 15: Unconfigure ME with resetting MEBx password to default. |

3.6.2.3 Trusted Computing



| Item | Options | Description |
|--------------------------------|-------------------------------------|---|
| Security Device Support | Disable, Enable [Default] | Enables or Disables BIOS support for security device. O.S. will not show Security Device. TCG EFI protocol and INT1A interface will not be available. |

3.6.2.4 APCI Settings



| Item | Options | Description |
|---------------------------------------|--|---|
| Enable ACPI Auto Configuration | Disabled[Default], Enabled | Enables or Disables BIOS ACPI Auto Configuration. |
| Enable Hibernation | Disabled Enabled[Default], | Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option may not be effective with some OS. |
| ACPI Sleep State | Suspend Disabled, S3 (Suspend to RAM)[Default] | Select the highest ACPI sleep state the system will enter when the SUSPEND button is pressed. |

3.6.2.5 IT8528 Super IO Configuration

You can use this item to set up or change the IT8528 Super IO configuration for serial ports.

Please refer to 3.6.2.5.1~ 3.6.2.5.2 for more information.




| Item | Description |
|------------------------------------|---|
| Serial Port 1 Configuration | Set Parameters of Serial Port 1 (COMA). |
| Serial Port 2 Configuration | Set Parameters of Serial Port 2 (COMB). |

3.6.2.5.1 Serial Port 1 Configuration




| Item | Option | Description |
|-------------|-------------------------------|--------------------------------------|
| Serial Port | Enabled[Default], Disabled | Enable or Disable Serial Port (COM). |

3.6.2.5.2 Serial Port 2 Configuration




| Item | Option | Description |
|-------------|-------------------------------|--------------------------------------|
| Serial Port | Enabled[Default], Disabled | Enable or Disable Serial Port (COM). |

3.6.2.6 EC 8528 HW Monitor




| Item | Options | Description |
|---------------------------|---------------------------------------|--------------------------------|
| Smart Fan Function | Enabled, Disabled [Default] | Enables or Disables Smart Fan. |

3.6.2.7 S5 RTC Wake Settings




| Item | Options | Description |
|---------------------|---|--|
| Wake system from S5 | Disabled[Default], Fixed Time Dynamic Time | Enable or disable System wake on alarm event. Select Fixed Time, system will wake on the hr::min::sec specified. Select Dynamic Time, System will wake on the current time + Increase minute(s). |

3.6.2.8 Serial Port Console Redirection



| Item | Options | Description |
|---------------------|--|--|
| Console Redirection | Disabled[Default], Enabled | Console Redirection Enable or Disable. |


3.6.2.8.1 Legacy Console Redirection Settings



| Item | Option | Description |
|-----------------------------|--|--|
| Redirection COM Port | COM0[Default] | Select a COM port to display redirection of Legacy OS and Legacy OPROM Messages. |
| Resolution | 80x24[Default] 80x25 | On Legacy OS, the Number of Rows and Columns supported redirection. |
| Redirect After POST | Always Enable[Default] BootLoader | When Bootloader is selected, then Legacy Console Redirection is disabled before booting to legacy OS. When Always Enable is selected, then Legacy Console Redirection is enabled for legacy OS. Default setting for this option is set to Always Enable. |

3.6.2.9 USB Configuration

The USB Configuration menu helps read USB information and configures USB settings.




| Item | Options | Description |
|------------------------------|--|--|
| USB transfer time-out | 1 sec 5 sec 10 sec 20 sec[Default] | The time-out value for Control, Bulk, and Interrupt transfers. |
| Device reset time-out | 10 sec 20 sec[Default] 30 sec 40 sec | USB mass storage device Start Unit command time-out. |
| Device power-up delay | Auto [Default] Manual | Maximum time the device will take before it properly reports itself to the Host Controller. 'Auto' uses default value: for a Root port it is 100ms, for a Hub port the delay is taken from Hub descriptor. |
| Mass Storage Devices | Auto [Default] Floppy Forced FDD Hard Disk CD-ROM | Mass storage device emulation type. 'AUTO' enumerates devices according to their media format. Optical drives are emulated as 'CDROM', drives with no media will be emulated according to a drive type. |

3.6.2.10 Network Stack Configuration



| Item | Options | Description |
|----------------------|--------------------------------------|------------------------------------|
| Network Stack | Enabled Disabled [Default] | Enable/Disable UEFI Network Stack. |

3.6.2.11 NVMe Configuration



3.6.3 Chipset




3.6.3.1 System Agent (SA) Configuration




| Item | Option | Description |
|------|------------------------------|------------------|
| VT-d | Enabled[Default] Disabled | VT-d capability. |

3.6.3.1.1 Memory Configuration



| Item | Option | Description |
|------------------|--|---|
| Max TOLUD | Dynamic [Default] 1 GB 1.25 GB 1.5 GB 1.75 GB 2 GB 2.25 GB 2.5 GB 2.75 GB 3 GB | Maximum Value of TOLUD. Dynamic assignment would adjust TOLUD automatically based on largest MMIO length of installed graphic controller. |

3.6.3.1.2 Graphics Configuration



| Item | Option | Description |
|------------------------|-----------------------------------|---|
| Primary Display | Auto [Default] IGFX | Select which of IGFX/PEG/PCI Graphics device should be Primary Display Or select SG for Switchable Gfx. |
| GTT Size | 2MB 4MB 8MB[Default] | Select the GTT Size. |

3.6.3.1.3 DMI/OPI Configuration




3.6.3.2 PCH-IO Configuration




| Item | Option | Description |
|--------------------|------------------------------|-----------------------------|
| PCH LAN Controller | Disabled Enabled[Default] | Enable/Disable onboard NIC. |

3.6.3.2.1 PCI Express Configuration




3.6.3.2.1.1 Intel I211 LAN Chip (PCI-E Port 6)



| Item | Option | Description |
|------------------------------------|--|---|
| Intel I211 LAN Chip (PCI-E Port 6) | Enabled[Default], Disabled | Control the PCI Express Root Port. |
| ASPM 5 | Disabled, L0s | Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto |

| | | |
|-----------------------|--|--|
| | L1 L0sL1 Auto[Default] | configure DISABLE – Disables ASPM. |
| L1 Substates | Disabled, L1.1 L1.1 & L1.2[Default] | PCI Express L1 Substates settings. |
| PCIe Speed | Auto[Default] Gen1 Gen2 Gen3 | Configure PCIe Speed. |
| Detect Timeout | 0 | The number of milliseconds reference code will wait for link to exit Detect state for enabled ports before assuming there is no device and potentially disabling the port. |


3.6.3.2.1.2 mPCIe/mSATA Slot (PEI-E Port 15)



| Item | Option | Description |
|---|---|--|
| mPCIe/mSATA Slot (PEI-E Port 15) | Enabled[Default], Disabled | Control the PCI Express Root Port. |
| ASPM 14 | Disabled, L0s L1 L0sL1 Auto[Default] | Set the ASPM Level: Force L0s – Force all links to L0s State AUTO – BIOS auto configure DISABLE – Disables ASPM. |
| L1 Substates | Disabled, L1.1 L1.1 & L1.2[Default] | PCI Express L1 Substates settings. |
| PCIe Speed | Auto[Default] Gen1 Gen2 | Configure PCIe Speed. |


| | | |
|-----------------------|------|--|
| | Gen3 | |
| Detect Timeout | 0 | The number of milliseconds reference code will wait for link to exit Detect state for enabled ports before assuming there is no device and potentially disabling the port. |

3.6.3.2.2 SATA And RST Configuration




| Item | Options | Description |
|----------------------------|--|--|
| SATA Controller(s) | Enabled[Default] Disabled | Enable/Disable SATA Device. |
| SATA Mode Selection | AHCI[Default], RAID | Determines how SATA controller(s) operate. |
| SATA Test Mode | Enabled Disabled[Default] | The Mode Enable/Disable (Loop Back). |
| SATA Port | Enabled[Default] Disabled | Enable or Disable SATA Port. |
| SATA Device Type | Hard Disk Drive[Default] Solid State Drive | Identify the SATA port is connected to Solid State Drive or Hard Disk Drive. |

3.6.3.2.3 HD Audio Configuration




| Item | Option | Description |
|----------|------------------------------|--|
| HD Audio | Disabled Enabled[Default] | Control Detection of the HD-Audio device. Disable = HDA will be unconditionally disabled Enabled = HDA will be unconditionally enabled |

3.6.3.3 Board & Panel Configuration



| Item | Option | Description |
|-------------------------|--|---|
| Active Panel (eDP/LVDS) | Disabled[Default] Enabled | Active Internal LVDS(eDP->Cg7511-to-LVDS). |
| ErP Function | Disabled[Default] Enabled | ErP Function (Deep S5). |
| PWR-On After PWR-Fail | Off[Default] On Last state | AC loss resume. |
| Watch Dog | Disabled[Default] 30 sec 40 sec 50 sec 1 min 2 min 10 min 30 min | Select WatchDog. |
| Wake Up by Ring | Disabled Enabled[Default] | Wake Up by Ring from S3/S4/S5. |
| USB Standby Power | Disabled Enabled[Default] | Enable/Disabled USB Standby Power during S3/S4/S5. |

3.6.4 Security





● Administrator Password

Set setup Administrator Password

● User Password



Set User Password

3.6.4.1 Secure Boot






| Item | Option | Description |
|-------------------------|---------------------------------------|--|
| Secure Boot | Disabled[Default] Enabled | Secure Boot feature is Active if Secure Boot is Enabled, Platform Key(PK) is enrolled and the System is in User mode. The mode chagne requires platform reset. |
| Secure Boot Mode | Standard Custom[Default] | Secure Boot mode selector: Standard/Custom. In Custom mode Secure Boot Variables can be configured without authentication. |




3.6.4.1.1 Key Management




Quick Reference Guide



EPS-CFS2




Quick Reference Guide




| Item | Option | Description |
|------------------------------|--|--|
| Factory Key Provision | Disabled [Default] Enabled | Install factory default Secure Boot keys after the platform reset and while the System is in Setup mode. |

3.6.5 Boot



| Item | Option | Description |
|-----------------------------|---------------------------------------|---|
| Setup Prompt Timeout | 1~ 65535 | Number of seconds to wait for setup activation key. 65535(0xFFFF) means indefinite waiting. |
| Bootup NumLock State | On Off[Default] | Select the Keyboard NumLock state |
| Quiet Boot | Disabled[Default] Enabled | Enables or disables Quiet Boot option |
| Boot Option #1 | Set the system boot order. | |

3.6.6 Save and exit



3.6.6.1 Save Changes and Reset

Reset the system after saving the changes.

3.6.6.2 Discard Changes and Reset

Any changes made to BIOS settings during this session of the BIOS setup program are discarded. The setup program then exits and reboots the controller.

3.6.6.3 Restore Defaults

This option restores all BIOS settings to the factory default. This option is useful if the controller exhibits unpredictable behavior due to an incorrect or inappropriate BIOS setting.

3.6.6.4 Launch EFI Shell from filesystem device

Attempts to Launch EFI Shell application (Shellx64.efi) from one of the available filesystem devices.

