

P400M9

4" ARM A73 + A53 Rugged Handheld Computer



Quick Start Guide

1. Getting Started

Congratulations on purchasing Winmate® Rugged Handheld Computer P400M9.

P400M9 Rugged Handheld Computer is an enterprise-class rugged mobile computer with powerful mobile computing solution. The processing power comes from the Cortex-A73 + Cortex-A53 (Octa-core up to 2.0 GHz) processor for high performance. The P400M9 packs WLAN, BT, GPS, and WWAN function - all into a single device. With great multiple wireless communicate design, the P400M9 brings a new level of flexibility, functionality, and rugged design to pocket-sized mobile devices.

Highlights

- Cortex-A73 + Cortex-A53 (Octa-core up to 2.0 GHz)
- 4" 800 x 480 Panel with direct optical bonding
- Supports Android 11
- Compatible for PoC application

2. Unpacking


Check and identify the standard supplied accessories.

Standard factory shipment list:

- **Handheld Computer**



- **Standard Battery**




- **Power Adapter**



- **Quick Start Guide**



3. Description of Parts



No	Item	Description	No	Item	Description
1	Adjusting Knob	Adjust Radio frequency	9	Docking Connector	Connect to desk docking
2	Emergency Button	Send SOS message	10	Audio Jack	Connect to a K-type headset or headphone
3	PTT Button	Press and hold to speak during half-duplex calls	11	USB Type C	For data transfer and charging
4	Function Button	Programmable button. Default: Menu	12	Power Button	Turn on/off the device
5	Volume Buttons	Increase and decrease volume	13	Rear Camera	13MP Autofocus Camera.
6	Front Camera	8 Megapixel Webcam	14	Battery	7.6V, typ. 2500mAh Li-Polymer
7	4" Touch Screen	Display and act as one of the inputs for the PoC Radio	15	SIM Card Slot	Slot to insert Micro SIM card.
8	Speaker	Send out the voice from the device	16	MicroSD Card Slot	Memory card reader port for SD Card

4. First-Time Operation

Inserting Battery Pack




Warning! Discontinue using the device immediately if you notice the battery is swelling or looks puffy or misshapen. Do not attempt to charge or use the device. Do not handle a damaged or leaking battery. Do not let leaking battery fluid come into contact with your eyes, skin, or clothing.



Caution To keep battery health and prevent possible issues from battery over-discharged, please charge the device's built-in backup battery once every two months.


To install the standard battery pack:

1. Disconnect any cords connected to the PoC radio and turn the radio over, back facing up.
2. Locate the Battery Lock Latch and push it to the "Unlocked" position.
3. Insert the battery with the connector-pins side first, and then lower the battery into the battery compartment. The battery will be flat against the housing once fully inserted.
4. Slide the Battery Lock to the "Locked" position.



To remove the battery pack:


1. Shut down the radio. Disconnect any cords connected to the device.
2. Turn the PoC radio over, back facing up.
3. Locate the Battery Lock and slide it to the "Unlocked" position.
4. Lift the battery out of the compartment.



Installing SIM-Card

To install the SIM card:


1. Remove the battery, as described in the section *Inserting Battery Pack*.
2. Push and lift the SIM-card slot.
3. Insert the SIM card into the SIM-card slot. **Chip/contact is facing down.**
4. Push the SIM-Card slot back to the original position.
5. Put the battery back.



Inserting MicroSD Card

To install MicroSD Card:

1. Remove the battery, as described in the section *Inserting Battery Pack*.
2. Push and lift the microSD-card slot.
3. Insert microSD card into slot. **Chip/contact is facing down.**
4. Close the microSD card holder.
5. Put back the battery, as described in the section *Inserting Battery Pack*.



Connecting to Power Supply

The PoC radio operates either on external AC power or internal battery power. It is recommended to use AC power when you start up the radio for the first time.



Caution Use only the AC adapter included with your device. Using other AC adapters may damage the device and the Battery.



Caution Please ensure the battery has fully charged before starting up the device for the first time.

Perform the following to connect the Tablet computer to AC Power:


1. Open I/O protective cover by pulling out the latch.
2. Plug the USB Type C of the power adapter into the USB Type C port of the device.
3. Plug the power cord into the electrical outlet.

5. Turning On and Off the Device

Turning On

1. Press and hold the power button on the right side of the unit for **3 seconds**.
2. When the device vibrates, release the power button.
3. The desktop screen is displayed.


Turning Off

1. Press and hold the power button until the phone options menu appears, tap the **Power Off** .
2. Users can also use the Phone options menu to put the device into silent or airplane mode.







6. PoC Setting

Using PoC Functions

1. In the main APPS window, open the Larzio app and log in. Select any person/group in the address book to enter the call page.



2. Click **Contact** to open contact list, group, and marked favorite list.





Switch Channels

On the **PTT** page, rotate the adjusting knob or click the left/right arrow buttons to switch channels.




Setting

Click the **Setting** at the top right to turn on/off the notification, PoC function, and Bluetooth Mic, also adjust the volume.




Dashboard

1. Click **Other**, **Dashboard**.
2. Click **+ Contact or Group** to add maximum 4 frequently call contacts or groups.




Push to Talk


Press and hold the **Push To Talk** on the screen or the PTT button on the left side of the device to speak during half-duplex calls.



7. Winmate Kiosk Manager

The P400M9 Multi-mode PoC radio comes with preinstalled APP named Winmate® Home Manager (WKM). This application lets the device manager lock the launcher. When the launcher is locked, the user can only use one application assigned by the device manager.

1. In the main APPS window, select the **Kiosk Manager** . Select **Kiosk Manager** to start your settings. Go to **Password Manager** and set your password for this APP. The default password: **password**



Refer to the *User Guide* for more details about Winmate Kiosk Manager.

