

IB915F

Intel® Skylake U
3.5" Disk Size SBC

USER'S MANUAL

Version 1.2

Acknowledgments

AMI is a registered trademark of American Megatrends Inc.

PS/2 is a trademark of International Business Machines Corporation.

Intel and Intel® 6th Generation Mobile Core™ i MCP Processor are registered trademarks of Intel Corporation.

Microsoft Windows is a registered trademark of Microsoft Corporation.

Fintek is a registered trademark of Fintek Technology Corporation.

All other product names or trademarks are properties of their respective owners.

Table of Contents

| | |
|--|-----------|
| Introduction | 1 |
| Product Description..... | 1 |
| Checklist..... | 2 |
| IB915F Specifications..... | 3 |
| Board Dimensions | 5 |
| Installations | 6 |
| Installing the Memory | 7 |
| Setting the Jumpers | 8 |
| Connectors on IB915F | 13 |
| BIOS Setup | 24 |
| Drivers Installation | 44 |
| Intel Chipset Software Installation Utility..... | 45 |
| VGA Drivers Installation | 47 |
| Realtek HD Audio Driver Installation..... | 50 |
| LAN Drivers Installation..... | 52 |
| Intel® Management Engine Interface | 55 |
| Intel® USB 3.0 Drivers..... | 57 |
| ASMedia USB 3.1 Drivers..... | 60 |
| Appendix..... | 62 |
| A. I/O Port Address Map..... | 62 |
| B. Interrupt Request Lines (IRQ) | 63 |
| C. Watchdog Timer Configuration..... | 64 |

This page is intentionally left blank.

Introduction

Product Description

The IB915F is a 3.5-inch single board computer based on the Intel® Skylake U MCP processors.

The IB915F platform is well suited for low-power and high-performance designs in a broad range of markets including Industrial Control & Automation, Digital Signage, Thin Client, Electronic Gaming Machines, and SMB storage appliances.

IB915F Features:

- Supports Intel® 6th generation mobile Core™ i MCP processors
- Two DDR3L SO-DIMM, 1600 MHz, Max. 16GB memory
- Integrated graphics for DisplayPort, LVDS, eDP displays
- 2 x SATA III connector
- 4x COM port connector
- 1 x Mini-PCIe(x1) slot (*w/ USB/mSATA support*)
- 2x GbE (RJ-45) connector
- 1x 9V to 24V DC-IN power connector

Checklist

Your IB915F package should include the items listed below.


- The IB915F SBC
- This User's Manual
- 1 DVD containing chipset drivers and flash memory utility
- Optional cable kit IB75 (containing DC in power cable/PW87, COM port cable / PK1H, SATA & HDD power cable/SATA-26 and USB 2.0 cable/USB-29)
- Other options: Audio-18 audio cable, HSIB915-BGA-B heatsink , HSIB915-BGA-1 heat spreader

IB915F Specifications

| | |
|---------------------|--|
| Product Name | IB915AF-6600 (Supports iAMT) IB915AF-6300 (Supports iAMT) IB915F-6100 IB915F-3955 (MOQ) **IB915 will be model name printed on PCB surface** |
| Form Factor | 3.5" |
| CPU Type | - Intel® 6 th generation mobile Core™ i MCP processors (14nm monolithic) - TDP = 15W (DC) , 42mm x 24mm x 1.16mm, FCBGA1356 @ solder side |
| CPU Speed | Intel® Core™ i7-6600U processor (2.6GHz/3.4GHz) [IB915AF-6600] Intel® Core™ i5-6300U processor (2.4GHz/3GHz) [IB915AF-6300] Intel® Core™ i3-6100U processor (2.3GHz) [IB915F-6100](Non-AMT) Intel® Celeron® 3955U processor (2GHz) [IB915F-3955](Non-AMT) |
| Cache | Up to 4MB |
| Chipset | Integratd in Intel® 6 th Generation Core™ U-series processor |
| BIOS | AMI BIOS |
| Memory | Intel® 6 th Gen. Core™ U-series processor integrated memory controller - DDR3L(1.35V) @1600 MHz, SO-DIMM x 2 , Max.=16GB , Non-ECC |
| Display | Intel® 6 th Gen. Core™ U-series processor integrated Gfx, supports 3 independent displays, - eDP x 1 (Thru eDP) - DP++ x 1 (Thru DDI#1) - LVDS(Thru DDI#2, via NXP PTN3460BS/F6) |
| LAN | 1. Intel® I219LM GbE PHY (IB915AF-6600 & IB915AF-6300) Intel® I219V GbE PHY (IB915F-6100 & IB915F-3955) ** Thru PCIe port # 9** 2. Intel® I211AT as 2 nd GbE ** Thru PCIe port # 10** |
| USB | - Intel® 6 th Gen. Core™ U-series processor integrated USB 2.0 host controller ,2 ports onboard pin header + 1 port thru MiniPCIe - Intel® 6 th Gen. Core™ U-series processor integrated USB 3.0 host controller 4 x USB 3.0 in the rear panel ** Thru USB3 port# 1-port# 4 ** - USB 3.1 type C connector thru ASM1142 PCIe to USB 3.1 host controller ** Thru PCIe port# 1 ** |
| Serial Ports | ATA Intel® 6 th Gen. Core™ U-series processor built-in SATA III controller - 2 x SATA 3.0 (6Gbps) onboard **Thru SATA port# 0 & port# 2 ** - 1 x mSATA via MiniPCIe full-sized slot **Thru SATA port# 1/Pcie port # 11** |
| Audio | Intel® 6 th Gen. Core™ U-series processor built-in HD audio controller Realtek ALC662-GR Codec |

| | |
|-----------------------------------|--|
| LPC I/O | Fintek F81846AD-I (128-pin LQFP [14mm x 14 mm]) <ul style="list-style-type: none"> ▪ COM #1 (RS232/422/485) @ edge I/O With Fintek F81439N transceiver x 1 for jumper-less selection <ul style="list-style-type: none"> ▪ COM #2~COM #4 (RS232 only) [Hardware Monitor] 2 x Thermal inputs 2 x Voltage monitoring |
| Digital IO | 4 in & 4 out |
| iAMT(11.0) | For IB915AF-6600 & IB915AF-6300 |
| Expansion Slots | 1 x mPCIe(x1) w/ USB 2.0 signal, support mSATA [Full-sized] ** Thru PCIe port # 4** |
| Edge Connector | DP connector x 1 [C12ZZDPP23VD11000P] RJ45 x2 for LAN#1 & #2 (Horizontal Combo type) USB 3.0 stack connector x 2 for USB1/2 & USB3/4 [Blue color] RJ50 x 1 for COM #1 USB 3.1 type C connector x 1 |
| On Board Header/ Connector | DF20-20 socket connector x 2 for 24-bit dual channel LVDS 4 pins box header x 1 for backlight/brightness control eDP 30-pin connector x 1 2 ports x SATA III [Blue color] 2x4 pins header x 1 for 2 x USB 2.0 ports[DF11 x 1] DF-11 2x6 pins box header x1 for front audio DF-11 2x5 pins box header x 3 for COM2 ~ COM4 2x5 pins headers x 1 for LPC (Debug purpose only) 4 pins power connector x 1 for SATA HDD 2 pins power connector x 1 for DC-in |
| Watchdog Timer | Yes (256 segments, 0, 1, 2...255 sec/min) |
| Power Input | +9V ~ +24V DC-in |
| RoHS | Yes |
| Board Size | 102mm x 147mm |
| OS support | <ul style="list-style-type: none"> - Windows 8.1 / Industrial; Windows 10 - Linux - Fedora - Ubuntu |
| Others | <ol style="list-style-type: none"> 1. Support RAID function 2. iSMART 3.2 3. RTC battery via cable |
| Optional Cable Kit (IB75) | PW87 x 1 PK1H x 1 SATA-26 x 1 USB29 x 1 |
| Optional items | <ol style="list-style-type: none"> 1. Heatsink 2. Heat Spreader 3. Audio-18 cable (C501AUD1812302000P) |

Board Dimensions



Installations

This section provides information on how to use the jumpers and connectors on the IB915F in order to set up a workable system. The topics covered are:

| | |
|----------------------------|----|
| Installing the Memory..... | 7 |
| Setting the Jumpers..... | 8 |
| Connectors on IB915F..... | 13 |


Installing the Memory

The IB915F board supports two DDR3L memory sockets for a maximum total memory of 16GB DDR3L memory type.

Installing and Removing Memory Modules

To install the DDR3L modules, locate the memory slot on the board and perform the following steps:

1. Hold the DDR3L module so that the key of the DDR3L module aligned with that on the memory slot.
2. Gently push the DDR3L module in an upright position until the clips of the slot close to hold the DDR3L module in place when the DDR3L module touches the bottom of the slot.
3. To remove the DDR3L module, press the clips with both hands.




Setting the Jumpers

Jumpers are used on IB915F to select various settings and features according to your needs and applications. Contact your supplier if you have doubts about the best configuration for your needs. The following lists the connectors on IB915F and their respective functions.

| | |
|--|----|
| Jumper Locations on IB915F..... | 9 |
| JP1: LVDS Panel Brightness Control Selection | 10 |
| JP2: LCD Backlight Connector | 10 |
| JP3: USB 2.0 Pin Header..... | 11 |
| JP4: SPI Flash Connector (Factory use only) | 11 |
| JP5: LPC debug Connector (Factory use only)..... | 11 |
| J7: Clear ME..... | 12 |
| J8: Clear CMOS Contents..... | 12 |

Jumper Locations on IB915F




Jumpers on IB915F

Page


| | |
|---|----|
| JP1: LVDS Panel Brightness Control Selection..... | 10 |
| JP2: LCD Backlight Connector | 10 |
| JP3: USB 2.0 Pin Header..... | 11 |
| JP4: SPI Flash Connector (Factory use only)..... | 11 |
| JP5: LPC debug Connector (Factory use only) | 11 |
| J7: Clear ME..... | 12 |
| J8: Clear CMOS Contents | 12 |

JP1: LVDS Panel Brightness Control Selection




| JP1 | Brightness Control (PWM mode) |
|-------|-------------------------------|
| Open | 3.3V |
| Close | 5V(Default) |

JP2: LCD Backlight Connector




| Pin # | Signal Name |
|-------|--------------------|
| 1 | +12V |
| 2 | Backlight Enable |
| 3 | Brightness Control |
| 4 | Ground |

JP3: USB 2.0 Pin Header




| Signal Name | Pin # | Pin # | Signal Name |
|-------------|-------|-------|-------------|
| Vcc | 1 | 2 | Ground |
| D0- | 3 | 4 | D1+ |
| D0+ | 5 | 6 | D1- |
| Ground | 7 | 8 | Vcc |


JP4: SPI Flash Connector (Factory use only)



JP5: LPC debug Connector (Factory use only)




J7: Clear ME



| J7 | Setting | Function |
|--------------|-------------------------|----------|
| <p>1 2 3</p> | Pin 1-2 Short/Closed | Normal |
| <p>1 2 3</p> | Pin 2-3 Short/Closed | Clear ME |

J8: Clear CMOS Contents




| J8 | Setting | Function |
|--------------|-------------------------|------------|
| <p>1 2 3</p> | Pin 1-2 Short/Closed | Normal |
| <p>1 2 3</p> | Pin 2-3 Short/Closed | Clear CMOS |


Connectors on IB915F

| | |
|---|-----|
| Connector Locations on IB915F | 14 |
| CN1 / CN2: SATA3 Connector..... | 15 |
| CN3: Gigabit LAN (I219) / Gigabit LAN (I211AT)..... | 15 |
| CN4: eDP Connector (30 Pin)..... | 15 |
| CN5 / CN6: USB3.0 Connector | 166 |
| CN7: COM1 RJ50 Connector | 166 |
| CN8: Display Port Connector..... | 166 |
| CN9: USB Type C Connector | 166 |
| J1: Flash Descriptor Security Override (Factory use only) | 177 |
| J2/JP6: LVDS Panel Power Selection | 177 |
| J3, J4: LVDS Connectors | 188 |
| J5: Audio Connector | 199 |
| J11: DDR3L SO-DIMM (CH-A) Socket..... | 199 |
| J6: DDR3L SO-DIMM (CH-B) Socket..... | 199 |
| J9: Battery Connector | 20 |
| J10: SATA HDD Power Connectors | 20 |
| J12: MCU JTAG..... | 20 |
| J13: Mini PCIE / mSATA Slot..... | 211 |
| J14, J17: COM3/COM4..... | 211 |
| J15: Front Panel..... | 211 |
| J16: COM2 | 222 |
| J18: Digital I/O..... | 22 |
| J19: DC_IN Connector..... | 233 |

Connector Locations on IB915F




CN1 / CN2: SATA3 Connector



CN3: Gigabit LAN (I219) / Gigabit LAN (I211AT)


CN4: eDP Connector (30 Pin) (I-PEX_20374-030E-31)



| Signal Name | Pin # | Pin # | Signal Name |
|-------------|-------|-------|-------------|
| BL_Power | 2 | 1 | NC |
| BL_Power | 4 | 3 | BL_Power |
| NC | 6 | 5 | BL_Power |
| BRIGHTNESS | 8 | 7 | NC |
| GND | 10 | 9 | Bklt_en |
| GND | 12 | 11 | GND |
| HPD | 14 | 13 | GND |
| GND | 16 | 15 | GND |
| Panel_VDD | 18 | 17 | NC |
| GND | 20 | 19 | Panel_VDD |
| AUX_P | 22 | 21 | AUX_N |
| TX0_P | 24 | 23 | GND |
| GND | 26 | 25 | TX0_N |
| TX1_N | 28 | 27 | TX1_P |
| NC | 30 | 29 | GND |

CN5 / CN6: USB3.0 Connector

CN7: COM1 RJ50 Connector



RJ-50_10P10C


| Pin # | Signal Name |
|-------|-------------|
| 1 | DSR |
| 2 | GND |
| 3 | GND |
| 4 | TXD |
| 5 | RXD |
| 6 | DCD |
| 7 | DTR |
| 8 | CTS |
| 9 | RTS |
| 10 | RI |

| Pin # | Signal Name | | |
|-------|-------------|--------|--------|
| | RS-232 | RS-422 | RS-485 |
| 1 | DSR | - | - |
| 2, 3 | Ground | Ground | Ground |
| 4 | TX | RX+ | - |
| 5 | RX | TX+ | DATA+ |
| 6 | DCD | TX- | DATA- |
| 7 | DTR | RX- | - |
| 8 | CTS | - | - |
| 9 | RTS | - | - |
| 10 | RI | - | - |


CN8: DisplayPort Connector



CN9: USB Type C Connector

J1: Flash Descriptor Security Override (Factory use only)



J2/JP6: LVDS Panel Power Selection




| J2/JP6 | Setting | Panel Voltage |
|--|-------------------------|----------------|
|  | Pin 1-2 Short/Closed | 3.3V (default) |
|  | Pin 2-3 Short/Closed | 5V |

J3, J4: LVDS Connectors (Hirose DF20G-20DP-1V)


J4: First Channel LVDS

J3: Second Channel LVDS




| Signal Name | Pin # | Pin # | Signal Name |
|-------------|-------|-------|-------------|
| TX0N | 2 | 1 | TX0P |
| Ground | 4 | 3 | Ground |
| TX1N | 6 | 5 | TX1P |
| Ground | 8 | 7 | Ground |
| TX2N | 10 | 9 | TX2P |
| Ground | 12 | 11 | Ground |
| CLKN | 14 | 13 | CLKP |
| Ground | 16 | 15 | Ground |
| TX3N | 18 | 17 | TX3P |
| Power | 20 | 19 | Power |

J5: Audio Connector (DF11-12DP-2DSA)




| Signal Name | Pin # | Pin # | Signal Name |
|-------------|-------|-------|-------------|
| LINEOUT_R | 2 | 1 | LINEOUT_L |
| Ground | 4 | 3 | JD_FRONT |
| LINEIN_R | 6 | 5 | LINEIN_L |
| Ground | 8 | 7 | JD_LINEIN |
| MIC-R | 10 | 9 | MIC_L |
| Ground | 12 | 11 | JD_MIC1 |


J11: DDR3L SO-DIMM (CH-A) Socket




J6: DDR3L SO-DIMM (CH-B) Socket



J9: Battery Connector




J10: SATA HDD Power Connectors




| Pin # | Signal Name |
|-------|-------------|
| 1 | +5V |
| 2 | Ground |
| 3 | Ground |
| 4 | +12V |


J12: MCU JTAG





J13: Mini PCIE / mSATA Slot



J14, J17: COM3/COM4




J15: Front Panel




| Signal Name | Pin # | Pin # | Signal Name |
|-------------|-------|-------|-------------|
| GND | 1 | 2 | PWR_BTN |
| 3.3V | 3 | 4 | HDD Active |
| GND | 5 | 6 | Reset |
| +5V | 7 | 8 | GND |

J16: COM2




| Signal Name | Pin # | Pin # | Signal Name |
|--------------------------|-------|-------|--------------------------|
| DCD, Data carrier detect | 1 | 2 | RXD, Receive data |
| TXD, Transmit data | 3 | 4 | DTR, Data terminal ready |
| GND, ground | 5 | 6 | DSR, Data set ready |
| RTS, Request to send | 7 | 8 | CTS, Clear to send |
| RI, Ring indicator | 9 | 10 | Not Used |

J18: Digital I/O



| Signal Name | Pin # | Pin # | Signal Name |
|-------------|-------|-------|-------------|
| GND | 1 | 2 | VCC |
| OUT3 | 3 | 4 | OUT1 |
| OUT2 | 5 | 6 | OUT0 |
| IN3 | 7 | 8 | IN1 |
| IN2 | 9 | 10 | IN0 |

J19: DC_IN Connector

| Pin # | Signal Name |
|-------|-------------|
| 1 | +9V ~ +24V |
| 2 | GND |

BIOS Setup

This chapter describes the different settings available in the BIOS that comes with the board. The topics covered in this chapter are as follows:

| | |
|---------------------------|----|
| BIOS Introduction | 25 |
| BIOS Setup | 25 |
| Advanced Settings | 27 |
| Chipset Settings | 39 |
| Boot Settings..... | 42 |
| Security Settings | 41 |
| Save & Exit Settings..... | 43 |

BIOS Introduction

The BIOS (Basic Input/Output System) installed in your computer system's ROM provides critical low-level support for a standard device such as disk drives, serial ports and parallel ports. It also adds virus and password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

BIOS Setup

The BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS ROM of the system stores the Setup utility. When you turn on the computer, the BIOS is immediately activated. Pressing the key immediately allows you to enter the Setup utility. If you are a little bit late pressing the key, POST (Power On Self Test) will continue with its test routines, thus preventing you from invoking the Setup. If you still wish to enter Setup, restart the system by pressing the "Reset" button or simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys. You can also restart by turning the system Off and back On again. The following message will appear on the screen:

```
Press <DEL> or <ESC> to Enter Setup
```

In general, you press the arrow keys to highlight items, <Enter> to select, the <PgUp> and <PgDn> keys to change entries, <F1> for help and <Esc> to quit.

When you enter the Setup utility, the Main Menu screen will appear on the screen. The Main Menu allows you to select from various setup functions and exit choices.

Main Settings

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|------------------|----------|---------|------------------|----------|------------------------------------|
| Access Level | | | Administrator | | Choose the system default language |
| Total memory | | | 4096 MB | | |
| Memory Frequency | | | 1600 Mhz | | → ← Select Screen |
| System Language | | | [Englisg] | | ↑ ↓ Select Item |
| System Date | | | [Tue 10/29/2013] | | Enter: Select |
| System Time | | | [15:27:20] | | + - Change Field |
| | | | | | F1: General Help |
| | | | | | F2: Previous Values |
| | | | | | F3: Optimized Default |
| | | | | | F4: Save |
| | | | | | ESC: Exit |

System Date

Set the Date. Use Tab to switch between Data elements.

System Time

Set the Time. Use Tab to switch between Data elements.

Advanced Settings

This section allows you to configure and improve your system and allows you to set up some system features according to your preference.

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|------|--|---------|------|----------|---|
| | <ul style="list-style-type: none"> ▶ ACPI Settings ▶ LVDS (eDP/DP) Configuration ▶ ISmart Controller ▶ AMT Configuration ▶ Fintek Super IO Configuration ▶ Hardware Monitor ▶ CPU Configuration ▶ SATA Configuration ▶ Acoustic Management Configuration ▶ Network Stack Configuration ▶ CSM Configuration ▶ USB Configuration | | | | → ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit |

ACPI Settings

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|---------------|--------------------------------|---------|------------------------|----------|-----------------------|
| ACPI Settings | | | | | |
| | Enable ACPI Auto Configuration | | [Disabled] | | → ← Select Screen |
| | Enable Hibernation | | [Enabled] | | ↑ ↓ Select Item |
| | ACPI Sleep State | | [S3 (Suspend to R...)] | | Enter: Select |
| | Lock Legacy Resources | | [Disabled] | | + - Change Field |
| | S3 Video Report | | [Disabled] | | F1: General Help |
| | ACPI Low Power S0 Idle | | [Disabled] | | F2: Previous Values |
| | | | | | F3: Optimized Default |
| | | | | | F4: Save |
| | | | | | ESC: Exit |

Enable Hibernation

Enables or Disables System ability to hibernate (OS/S4 Sleep State). This option may be not effective with some OS.

ACPI Sleep State

Select ACPI sleep state the system will enter, when the SUSPEND button is pressed.

Lock Legacy Resources

Enabled or Disabled Lock of Legacy Resources.

S3 Video Report

Enabled or Disabled S3 Video Report.

ACPI Low Power S0 Idle

Enabled or Disabled ACPI Low Power S0 Idle Support.

LVDS (eDP/DP) Configuration

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|-----------------------------|----------|-----------------------|-------------|----------|-----------------------|
| LVDS (eDP/DP) Configuration | | | | | |
| | | LVDS (eDP/DP) Support | [Enabled] | | → ← Select Screen |
| | | Panel Color Depth | [18 BIT] | | ↑ ↓ Select Item |
| | | LVDS Channel Type | [Single] | | Enter: Select |
| | | Panel Type | [800 x 600] | | + - Change Field |
| | | Brightness Control | [Enabled] | | F1: General Help |
| | | Signal Type | [PWM] | | F2: Previous Values |
| | | Brightness Percent | [100%] | | F3: Optimized Default |
| | | PWM Clock | [200Hz] | | F4: Save & Exit |
| | | | | | ESC: Exit |

Panel Color Depth

Select the LFP Panel Color Depth: 18 Bit, 24 Bit.

LVDS Channel Type

Select LVDS Channel Type

Panel Type

Select LCD panel used by Internal Graphics Device by selecting the appropriate setup item: 800x600 LVDS ~ 1920x1080 LVDS.

LVDS Brightness Control

Enable or Disable LVDS Brightness

ISmart Controller

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|-------------------|------------------------------|---------|-----------|----------|-----------------------|
| ISmart Controller | | | | | |
| | Power-On after Power failure | | [Disable] | | → ← Select Screen |
| | Temperature Guardian | | [Disable] | | ↑ ↓ Select Item |
| | Schedule Slot 1 | | [None] | | Enter: Select |
| | Schedule Slot 2 | | [None] | | + - Change Field |
| | | | | | F1: General Help |
| | | | | | F2: Previous Values |
| | | | | | F3: Optimized Default |
| | | | | | F4: Save |
| | | | | | ESC: Exit |

Power-On after Power failure

Enable or Disable.

Temperature Guardian

Enable or Disable.

Schedule Slot 1 / 2

Setup the hour/minute for system power on.

AMT Configuration

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|------|----------|---------|------------------------------------|------------|-----------------------|
| | | | Intel AMT | [Enabled] | |
| | | | BIOS Hotkey Pressed | [Disabled] | |
| | | | MEBx Selection Screen | [Disabled] | |
| | | | Hide Un-Configure ME Confirmation | [Disabled] | |
| | | | Amt Wait Timer | 0 | → ← Select Screen |
| | | | ASF | [Enabled] | ↑ ↓ Select Item |
| | | | Activate Remote Assistance Process | [Disabled] | Enter: Select |
| | | | USB Configure | [Enabled] | + - Change Field |
| | | | PET Progress | [Enabled] | F1: General Help |
| | | | AMT CIRA Timeout | 0 | F2: Previous Values |
| | | | Watchdog | [Disabled] | F3: Optimized Default |
| | | | OS Timer | 0 | F4: Save |
| | | | BIOS Timer | 0 | ESC: Exit |

AMT Configuration

This configuration is supported only with IB915AF(with iAMT function).

Options are Enabled and Disabled.

Note: iAMT H/W is always enabled. This option just controls the BIOS extension execution. If enabled, this requires additional firmware in the SPI device.

Amt Wait Timer

Set timer to wait before sending ASF_GET_BOOT_OPTIONS.

Activate Remote Assistance Process

Trigger CIRA boot.

PET Progress

User can Enable/Disable PET Events progress to receive PET events or not.

Watchdog Timer

Enable/Disable Watchdog Timer.

Fintek Super IO Configuration

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|-------------------------------|----------|---------|------|---------------|-----------------------|
| Fintek Super IO Configuration | | | | | → ← Select Screen |
| Super IO Chip | | | | F81846 Serial | ↑ ↓ Select Item |
| ▶ Serial Port 1 Configuration | | | | | Enter: Select |
| ▶ Serial Port 2 Configuration | | | | | + - Change Field |
| ▶ Serial Port 3 Configuration | | | | | F1: General Help |
| ▶ Serial Port 4 Configuration | | | | | F2: Previous Values |
| | | | | | F3: Optimized Default |
| | | | | | F4: Save |
| | | | | | ESC: Exit |

Serial Port Configuration

Set parameters of serial ports. User can Enable/Disable the serial port and Select an optimal settings for the Super IO Device.

Hardware Monitor

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|------------------|-------------|---------|------------|----------|-----------------------|
| PC Health Status | | | | | → ← Select Screen |
| CPU | temperature | | :+46 C | | ↑ ↓ Select Item |
| System | temperature | | :+46 C | | Enter: Select |
| VCore | | | :+0.888 V | | + - Change Field |
| VBAT | | | :+3.248 C | | F1: General Help |
| CPU Shutdown | Temperature | | [Disabled] | | F2: Previous Values |
| | | | | | F3: Optimized Default |
| | | | | | F4: Save |
| | | | | | ESC: Exit |

CPU Shutdown Temperature

The default setting is Disabled.

Temperatures/Voltages

These fields are the parameters of the hardware monitoring function feature of the board. The values are read-only values as monitored by the system and show the PC health status.

[

CPU Configuration

This section shows the CPU configuration parameters.

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|--|----------|---------|------|----------|-------------|
| CPU Configuration | | | | | |
| Intel(R) CPU Core(TM)i3-6100U CPU @ 2.30GHz | | | | | |
| CPU Signature 406E3 | | | | | |
| Microcode Patch 33 | | | | | |
| Processor cores 2 | | | | | |
| Max CPU Speed 2200 MHz | | | | | |
| Min CPU Speed 500 MHz | | | | | |
| CPU Speed 3100 MHz | | | | | |
| Processor Cores 2 | | | | | |
| Hyper Threading Technology Supported | | | | | |
| Intel VT-x Technology Supported | | | | | |
| Intel SMX Technology Not Supported | | | | | |
| 64-bit Supported | | | | | |
| EIST Technology Supported | | | | | |
| CPU C3 State Supported | | | | | |
| CPU C6 State Supported | | | | | |
| CPU C7 State Supported | | | | | |
| | | | | | |
| Intel (R) SpeedStep(tm)- [Enabled] → ← Select Screen | | | | | |
| Turbo Mode [Enabled] ↑ ↓ Select Item | | | | | |
| Package power Limit MSR Lock [Disabled] Enter: Select | | | | | |
| 1-Core Ratio Limit Override 0 +- Change Field | | | | | |
| 2-Core Ratio Limit Override 0 F1: General Help | | | | | |
| Configurable TDP Boot Mode [Nominal] F2: Previous Values | | | | | |
| Configurable TDP Lock [Disabled] F3: Optimized Default | | | | | |
| CTDP BIOS control [Disabled] F4: Save | | | | | |
| PRMRR Size [AUTO] ESC: Exit | | | | | |

Intel (R) SpeedStep(tm)

Allows more than two frequency ranges to be supported.

Turbo Mode

Enable or Disable Turbo Mode.

Package power Limit MSR Lock

Enable/disable locking of Package Power Limit settings. When enabled, PACKAGE_POWER_LIMIT MSR will be locked and a rest will be required to unlock the register.

Configurable TDP Boot Mode

Configurable TDP Boot Mode as Nominal/Up/Down/Deactivate TDP selection. Deactivate option will set MSR to Nominal and MMIO to Zero.

Configurable TDP Lock

Configurable TDP Lock sets the Lock bits on

TURBO_ACTIVATION_RATIO and CONFIG_TDP_CONTROL.

Note: When CTD Lock is enabled Custom ConfigTDP Count will be forced to 1 and Custom ConfigTDP Boot Index will be forced to 0.

CTDP BIOS control

Enables CTD control via runtime ACPI BIOS methods.

This "BIOS only" feature does not require EC or driver support.

SATA Configuration

SATA Devices Configuration.

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|------|-------------------------------------|---------|------------|----------|-----------------------|
| | SATA Controller(s) | | [Enabled] | | |
| | SATA Mode Selection | | [AHCI] | | |
| ▶ | Software Feature Mask Configuration | | | | |
| | Aggressive LPM Support | | [Enabled] | | |
| | Serial ATA Port 0 | | [Empty] | | |
| | Software Preserve | | [Unknown] | | |
| | Port 0 | | [Enabled] | | |
| | Hot Plug | | [Disabled] | | |
| | Serial ATA Port1 | | [Empty] | | |
| | Software Preserve | | [Unknown] | | |
| | Port 1 | | [Enabled] | | |
| | Hot Plug | | [Disabled] | | |
| | Serial ATA Port2 | | [Empty] | | |
| | Software Preserve | | [Unknown] | | |
| | Port 2 | | [Enabled] | | |
| | Hot Plug | | [Disabled] | | |
| | Serial ATA Port3 | | [Empty] | | |
| | Software Preserve | | [Unknown] | | |
| | Port 3 | | [Enabled] | | |
| | Hot Plug | | [Disabled] | | |
| | | | | | → ← Select Screen |
| | | | | | ↑ ↓ Select Item |
| | | | | | Enter: Select |
| | | | | | + - Change Field |
| | | | | | F1: General Help |
| | | | | | F2: Previous Values |
| | | | | | F3: Optimized Default |
| | | | | | F4: Save |
| | | | | | ESC: Exit |

SATA Controller(s)

Enable / Disable Serial ATA Controller.

SATA Mode Selection

- (1) AHCI Mode.
- (2) RAID Mode.

Software Feature Mask Configuration

RAID OROM/RST driver will refer to the SWFM configuration to enable or disable the storage features.

Aggressive LPM Support

Enable PCH to aggressively enter link power state.

Acoustic Management Configuration

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|--|----------|---------|------|---|-------------|
| Acoustic Management Configuration HDD not found | | | | → ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit | |

Acoustic Management Configuration

Option to Enable or Disable Automatic Acoustic Management

Network Stack Configuration

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|---------------|----------|------------|------|---|-------------|
| Network Stack | | [Disabled] | | → ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit | |

Network Stack Configuration

Network Stack Settings.

CSM Configuration

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|--|----------|---------|-------------------|----------|-----------------------|
| Compatibility Support Module Configuration | | | | | |
| CSM Support | | | Enabled | | |
| CSM16 Module Version | | | 07.78 | | |
| GateA20 Active | | | [Upon Request] | | |
| Option ROM Messages | | | [Force BIOS] | | |
| INT19 Trap Response | | | [Immediate] | | |
| Boot option filter | | | [UEFI and Legacy] | | → ← Select Screen |
| Option ROM execution | | | | | ↑ ↓ Select Item |
| Network | | | [Do not launch] | | Enter: Select |
| Storage | | | [Legacy] | | + - Change Field |
| Video | | | [Legacy] | | F1: General Help |
| Other PCI device | | | [Legacy] | | F2: Previous Values |
| | | | | | F3: Optimized Default |
| | | | | | F4: Save |
| | | | | | ESC: Exit |

CSM Support

Enable/Disable CSM Support.

Boot option filter

This option controls what devices system can boot to.

Network

Controls the execution of UEFI and Legacy PXE OpROM.

Storage

Controls the execution of UEFI and Legacy Storage OpROM.

Video

Controls the execution of UEFI and Legacy Video OpROM.

Other PCI device

Determines OpROM execution policy for devices other than Network, Storage, or Video.

USB Configuration

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|------------------------------------|----------|---------|------------|----------|-----------------------|
| USB Configuration | | | | | |
| USB Module Version | | | 12 | | |
| USB Controllers: | | | | | |
| 1 XHCI | | | | | |
| USB Devices: | | | | | |
| 1 Keyboard, 1 Mouse | | | | | |
| Legacy USB Support | | | [Enabled] | | → ← Select Screen |
| XHCI Hand-off | | | [Disabled] | | ↑ ↓ Select Item |
| USB MASS Storage Driver Support | | | [Enabled] | | Enter: Select |
| Port 60/64 Emulation | | | [Enabled] | | + - Change Field |
| USB hardware delays and time-outs: | | | | | F1: General Help |
| USB Transfer time-out | | | [20 sec] | | F2: Previous Values |
| Device reset time-out | | | [20 sec] | | F3: Optimized Default |
| Device power-up delay | | | [Auto] | | F4: Save |
| | | | | | ESC: Exit |

Legacy USB Support

Enables Legacy USB support.

AUTO option disables legacy support if no USB devices are connected.

DISABLE option keeps USB devices available only for EFI applications.

XHCI Hand-off

This is a workaround for OSes without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.

USB Mass Storage Driver Support

Enable/Disable USB Mass Storage Driver Support.

Port 60/64 Emulation

Enables I/O port 60h/64h emulation support. This should be enabled for the complete USB keyboard legacy support for non-USB aware OSes.

USB Transfer time-out

The time-out value for Control, Bulk, and Interrupt transfers.

Device reset time-out

USB mass Storage device start Unit command time-out.

Device power-up delay

Maximum time the device will take before it properly reports itself to the Host Controller. 'Auto' uses default value: for a Root port it is 100ms, for a Hub port the delay is taken from Hub descriptor.

Chipset Settings

This section allows you to configure and improve your system and allows you to set up some system features according to your preference.

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|---|----------|---------|------|----------|-------------|
| <ul style="list-style-type: none"> ▶ System Agent (SA) Configuration ▶ PCH-IO Configuration | | | | | |

System Agent (SA) Configuration

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|--------------------------|----------|---------|-----------------|----------|--|
| System Agent Bridge Name | | | Skylake | | → ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit |
| System Agent RC Version | | | 1.6.0.0 | | |
| VT-d Capability | | | Supported | | |
| VT-d | | | [Enabled] | | |
| eDRAM Mode | | | [eDRam HW Mode] | | |
| ▶ Graphics Configuration | | | | | |

VT-d

VT-d capability.

eDRAM Mode

SW Mode eDRAM on or eDRAM off.

PCH-IO Configuration

This section allows you to configure the North Bridge Chipset.

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|------|----------|--------------------------|--------------------------|----------|-----------------------|
| | | Intel PCH RC Version | 1.6.0.0 | | |
| | | Intel PCH SKU Name | PCH-LP Mobile (U) Pre... | | |
| | | Intel PCH Rev ID | 21/C1 | | |
| | | PCH LAN Controller | [Enabled] | | → ← Select Screen |
| | | LAN PHY Drives LAN_WAKE# | [Disabled] | | ↑ ↓ Select Item |
| | | Sensor Hub Type | [None] | | Enter: Select |
| | | LAN Wake From DeepSx | [Enabled] | | + - Change Field |
| | | Wake on LAN | [Enabled] | | F1: General Help |
| | | SLP_LAN# Low on DC Power | [Enabled] | | F2: Previous Values |
| | | | | | F3: Optimized Default |
| | | | | | F4: Save |
| | | | | | ESC: Exit |

PCH LAN Controller

Enable or disable onboard NIC.

LAN PHY Drives LAN_WAKE#

Enables/Disables LAN Phy driving LAN_WAKE# else platform drives LAN_WAKE#.

Sensor Hub Type

Choose the sensor Hub Type, 'None' will Suppress 'I2C Sensor Hub' Setup option, 'I2C' Will Suppress 'ALS' Setup option and 'USB' will Suppress Both I2C and ALS.

LAN Wake From DeepSx

Wake from DeepSx by the assertion of LAN_WAKE# pin.

Wake on LAN

Enable or disable integrated LAN to wake the system. (The Wake On LAN cannot be disabled if ME is on at Sx state.)

SLP_LAN# Low on DC Power

Enable/Disable SLP_LAN# Low on DC Power

Security Settings

This section allows you to configure and improve your system and allows you to set up some system features according to your preference.

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|---|----------|---------|------|---|-------------|
| Password Description | | | | | |
| If ONLY the Administrator's password is set, then this only limit access to Setup and is only asked for when entering Setup. | | | | | |
| If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights | | | | | |
| The password length must be in the following range: | | | | | |
| Minimum length | | | 3 | | |
| Maximum length | | | 20 | | |
| Administrator Password | | | | | |
| User Password | | | | | |
| | | | | → ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit | |

Administrator Password

Set Setup Administrator Password.

User Password

Set User Password.

Boot Settings

This section allows you to configure the boot settings.

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|-----------------------------|----------|-----------------|------|----------|-----------------------|
| Boot Configuration | | | | | |
| Setup Prompt Timeout | | 1 | | | |
| Bootup NumLock State | | [On] | | | |
| Quiet Boot | | [Disabled] | | | |
| Fast Boot | | [Disabled] | | | |
| Boot mode select | | [LEGACY] | | | |
| FIXED BOOT ORDER Priorities | | | | | |
| Boot Option #1 | | [Hard Disk] | | | → ← Select Screen |
| Boot Option #2 | | [CD / DVD] | | | ↑ ↓ Select Item |
| Boot Option #3 | | [USB Hard Disk] | | | Enter: Select |
| Boot Option #4 | | [USB CD / DVD] | | | + - Change Field |
| Boot Option #5 | | [USB Key] | | | F1: General Help |
| Boot Option #6 | | [USB Floppy] | | | F2: Previous Values |
| Boot Option #7 | | [USB LAN] | | | F3: Optimized Default |
| Boot Option #8 | | [Network] | | | F4: Save |
| | | | | | ESC: Exit |

Setup Prompt Timeout

Number of seconds to wait for setup activation key.
65535(0xFFFF) means indefinite waiting.

Bootup NumLock State

Select the keyboard NumLock state.

Quiet Boot

Enables/Disables Quiet Boot option.

Fast Boot

Enables/Disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.

Boot mode select

Select boot mode LEGACY/UEFI

FIXED BOOT ORDER Priorities

Sets the system boot order.

Save & Exit Settings

Aptio Setup Utility – Copyright © 2016 American Megatrends, Inc.

| Main | Advanced | Chipset | Boot | Security | Save & Exit |
|---|----------|---------|------|----------|---|
| Save Changes and Exit Discard Changes and Exit Save Changes and Reset Discard Changes and Reset Save Options Save Changes Discard Changes Restore Defaults Save as User Defaults Restore User Defaults | | | | | → ← Select Screen ↑ ↓ Select Item Enter: Select +- Change Field F1: General Help F2: Previous Values F3: Optimized Default F4: Save ESC: Exit |

Save Changes and Exit

Exit system setup after saving the changes.

Discard Changes and Exit

Exit system setup without saving any changes.

Save Changes and Reset

Reset the system after saving the changes.

Discard Changes and Reset

Reset system setup without saving any changes.

Save Changes

Save Changes done so far to any of the setup options.

Discard Changes

Discard Changes done so far to any of the setup options.

Restore Defaults

Restore/Load Defaults values for all the setup options.

Save as User Defaults

Save the changes done so far as User Defaults.

Restore User Defaults

Restore the User Defaults to all the setup options.

Drivers Installation

This section describes the installation procedures for software and drivers. The software and drivers are included with the motherboard. If you find the items missing, please contact the vendor where you made the purchase. The contents of this section include the following:

| | |
|---|----|
| Intel Chipset Software Installation Utility | 45 |
| VGA Drivers Installation..... | 47 |
| Realtek HD Audio Driver Installation | 50 |
| LAN Drivers Installation | 52 |
| Intel® Management Engine Interface..... | 55 |
| Intel® USB 3.0 Drivers | 57 |
| ASMedia USB 3.1 Drivers..... | 60 |

IMPORTANT NOTE:

After installing your Windows operating system, you must install first the Intel Chipset Software Installation Utility before proceeding with the drivers installation.

Intel Chipset Software Installation Utility

The Intel Chipset Drivers should be installed first before the software drivers to enable Plug & Play INF support for Intel chipset components. Follow the instructions below to complete the installation.


1. Insert the DVD that comes with the board. Click **Intel** and then **Intel(R) Skylake-U Chipset Drivers**.



2. Click **Intel(R) Chipset Software Installation Utility**.



3. When the Welcome screen to the Intel® Chipset Device Software appears, click *Next* to continue.
4. Click *Yes* to accept the software license agreement and proceed with the installation process.
5. On the Readme File Information screen, click *Install* to continue the installation.



6. The Setup process is now complete. Click *Finish* to restart the computer and for changes to take effect.

VGA Drivers Installation


1. Insert the DVD that comes with the board. Click **Intel** and then **Intel(R) Skylake-U Chipset Drivers**.




2. Click **Intel(R) HD Graphics Driver**.



3. When the Welcome screen appears, click *Next* to continue.




4. Click *Yes* to agree with the license agreement and continue the installation.



5. On the screen shown below, click **Install** to continue.



6. Setup complete. Click **Finish** to restart the computer and for changes to take effect.




Realtek HD Audio Driver Installation


1. Insert the DVD that comes with the board. Click *Intel* and then *Intel(R) Skylake-U Chipset Drivers*.




2. Click *Realtek High Definition Audio Driver*.



3. On the Welcome to the InstallShield Wizard screen, click **Next** to proceed with and complete the installation process.



4. The InstallShield Wizard Complete. Click **Finish** to restart the computer and for changes to take effect.



LAN Drivers Installation


1. Insert the DVD that comes with the board. Click **Intel** and then **Intel(R) Skylake-U Chipset Drivers**.




2. Click **Intel(R) PRO LAN Network Driver**.




3. Click **Install Drivers and Software**.




4. When the Welcome screen appears, click **Next**.



5. Click **Next** to agree with the license agreement.
6. Click the checkbox for **Drivers** in the Setup Options screen to select it and click **Next** to continue.



7. The wizard is ready to begin installation. Click **Install** to begin the installation.



8. When InstallShield Wizard is complete, click **Finish**.

Intel® Management Engine Interface

1. Insert the DVD that comes with the board. Click **Intel** and then **Intel(R) Skylake-U Chipset Drivers**.




2. Click **Intel (R) ME 11.x Drivers**.



3. When the Welcome screen to the InstallShield Wizard for Intel® Management Engine Components, click the checkbox for **Install Intel® Control Center** & click **Next**.



4. Click **Next** to agree with the license agreement.



5. When the Setup Progress screen appears, click **Next**. Then, click **Finish** when the setup progress has been successfully installed.

Intel® USB 3.0 Drivers


1. Insert the DVD that comes with the board. Click **Intel** and then **Intel(R) Skylake-U Chipset Drivers**.




2. Click **Intel(R) USB 3.0 Drivers**.



3. When the Welcome screen to the InstallShield Wizard for Intel® USB 3.0 eXtensible Host Controller Driver, click *Next*.



4. Click *Next* to agree with the license agreement and continue the installation.



5. On the Readme File Information screen, click **Next** to continue the installation of the Intel® USB 3.0 eXtensible Host Controller Driver.
6. Setup complete. Click **Finish** to restart the computer and for changes to take effect.



ASMedia USB 3.1 Drivers

1. Insert the DVD that comes with the board. Click **Intel** and then **Intel(R) Skylake-U Chipset Drivers**.




2. Click **ASMedia USB 3.1 Drivers**.



3. When the Welcome screen to the InstallShield Wizard for Asmedia USB Host Controller Driver, click **Next**.



4. Setup complete. Click **Finish**



Appendix

A. I/O Port Address Map

Each peripheral device in the system is assigned a set of I/O port addresses which also becomes the identity of the device. The following table lists the I/O port addresses used.

| Address | Device Description |
|-------------|-----------------------------------|
| 0000h-0CF7h | PCI Express Root Complex |
| 0040h-0043h | System timer |
| 0070h-0070h | System CMOS/real time clock |
| 02E8h-02EFh | Fintek Communications Port (COM4) |
| 02F8h-02FFh | Fintek Communications Port (COM2) |
| 03E8h-03EFh | Fintek Communications Port (COM3) |
| 03F8h-03FFh | Fintek Communications Port (COM1) |
| 03B0h-03BBh | Intel(R) HD Graphics 520 |
| 03C0h-03DFh | Intel(R) HD Graphics 520 |
| 0D00h-FFFFh | PCI Express Root Complex |

B. Interrupt Request Lines (IRQ)

Peripheral devices use interrupt request lines to notify CPU for the service required. The following table shows the IRQ used by the devices on board.

| Level | Function |
|--------------|-----------------------------------|
| IRQ0 | System Timer |
| IRQ1 | Keyboard |
| IRQ3 | Fintek Communications Port(COM2) |
| IRQ4 | Fintek Communications Port(COM1) |
| IRQ7 | Fintek Communications Port(COM3) |
| IRQ7 | Fintek Communications Port(COM4) |
| IRQ11 | Intel® Ethernet Connection I219-V |
| IRQ14 | MotherBoard resources |

C. Watchdog Timer Configuration

The WDT is used to generate a variety of output signals after a user programmable count. The WDT is suitable for use in the prevention of system lock-up, such as when software becomes trapped in a deadlock. Under these sorts of circumstances, the timer will count to zero and the selected outputs will be driven. Under normal circumstance, the user will restart the WDT at regular intervals before the timer counts to zero.

SAMPLE CODE:

```
//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#include <dos.h>
#include <conio.h>
#include <stdio.h>
#include <stdlib.h>
#include "F81866.H"
//-----
int main (int argc, char *argv[]);
void EnableWDT(int);
void DisableWDT(void);
//-----
int main (int argc, char *argv[])
{
    unsigned char bBuf;
    unsigned char bTime;
    char **endptr;

    char SIO;

    printf("Fintek 81866 watch dog program\n");

    SIO = Init_F81866();
    if (SIO == 0)
    {
        printf("Can not detect Fintek 81866, program abort.\n");
        return(1);
    }/if (SIO == 0)

    if (argc != 2)
    {
        printf(" Parameter incorrect!!\n");
        return (1);
    }

    bTime = strtol (argv[1], endptr, 10);
    printf("System will reset after %d seconds\n", bTime);

    if (bTime)
    {
        EnableWDT(bTime); }
    else
    {
        DisableWDT();    }

    return 0;
}
```

```

}
//-----
void EnableWDT(int interval)
{
    unsigned char bBuf;

    bBuf = Get_F81866_Reg(0x2B);
    bBuf &= (~0x20);
    Set_F81866_Reg(0x2B, bBuf); //Enable WDTO

    Set_F81866_LD(0x07); //switch to logic device 7
    Set_F81866_Reg(0x30, 0x01); //enable timer

    bBuf = Get_F81866_Reg(0xF5);
    bBuf &= (~0x0F);
    bBuf |= 0x52;
    Set_F81866_Reg(0xF5, bBuf); //count mode is second

    Set_F81866_Reg(0xF6, interval); //set timer

    bBuf = Get_F81866_Reg(0xFA);
    bBuf |= 0x01;
    Set_F81866_Reg(0xFA, bBuf); //enable WDTO output

    bBuf = Get_F81866_Reg(0xF5);
    bBuf |= 0x20;
    Set_F81866_Reg(0xF5, bBuf); //start counting
}
//-----
void DisableWDT(void)
{
    unsigned char bBuf;

    Set_F81866_LD(0x07); //switch to logic device 7

    bBuf = Get_F81866_Reg(0xFA);
    bBuf &= ~0x01;
    Set_F81866_Reg(0xFA, bBuf); //disable WDTO output

    bBuf = Get_F81866_Reg(0xF5);
    bBuf &= ~0x20;
    bBuf |= 0x40;
    Set_F81866_Reg(0xF5, bBuf); //disable WDT
}
//-----

```

```

//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//-----
#include "F81866.H"
#include <dos.h>
//-----
unsigned int F81866_BASE;
void Unlock_F81866 (void);
void Lock_F81866 (void);
//-----
unsigned int Init_F81866(void)
{
    unsigned int result;
    unsigned char ucDid;

    F81866_BASE = 0x4E;
    result = F81866_BASE;

    ucDid = Get_F81866_Reg(0x20);
    if (ucDid == 0x07) //Fintek 81866
    {
        goto Init_Finish;
    }

    F81866_BASE = 0x2E;
    result = F81866_BASE;

    ucDid = Get_F81866_Reg(0x20);
    if (ucDid == 0x07) //Fintek 81866
    {
        goto Init_Finish;
    }

    F81866_BASE = 0x00;
    result = F81866_BASE;

Init_Finish:
    return (result);
}
//-----
void Unlock_F81866 (void)
{
    outportb(F81866_INDEX_PORT, F81866_UNLOCK);
    outportb(F81866_INDEX_PORT, F81866_UNLOCK);
}
//-----
void Lock_F81866 (void)
{
    outportb(F81866_INDEX_PORT, F81866_LOCK);
}
//-----
void Set_F81866_LD( unsigned char LD)
{
    Unlock_F81866();
    outportb(F81866_INDEX_PORT, F81866_REG_LD);
    outportb(F81866_DATA_PORT, LD);
    Lock_F81866();
}
//-----
void Set_F81866_Reg( unsigned char REG, unsigned char DATA)
{
    Unlock_F81866();
    outportb(F81866_INDEX_PORT, REG);
    outportb(F81866_DATA_PORT, DATA);
    Lock_F81866();
}
//-----

```

```

unsigned char Get_F81866_Reg(unsigned char REG)
{
    unsigned char Result;
    Unlock_F81866();
    outportb(F81866_INDEX_PORT, REG);
    Result = inportb(F81866_DATA_PORT);
    Lock_F81866();
    return Result;
}
//-----

//-----
//
// THIS CODE AND INFORMATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY
// KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE
// IMPLIED WARRANTIES OF MERCHANTABILITY AND/OR FITNESS FOR A PARTICULAR
// PURPOSE.
//
//-----
#ifndef __F81866_H
#define __F81866_H                1
//-----
#define F81866_INDEX_PORT        (F81866_BASE)
#define F81866_DATA_PORT        (F81866_BASE+1)
//-----
#define F81866_REG_LD            0x07
//-----
#define F81866_UNLOCK            0x87
#define F81866_LOCK              0xAA
//-----
unsigned int Init_F81866(void);
void Set_F81866_LD(unsigned char);
void Set_F81866_Reg(unsigned char, unsigned char);
unsigned char Get_F81866_Reg(unsigned char);
//-----
#endif __F81866_H

```