

# HR908-B

## COM Express Compact Module User's Manual

## Copyright

This publication contains information that is protected by copyright. No part of it may be reproduced in any form or by any means or used to make any transformation/adaptation without the prior written permission from the copyright holders.

This publication is provided for informational purposes only. The manufacturer makes no representations or warranties with respect to the contents or use of this manual and specifically disclaims any express or implied warranties of merchantability or fitness for any particular purpose. The user will assume the entire risk of the use or the results of the use of this document. Further, the manufacturer reserves the right to revise this publication and make changes to its contents at any time, without obligation to notify any person or entity of such revisions or changes.

Changes after the publication's first release will be based on the product's revision. The website will always provide the most updated information.

© 2015. All Rights Reserved.

## Trademarks

Product names or trademarks appearing in this manual are for identification purpose only and are the properties of the respective owners.

## COM Express Specification Reference

PICMG® COM Express Module™ Base Specification.

<http://www.picmg.org/>

## FCC and DOC Statement on Class B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

### Notice:

1. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Shielded interface cables must be used in order to comply with the emission limits.

## Table of Contents

Copyright.....	2
Trademarks .....	2
FCC and DOC Statement on Class B.....	2
About this Manual .....	4
Warranty .....	4
Static Electricity Precautions.....	4
Safety Measures .....	4
About the Package .....	5
Chapter 1 - Introduction .....	6
Specifications .....	6
Features .....	7
Chapter 2 - Concept.....	8
COM Express Module Standards.....	8
Specification Comparison Table .....	9
Chapter 3 - Hardware Installation.....	10
Board Layout.....	10
Block Diagram.....	10
Mechanical Diagram.....	11
System Memory.....	12
Installing the DIMM Module .....	13
Connectors.....	14
CPU Fan Connector.....	14
COM Express Connectors .....	15
COM Express connector Signal Discription.....	16
Standby Power LED.....	25
Cooling Option.....	25
Installing HR908-B onto a Carrier Board.....	26

Chapter 4 - BIOS Setup.....	28
Overview .....	28
AMI BIOS Setup Utility.....	29
Main .....	29
Advanced .....	29
Chipset .....	34
Boot.....	40
Security.....	41
Save & Exit .....	41
Updating the BIOS .....	42
Notice: BIOS SPI ROM .....	43
Chapter 5 - Supported Software .....	44
Appendix A - nLite and AHCI Installation Guide.....	57
nLite.....	57
AHCI .....	61
Appendix B - Watchdog Sample Code.....	63
Appendix C - System Error Message.....	64
Appendix D - Troubleshooting.....	65

## About this Manual

An electronic file of this manual is included in the CD. To view the user's manual in the CD, insert the CD into a CD-ROM drive. The autorun screen (Main Board Utility CD) will appear. Click "User's Manual" on the main menu.

## Warranty

1. Warranty does not cover damages or failures that arised from misuse of the product, inability to use the product, unauthorized replacement or alteration of components and product specifications.
2. The warranty is void if the product has been subjected to physical abuse, improper installation, modification, accidents or unauthorized repair of the product.
3. Unless otherwise instructed in this user's manual, the user may not, under any circumstances, attempt to perform service, adjustments or repairs on the product, whether in or out of warranty. It must be returned to the purchase point, factory or authorized service agency for all such work.
4. We will not be liable for any indirect, special, incidental or consequential damages to the product that has been modified or altered.

## Static Electricity Precautions

It is quite easy to inadvertently damage your PC, system board, components or devices even before installing them in your system unit. Static electrical discharge can damage computer components without causing any signs of physical damage. You must take extra care in handling them to ensure against electrostatic build-up.

1. To prevent electrostatic build-up, leave the system board in its anti-static bag until you are ready to install it.
2. Wear an antistatic wrist strap.
3. Do all preparation work on a static-free surface.
4. Hold the device only by its edges. Be careful not to touch any of the components, contacts or connections.
5. Avoid touching the pins or contacts on all modules and connectors. Hold modules or connectors by their ends.



### Important:

Electrostatic discharge (ESD) can damage your processor, disk drive and other components. Perform the upgrade instruction procedures described at an ESD workstation only. If such a station is not available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the system chassis. If a wrist strap is unavailable, establish and maintain contact with the system chassis throughout any procedures requiring ESD protection.

## Safety Measures

To avoid damage to the system:

- Use the correct AC input voltage range.

To reduce the risk of electric shock:

- Unplug the power cord before removing the system chassis cover for installation or servicing. After installation or servicing, cover the system chassis before plugging the power cord.

## About the Package

The package contains the following items. If any of these items are missing or damaged, please contact your dealer or sales representative for assistance.

- One HR908 board
- One QR (Quick Reference)
- One DVD

## Optional Items

- COM331-B carrier board kit
- COM101-BAT carrier board kit
- Heat spreader: TBD
- Heat spreader with heat sink and fan: TBD
- Heat sink with fan

The board and accessories in the package may not come similar to the information listed above. This may differ in accordance with the sales region or models in which it was sold. For more information about the standard package in your region, please contact your dealer or sales representative.

## Chapter 1 - Introduction

### Specifications

<b>Processor</b>	<ul style="list-style-type: none"> <li>3<sup>rd</sup> generation Intel® Core™ processors (22nm process technology)               <ul style="list-style-type: none"> <li>Intel® Core™ i7-3615QE (6M Cache, up to 3.3GHz); 45W</li> <li>Intel® Core™ i7-3612QE (6M Cache, up to 3.1GHz); 35W</li> <li>Intel® Core™ i7-3555LE (4M Cache, up to 3.2GHz); 25W</li> <li>Intel® Core™ i7-3517UE (4M Cache, up to 2.8GHz); 17W</li> <li>Intel® Core™ i5-3610ME (3M Cache, up to 3.3GHz); 35W</li> <li>Intel® Core™ i3-3120ME (3M Cache, 2.4GHz); 35W</li> <li>Intel® Core™ i3-3217UE (3M Cache, 1.6GHz); 17W</li> <li>Intel® Celeron™ 1020E (2M Cache, 2.2GHz); 35W</li> <li>Intel® Celeron™ 1047UE (2M Cache, 1.4GHz); 17W</li> <li>Intel® Celeron™ 927UE (1M Cache, 1.5GHz); 17W</li> </ul> </li> <li>2<sup>nd</sup> generation Intel® Core™ processors (32nm process technology)               <ul style="list-style-type: none"> <li>Intel® Core™ i7-2715QE (6M Cache, up to 3.0GHz); 45W</li> <li>Intel® Core™ i7-2655LE (4M Cache, up to 2.9GHz); 25W</li> <li>Intel® Core™ i7-2610UE (4M Cache, up to 2.4GHz); 17W</li> <li>Intel® Core™ i5-2515E (3M Cache, up to 3.2GHz); 35W</li> <li>Intel® Core™ i3-2310E (3M Cache, 2.1GHz); 35W</li> <li>Intel® Core™ i3-2340UE (3M Cache, 1.3GHz); 17W</li> <li>Intel® Celeron™ B810E (2M Cache, 1.6GHz); 35W</li> <li>Intel® Celeron™ 847E (2M Cache, 1.1GHz); 17W</li> <li>Intel® Celeron™ 827E (1.5M Cache, 1.4GHz); 17W</li> <li>Intel® Celeron™ 807UE (1M Cache, 1.0GHz); 10W</li> </ul> </li> <li>BGA 1023 packaging technology</li> </ul>						
<b>Chipset</b>	<ul style="list-style-type: none"> <li>Intel® QM67 Express chipset</li> </ul>						
<b>System Memory</b>	<ul style="list-style-type: none"> <li>One 204-pin SODIMM socket</li> <li>Supports DDR3 SODIMM</li> </ul> <table border="1"> <thead> <tr> <th>3<sup>rd</sup> Generation Processors</th><th>2<sup>nd</sup> Generation Processors</th></tr> </thead> <tbody> <tr> <td>DDR3 1066/1333/1600MHz</td><td>DDR3 1066/1333MHz (i5/i3/Celeron)</td></tr> <tr> <td></td><td>DDR3 1600MHz (i7)</td></tr> </tbody> </table> <ul style="list-style-type: none"> <li>Supports DDR3L SODIMM               <ul style="list-style-type: none"> <li>1066/1333MHz when operating at 1.35V</li> <li>1066/1333/1600MHz when operating at 1.5V</li> </ul> </li> <li>Supports up to 8GB system memory</li> <li>DRAM device technologies: 1Gb, 2Gb and 4Gb DDR3 DRAM technologies are supported for x8 and x16 devices, unbuffered, non-ECC</li> </ul>	3 <sup>rd</sup> Generation Processors	2 <sup>nd</sup> Generation Processors	DDR3 1066/1333/1600MHz	DDR3 1066/1333MHz (i5/i3/Celeron)		DDR3 1600MHz (i7)
3 <sup>rd</sup> Generation Processors	2 <sup>nd</sup> Generation Processors						
DDR3 1066/1333/1600MHz	DDR3 1066/1333MHz (i5/i3/Celeron)						
	DDR3 1600MHz (i7)						
<b>Graphics</b>	<ul style="list-style-type: none"> <li>Intel® HD Graphics 4000 (3<sup>rd</sup> generation processors)</li> <li>Intel® HD Graphics 3000 (2<sup>nd</sup> generation processors)</li> <li>Intel® HD Graphics (Intel® Celeron™ processors)</li> <li>Supports LVDS, VGA, and DDI interfaces</li> <li>VGA: resolution up to 1920x1200 @ 60Hz</li> <li>LVDS: Single Channel - 18/24-bit; Dual Channel - 36/48-bit, resolution up to 1920x1200 @ 60Hz</li> <li>Digital Display Interfaces: HDMI, DVI, DP and SDVO</li> <li>HDMI, DVI, DP: resolution up to 1920x1200 @ 60Hz</li> <li>Intel® Clear Video Technology</li> <li>DirectX Video Acceleration (DXVA) for accelerating video processing               <ul style="list-style-type: none"> <li>Full AVC/VC1/MPEG2 HW Decode</li> </ul> </li> <li>Supports DirectX 11/10.1/10/9 and OpenGL 3.0 (3<sup>rd</sup> generation processors)</li> <li>Supports DirectX 10.1/10/9 and OpenGL 3.0 (2<sup>nd</sup> generation processors)</li> </ul>						

<b>Audio</b>	<ul style="list-style-type: none"> <li>Supports High Definition Audio interface</li> </ul>
<b>LAN</b>	<ul style="list-style-type: none"> <li>Intel® 82579LM Gigabit Ethernet PHY</li> <li>Integrated 10/100/1000 transceiver</li> <li>Fully compliant with IEEE 802.3, IEEE 802.3u, IEEE 802.3ab</li> </ul>
<b>Serial ATA</b>	<ul style="list-style-type: none"> <li>Supports 4 Serial ATA interfaces</li> <li>2 SATA 3.0 with data transfer rate up to 6Gb/s</li> <li>2 SATA 2.0 with data transfer rate up to 3Gb/s</li> <li>Integrated Advanced Host Controller Interface (AHCI) controller</li> <li>Supports RAID 0/1/5/10</li> </ul>
<b>Watchdog Timer</b>	<ul style="list-style-type: none"> <li>Watchdog timeout programmable via software from 1 to 255 seconds</li> </ul>
<b>Expansion Interfaces</b>	<ul style="list-style-type: none"> <li>Supports 8 USB 2.0 interfaces</li> <li>Supports 1 PCIe x16 interface               <ul style="list-style-type: none"> <li>Supports Gen 3.0 (3<sup>rd</sup> generation processors)</li> <li>Configurations (supported only via a riser card):                   <ul style="list-style-type: none"> <li>One x8 (GFX) and two x4 (I/O)</li> <li>Two x8 (GFX, I/O)</li> <li>One x16 (GFX, I/O)</li> </ul> </li> </ul> </li> <li>Supports 1 PCIe x4 and 3 PCIe x1 (default); or 7 PCIe x1 interfaces</li> <li>Supports LPC interface</li> <li>Supports SMBus interface</li> <li>Supports I<sup>2</sup>C interface</li> <li>Supports 2 serial interfaces (TX/RX)</li> <li>Supports 4-bit input and 4-bit output GPIO</li> </ul>
<b>Damage Free Intelligence</b>	<ul style="list-style-type: none"> <li>Monitors CPU temperature</li> <li>Monitors CPU fan speed</li> <li>Monitors Vcore/VGFX/DDR voltages</li> <li>Watchdog timer function</li> </ul>
<b>OS Support</b>	<ul style="list-style-type: none"> <li>Windows XP Professional x86 &amp; SP3 (32-bit)</li> <li>Windows XP Professional x64 &amp; SP2 (64-bit)</li> <li>Windows 7 Ultimate x86 &amp; SP1 (32-bit)</li> <li>Windows 7 Ultimate x64 &amp; SP1 (64-bit)</li> <li>Windows 8 Enterprise x86 (32-bit)</li> <li>Windows 8 Enterprise x64 (64-bit)</li> </ul>
<b>BIOS</b>	<ul style="list-style-type: none"> <li>64Mbit UEFI SPI BIOS</li> </ul>
<b>Temperature</b>	<ul style="list-style-type: none"> <li>Operating: 0°C to 60°C</li> <li>Storage: -20°C to 85°C</li> </ul>
<b>Humidity</b>	<ul style="list-style-type: none"> <li>10% to 90%</li> </ul>
<b>Power</b>	<ul style="list-style-type: none"> <li>Input: 12V, 5VSB, VCC_RTC</li> </ul>
<b>PCB</b>	<ul style="list-style-type: none"> <li>Dimensions               <ul style="list-style-type: none"> <li>COM Express® Compact</li> <li>95mm (3.74") x 95mm (3.74")</li> </ul> </li> <li>Compliance               <ul style="list-style-type: none"> <li>PICMG COM Express® R2.1 Compact form factor, Type 6</li> </ul> </li> </ul>

## Features

### • Watchdog Timer

The Watchdog Timer function allows your application to regularly “clear” the system at the set time interval. If the system hangs or fails to function, it will reset at the set time interval so that your system will continue to operate.

### • DDR3

DDR3 delivers increased system bandwidth and improved performance. The advantages of DDR3 are its higher bandwidth and its increase in performance at a lower power than DDR2.

### • Graphics



**Note:**

Due to the limitation of chipset QM67, 3 display features will not be supported.

The integrated Intel® HD graphics engine delivers an excellent blend of graphics performance and features to meet business needs. It provides excellent video and 3D graphics with outstanding graphics responsiveness. These enhancements deliver the performance and compatibility needed for today's and tomorrow's business applications. It supports LVDS, VGA and DDI interfaces.

### • Serial ATA

Serial ATA is a storage interface that is compliant with SATA 1.0a specification. With speed of up to 3Gb/s (SATA 2.0) and 6Gb/s (SATA 3.0), it improves hard drive performance faster than the standard parallel ATA whose data transfer rate is 100MB/s. The bandwidth of the SATA 3.0 will be limited by carrier board design.

### • Gigabit LAN

The Intel 82579LM Gigabit LAN controller supports up to 1Gbps data transmission.

## Chapter 2 - Concept

### COM Express Module Standards

The figure below shows the dimensions of the different types of COM Express modules.

HR908-B is a COM Express Compact module. The dimension is 95mm x 95mm.

● Common for all Form Factors


○ Extended only

● Basic only

○ Compact only

○ Compact and Basic only

○ Mini only





## Specification Comparison Table

The table below shows the COM Express standard specifications and the corresponding specifications supported on the HR908-B module.

Connector	Feature	COM Express Module Base Specification Type 6 (No IDE or PCI, add DDI + USB3) Min / Max	DFI HR908-B Type 6
A-B	System I/O		
A-B	PCI Express Lanes 0 - 5	1 / 6	6
A-B	LVDS Channel A	0 / 1	1
A-B	LVDS Channel B	0 / 1	1
A-B	eDP on LVDS CH A pins	0 / 1	0
A-B	VGA Port	0 / 1	1
A-B	TV-Out	NA	NA
A-B	DDI 0	NA	NA
A-B <sup>5</sup>	Serial Ports 1 - 2	0 / 2	2
A-B	CAN interface on SER1	0 / 1	0
A-B	SATA / SAS Ports	1 / 4	4
A-B	AC'97 / HDA Digital Interface	0 / 1	1
A-B	USB 2.0 Ports	4 / 8	8
A-B	USB Client	0 / 1	0
A-B	USB 3.0 Ports	NA	NA
A-B	LAN Port 0	1 / 1	1
A-B	Express Card Support	1 / 2	2
A-B	LPC Bus	1 / 1	1
A-B	SPI	1 / 2	1
A-B	System Management		
A-B <sup>6</sup>	SDIO (muxed on GPIO)	0 / 1	0
A-B <sup>6</sup>	General Purpose I/O	8 / 8	8
A-B	SMBus	1 / 1	1
A-B	I2C	1 / 1	1
A-B	Watchdog Timer	0 / 1	1
A-B	Speaker Out	1 / 1	1
A-B	External BIOS ROM Support	0 / 2	0
A-B	Reset Functions	1 / 1	1

- 5 Indicates 12V-tolerant features on former VCC\_12V signals.
- 6 Cells in the connected columns spanning rows provide a rough approximation of features sharing connector pins.


Connector	Feature	COM Express Module Base Specification Type 6 (No IDE or PCI, add DDI + USB3) Min / Max	DFI HR908-B Type 6
A-B	Power Management		
A-B	Thermal Protection	0 / 1	1
A-B	Battery Low Alarm	0 / 1	1
A-B	Suspend/Wake Signals	0 / 3	2
A-B	Power Button Support	1 / 1	1
A-B	Power Good	1 / 1	1
A-B	VCC_5V_SBY Contacts	4 / 4	4
A-B <sup>5</sup>	Sleep Input	0 / 1	1
A-B <sup>5</sup>	Lid Input	0 / 1	1
A-B <sup>5</sup>	Fan Control Signals	0 / 2	2
A-B	Trusted Platform Modules	0 / 1	0
A-B	Power		
A-B	VCC_12V Contacts	12 / 12	12

Module Pin-out - Required and Optional Features C-D Connector. PICMG® COM.0Revision 2.1


Connector	Feature	COM Express Module Base Specification Type 6 (No IDE or PCI, add DDI + USB3) Min / Max	DFI HR908-B Type 6
C-D	System I/O		
C-D <sup>6</sup>	PCI Express Lanes 16 - 31	0 / 16	0
	PCI Express Graphics (PEG)	0 / 1	1
C-D <sup>6</sup>	Muxed SDVO Channels 1 - 2	NA	NA
	PCI Express Lanes 6 - 15	0 / 2	2
	PCI Bus - 32 Bit	NA	NA
	PATA Port	NA	NA
	LAN Ports 1 - 2	NA	NA
	DDIs 1 - 3	0 / 3	3
	USB 3.0 Ports	0 / 4	NA
C-D	Power		
C-D	VCC_12V Contacts	12 / 12	12

## Chapter 3 - Hardware Installation

### Board Layout




Top View




Bottom View

### Block Diagram




## Mechanical Diagram

HR908-B Module with Heat Sink



Side View of the Module with Heat Sink and Carrier Board

HR908-B Module



**Important:**


Electrostatic discharge (ESD) can damage your board, processor, disk drives, add-in boards, and other components. Perform installation procedures at an ESD workstation only. If such a station is not available, you can provide some ESD protection by wearing an antistatic wrist strap and attaching it to a metal part of the system chassis. If a wrist strap is unavailable, establish and maintain contact with the system chassis throughout any procedures requiring ESD protection.

## System Memory

The system board is equipped with one 204-pin SODIMM socket that support DDR3 memory modules.

**Important:**

When the Standby Power LED lit red, it indicates that there is power on the board. Power-off the PC then unplug the power cord prior to installing any devices. Failure to do so will cause severe damage to the board and components.




## Installing the DIMM Module



**Note:**

The system board used in the following illustrations may not resemble the actual one. These illustrations are for reference only.


1. Make sure the PC and all other peripheral devices connected to it has been powered down.
2. Disconnect all power cords and cables.
3. Locate the SODIMM socket on the system board.
4. Note the key on the socket. The key ensures the module can be plugged into the socket in only one direction.



5. Grasping the module by its edges, align the module into the socket at an approximately 30 degrees angle. Apply firm even pressure to each end of the module until it slips down into the socket. The contact fingers on the edge of the module will almost completely disappear inside the socket.




6. Push down the module until the clips at each end of the socket lock into position. You will hear a distinctive "click", indicating the module is correctly locked into position.



## Connectors

### CPU Fan Connector



Connect the CPU fan's cable connector to the CPU fan connector on the board. The cooling fan will provide adequate airflow throughout the chassis to prevent overheating the CPU and board components.


### BIOS Setting

"Module Board H/W Monitor" submenu in the Advanced menu of the BIOS will display the current speed of the cooling fan. Refer to chapter 3 of the manual for more information.

### COM Express Connectors

The COM Express connectors are used to interface the HR908-B COM Express board to a carrier board. Connect the COM Express connectors (located on the solder side of the board) to the COM Express connectors on the carrier board.

Refer to the "Installing HR908-B onto a Carrier Board" section for more information.



COM Express Connectors

Refer to the following pages for the pin functions of these connectors.

## COM Express Connectors

Row A	Row B	Row A	Row B
A1 GND (FIXED)	B1 GND (FIXED)	A56 PCIE_TX4-	B56 PCIE_RX4-
A2 GBE0_MDI3-	B2 GBE0_ACT#	A57 GND	B57 GPO2
A3 GBE0_MDI3+	B3 LPC_FRAME#	A58 PCIE_TX3+	B58 PCIE_RX3+
A4 GBE0_LINK100#	B4 LPC_AD0	A59 PCIE_TX3-	B59 PCIE_RX3-
A5 GBE0_LINK1000#	B5 LPC_AD1	A60 GND (FIXED)	B60 GND (FIXED)
A6 GBE0_MDI2-	B6 LPC_AD2	A61 PCIE_TX2+	B61 PCIE_RX2+
A7 GBE0_MDI2+	B7 LPC_AD3	A62 PCIE_TX2-	B62 PCIE_RX2-
A8 GBE0_LINK#	B8 LPC_DRQ0#	A63 GPI1	B63 GPO3
A9 GBE0_MDI1-	B9 LPC_DRQ1#	A64 PCIE_TX1+	B64 PCIE_RX1+
A10 GBE0_MDI1+	B10 LPC_CLK	A65 PCIE_TX1-	B65 PCIE_RX1-
A11 GND (FIXED)	B11 GND (FIXED)	A66 GND	B66 WAKE0#
A12 GBE0_MDI0-	B12 PWRBTN#	A67 GPI2	B67 WAKE1#
A13 GBE0_MDI0+	B13 SMB_CLK	A68 PCIE_TX0+	B68 PCIE_RX0+
A14 GBE0_CTREF	B14 SMB_DAT	A69 PCIE_TX0-	B69 PCIE_RX0-
A15 SUS_S3#	B15 SMB_ALERT#	A70 GND(FIXED)	B70 GND (FIXED)
A16 SATA0_TX+	B16 SATA1_TX+	A71 LVDS_A0+	B71 LVDS_B0+
A17 SATA0_TX-	B17 SATA1_TX-	A72 LVDS_A0-	B72 LVDS_B0-
A18 SUS_S4#	B18 SUS_STAT#	A73 LVDS_A1+	B73 LVDS_B1+
A19 SATA0_RX+	B19 SATA1_RX+	A74 LVDS_A1-	B74 LVDS_B1-
A20 SATA0_RX-	B20 SATA1_RX-	A75 LVDS_A2+	B75 LVDS_B2+
A21 GND (FIXED)	B21 GND (FIXED)	A76 LVDS_A2-	B76 LVDS_B2-
A22 SATA2_TX+	B22 SATA3_TX+	A77 LVDS_VDD_EN	B77 LVDS_B3+
A23 SATA2_TX-	B23 SATA3_TX-	A78 LVDS_A3+	B78 LVDS_B3-
A24 SUS_S5#	B24 PWR_OK	A79 LVDS_A3-	B79 LVDS_BKLT_EN
A25 SATA2_RX+	B25 SATA3_RX+	A80 GND (FIXED)	B80 GND (FIXED)
A26 SATA2_RX-	B26 SATA3_RX-	A81 LVDS_A_CK+	B81 LVDS_B_CK+
A27 BATLOW#	B27 WDT	A82 LVDS_A_CK-	B82 LVDS_B_CK-
A28 (S)ATA_ACT#	B28 AC/HDA_SDIN2	A83 LVDS_I2C_CK	B83 LVDS_BKLT_CTRL
A29 AC/HDA_SYNC	B29 AC/HDA_SDIN1	A84 LVDS_I2C_DAT	B84 VCC_5V_SBY
A30 AC/HDA_RST#	B30 AC/HDA_SDIN0	A85 GPI3	B85 VCC_5V_SBY
A31 GND (FIXED)	B31 GND (FIXED)	A86 RSVD	B86 VCC_5V_SBY
A32 AC/HDA_BITCLK	B32 SPKR	A87 RSVD	B87 VCC_5V_SBY
A33 AC/HDA_SDOUT	B33 I2C_CK	A88 PCIE0_CK_REF+	B88 BIOS_DIS1#
A34 BIOS_DIS0#	B34 I2C_DAT	A89 PCIE0_CK_REF-	B89 VGA_RED
A35 THRMTRIP#	B35 THRM#	A90 GND (FIXED)	B90 GND (FIXED)
A36 USB6-	B36 USB7-	A91 SPI_POWER	B91 VGA_GRN
A37 USB6+	B37 USB7+	A92 SPI_MISO	B92 VGA_BLU
A38 USB_6_7_OC#	B38 USB_4_5_OC#	A93 GPO0	B93 VGA_HSYNC
A39 USB4-	B39 USB5-	A94 SPI_CLK	B94 VGA_VSYNC
A40 USB4+	B40 USB5+	A95 SPI_MOSI	B95 VGA_I2C_CK
A41 GND (FIXED)	B41 GND (FIXED)	A96 TPM_PP	B96 VGA_I2C_DAT
A42 USB2-	B42 USB3-	A97 TYPE10#	B97 SPI_CS#
A43 USB2+	B43 USB3+	A98 SER0_TX	B98 RSVD
A44 USB_2_3_OC#	B44 USB_0_1_OC#	A99 SER0_RX	B99 RSVD
A45 USB0-	B45 USB1-	A100 GND (FIXED)	B100 GND (FIXED)
A46 USB0+	B46 USB1+	A101 SER1_TX	B101 FAN_PWMOUT
A47 VCC_RTC	B47 EXCD1_PERST#	A102 SER1_RX	B102 FAN_TACHIN
A48 EXCD0_PERST#	B48 EXCD1_CPPE#	A103 LID#	B103 SLEEP#
A49 EXCD0_CPPE#	B49 SYS_RESET#	A104 VCC_12V	B104 VCC_12V
A50 LPC_SERIRQ	B50 CB_RESET#	A105 VCC_12V	B105 VCC_12V
A51 GND (FIXED)	B51 GND (FIXED)	A106 VCC_12V	B106 VCC_12V
A52 PCIE_TX5+	B52 PCIE_RX5+	A107 VCC_12V	B107 VCC_12V
A53 PCIE_TX5-	B53 PCIE_RX5-	A108 VCC_12V	B108 VCC_12V
A54 GPIO	B54 GPO1	A109 VCC_12V	B109 VCC_12V
A55 PCIE_TX4+	B55 PCIE_RX4+	A110 GND (FIXED)	B110 GND (FIXED)

Row C	Row D	Row C	Row D
C1 GND (FIXED)	D1 GND (FIXED)	C56 PEG_RX1-	D56 PEG_TX1-
C2 GND	D2 GND	C57 TYPE1#	D57 TYPE2#
C3 NA	D3 NA	C58 PEG_RX2+	D58 PEG_TX2+
C4 NA	D4 NA	C59 PEG_RX2-	D59 PEG_TX2-
C5 GND	D5 GND	C60 GND (FIXED)	D60 GND (FIXED)
C6 NA	D6 NA	C61 PEG_RX3+	D61 PEG_TX3+
C7 NA	D7 NA	C62 PEG_RX3-	D62 PEG_TX3-
C8 GND	D8 GND	C63 RSVD	D63 RSVD
C9 NA	D9 NA	C64 RSVD	D64 RSVD
C10 NA	D10 NA	C65 PEG_RX4+	D65 PEG_TX4+
C11 GND (FIXED)	D11 GND (FIXED)	C66 PEG_RX4-	D66 PEG_TX4-
C12 NA	D12 NA	C67 NC	D67 GND
C13 NA	D13 NA	C68 PEG_RX5+	D68 PEG_TX5+
C14 GND	D14 GND	C69 PEG_RX5-	D69 PEG_TX5-
C15 DDI1_PAIR6+	D15 DDI1_CTRLCLK_AUX+	C70 GND (FIXED)	D70 GND (FIXED)
C16 DDI1_PAIR6-	D16 DDI1_CTRLCLK_AUX-	C71 PEG_RX6+	D71 PEG_TX6+
C17 RSVD	D17 RSVD	C72 PEG_RX6-	D72 PEG_TX6-
C18 RSVD	D18 RSVD	C73 GND	D73 GND
C19 PCIE_RX6+	D19 PCIE_TX6+	C74 PEG_RX7+	D74 PEG_TX7+
C20 PCIE_RX6-	D20 PCIE_TX6-	C75 PEG_RX7-	D75 PEG_TX7-
C21 GND (FIXED)	D21 GND (FIXED)	C76 GND	D76 GND
C22 PCIE_RX7+	D22 PCIE_TX7+	C77 RSVD	D77 IDE_CBLID#
C23 PCIE_RX7-	D23 PCIE_TX7-	C78 PEG_RX8+	D78 PEG_TX8+
C24 DDI1_HPD	D24 RSVD	C79 PEG_RX8-	D79 PEG_TX8-
C25 DDI1_PAIR4+	D25 RSVD	C80 GND (FIXED)	D80 GND (FIXED)
C26 DDI1_PAIR4-	D26 DDI1_PAIR0+	C81 PEG_RX9+	D81 PEG_TX9+
C27 RSVD	D27 DDI1_PAIR0-	C82 PEG_RX9-	D82 PEG_TX9-
C28 RSVD	D28 RSVD	C83 TPM_PP	D83 RSVD
C29 DDI1_PAIR5+	D29 DDI1_PAIR1+	C84 GND	D84 GND
C30 DDI1_PAIR5-	D30 DDI1_PAIR1-	C85 PEG_RX10+	D85 PEG_TX10+
C31 GND (FIXED)	D31 GND (FIXED)	C86 PEG_RX10-	D86 PEG_TX10-
C32 DDI2_CTRLCLK_AUX+	D32 DDI1_PAIR2+	C87 GND	D87 GND
C33 DDI2_CTRLCLK_AUX-	D33 DDI1_PAIR2-	C88 PEG_RX11+	D88 PEG_TX11+
C34 PCIE_DDC_AUX_SEL	D34 DDI1_DDC_AUX_SEL	C89 PEG_RX11-	D89 PEG_TX11-
C35 RSVD	D35 RSVD	C90 GND (FIXED)	D90 GND (FIXED)
C36 DDI3_CTRLCLK_AUX+	D36 DDI1_PAIR3+	C91 PEG_RX12+	D91 PEG_TX12+
C37 DDI3_CTRLCLK_AUX-	D37 DDI1_PAIR3-	C92 PEG_RX12-	D92 PEG_TX12-
C38 DDI3_DDC_AUX_SEL	D38 RSVD	C93 GND	D93 GND
C39 DDI3_PAIR0+	D39 DDI2_PAIR0+	C94 PEG_RX13+	D94 PEG_TX13+
C40 DDI3_PAIR0-	D40 DDI2_PAIR0-	C95 PEG_RX13-	D95 PEG_TX13-
C41 GND (FIXED)	D41 GND (FIXED)	C96 GND	D96 GND
C42 DDI3_PAIR1+	D42 DDI2_PAIR1+	C97 RSVD	D97 RSVD
C43 DDI3_PAIR1-	D43 DDI2_PAIR1-	C98 PEG_RX14+	D98 PEG_TX14+
C44 DDI3_HPD	D44 DDI2_HPD	C99 PEG_RX14-	D99 PEG_TX14-
C45 RSVD	D45 RSVD	C100 GND (FIXED)	D100 GND (FIXED)
C46 DDI3_PAIR2+	D46 DDI2_PAIR2+	C101 PEG_RX15+	D101 PEG_TX15+
C47 DDI3_PAIR2-	D47 DDI2_PAIR2-	C102 PEG_RX15-	D102 PEG_TX15-
C48 RSVD	D48 RSVD	C103 GND	D103 GND
C49 DDI3_PAIR3+	D49 DDI2_PAIR3+	C104 VCC_12V	D104 VCC_12V
C50 DDI3_PAIR3-	D50 DDI2_PAIR3-	C105 VCC_12V	D105 VCC_12V
C51 GND (FIXED)	D51 GND (FIXED)	C106 VCC_12V	D106 VCC_12V
C52 PEG_RX0+/	D52 PEG_TX0+	C107 VCC_12V	D107 VCC_12V
C53 PEG_RX0-	D53 PEG_TX0-	C108 VCC_12V	D108 VCC_12V
C54 TYPE0#	D54 PEG_LANE_RV#	C109 VCC_12V	D109 VCC_12V
C55 PEG_RX1+	D55 PEG_TX1+	C110 GND (FIXED)	D110 GND (FIXED)

## COM Express Connectors Signal Description

Pin Types  
 I Input to the Module  
 O Output from the Module  
 I/O Bi-directional input / output signal  
 OD Open drain output

**AC97/HDA Signals Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
AC/HAD_RST#	A30	O CMOS	3.3V Suspend/3.3V		Connect to CODEC pin 11 RESET#	Reset output to CODEC, active low.
AC/HDA_SYNC	A29	O CMOS	3.3V/3.3V	PU 1K to 3.3VSB	Connect to CODEC pin 10 SYNC	Sample-synchronization signal to the CODEC(s).
AC/HDA_BITCLK	A32	I/O CMOS	3.3V/3.3V		Connect to CODEC pin 6 BIT_CLK	Serial data clock generated by the external CODEC(s).
AC/HDA_SDOOUT	A33	O CMOS	3.3V/3.3V		Connect to CODEC pin 5 SDATA_OUT	Serial TDM data output to the CODEC.
AC/HDA_SDIN2	B28	I/O CMOS	3.3V Suspend/3.3V		Connect 33 $\Omega$ in series to CODEC2 pin 8 SDATA_IN	Serial TDM data inputs from up to 3 CODECs.
AC/HDA_SDIN1	B29	I/O CMOS	3.3V Suspend/3.3V		Connect 33 $\Omega$ in series to CODEC1 pin 8 SDATA_IN	
AC/HDA_SDIN0	B30	I/O CMOS	3.3V Suspend/3.3V		Connect 33 $\Omega$ in series to CODEC0 pin 8 SDATA_IN	

**Gigabit Ethernet Signals Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
GBE0_MDIO+	A13	I/O Analog	3.3V max Suspend		Connect to Magnetics Module MDIO+/-	Gigabit Ethernet Controller 0: Media Dependent Interface Differential Pairs 0,1,2,3. The MDI can operate in 1000, 100 and 10 Mbit / sec modes. Some pairs are unused in some modes, per the following: 1000BASE-T 100BASE-TX 10BASE-T MDI[0]+/- B1_DA+/- TX+/- TX+/- MDI[1]+/- B1_DB+/- RX+/- RX+/- MDI[2]+/- B1_DC+/- MDI[3]+/- B1_DD+/-
GBE0_MDIO-	A12	I/O Analog	3.3V max Suspend			
GBE0_MDII+	A10	I/O Analog	3.3V max Suspend		Connect to Magnetics Module MDII+/-	
GBE0_MDII-	A9	I/O Analog	3.3V max Suspend			
GBE0_MD12+	A7	I/O Analog	3.3V max Suspend		Connect to Magnetics Module MD12+/-	
GBE0_MD12-	A6	I/O Analog	3.3V max Suspend			Gigabit Ethernet Controller 0 activity indicator, active low. Gigabit Ethernet Controller 0 link indicator, active low. Gigabit Ethernet Controller 0 1000 Mbit / sec link indicator, active low. Gigabit Ethernet Controller 0 1000 Mbit / sec link indicator, active low.
GBE0_MD13+	A3	I/O Analog	3.3V max Suspend		Connect to Magnetics Module MD13+/-	
GBE0_MD13-	A2	I/O Analog	3.3V max Suspend			
GBE0_ACT#	B2	OD CMOS	3.3V Suspend/3.3V		Connect to LED and <b>recommend</b> current limit resistor 150 $\Omega$ to 3.3VSB	
GBE0_LINK#	A8	OD CMOS	3.3V Suspend/3.3V		NC	
GBE0_LINK100#	A4	OD CMOS	3.3V Suspend/3.3V		Connect to LED and <b>recommend</b> current limit resistor 150 $\Omega$ to 3.3VSB	
GBE0_LINK1000#	A5	OD CMOS	3.3V Suspend/3.3V		Connect to LED and <b>recommend</b> current limit resistor 150 $\Omega$ to 3.3VSB	

**SATA Signals Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
SATA0_TX+	A16	O SATA	AC coupled on Module	AC Coupling capacitor	Connect to SATA0 Conn TX pin	Serial ATA or SAS Channel 0 transmit differential pair.
SATA0_TX-	A17	O SATA	AC coupled on Module	AC Coupling capacitor		
SATA0_RX+	A19	I SATA	AC coupled on Module	AC Coupling capacitor	Connect to SATA0 Conn RX pin	Serial ATA or SAS Channel 0 receive differential pair.
SATA0_RX-	A20	I SATA	AC coupled on Module	AC Coupling capacitor		
SATA1_TX+	B16	O SATA	AC coupled on Module	AC Coupling capacitor	Connect to SATA1 Conn TX pin	Serial ATA or SAS Channel 1 transmit differential pair.
SATA1_TX-	B17	O SATA	AC coupled on Module	AC Coupling capacitor		
SATA1_RX+	B19	I SATA	AC coupled on Module	AC Coupling capacitor	Connect to SATA1 Conn RX pin	Serial ATA or SAS Channel 1 receive differential pair.
SATA1_RX-	B20	I SATA	AC coupled on Module	AC Coupling capacitor		
SATA2_TX+	A22	O SATA	AC coupled on Module	AC Coupling capacitor	Connect to SATA2 Conn TX pin	Serial ATA or SAS Channel 2 transmit differential pair.
SATA2_TX-	A23	O SATA	AC coupled on Module	AC Coupling capacitor		
SATA2_RX+	A25	I SATA	AC coupled on Module	AC Coupling capacitor	Connect to SATA2 Conn RX pin	Serial ATA or SAS Channel 2 receive differential pair.
SATA2_RX-	A26	I SATA	AC coupled on Module	AC Coupling capacitor		
SATA3_TX+	B22	O SATA	AC coupled on Module	AC Coupling capacitor	Connect to SATA3 Conn TX pin	Serial ATA or SAS Channel 3 transmit differential pair.
SATA3_TX-	B23	O SATA	AC coupled on Module	AC Coupling capacitor		
SATA3_RX+	B25	I SATA	AC coupled on Module	AC Coupling capacitor	Connect to SATA3 Conn RX pin	Serial ATA or SAS Channel 3 receive differential pair.
SATA3_RX-	B26	I SATA	AC coupled on Module	AC Coupling capacitor		
ATA_ACT#	A28	I/O CMOS	3.3V / 3.3V	PU 10K to 3.3V	Connect to LED and <b>recommend</b> current limit resistor 220 $\Omega$ to 3.3V	ATA (parallel and serial) or SAS activity indicator, active low.



## PCI Express Lanes Signals Descriptions

Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
PCIE_TX0+	A68	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Differential Transmit Pairs 0
PCIE_TX0-	A69			AC Coupling capacitor		
PCIE_RX0+	B68	I PCIE	AC coupled off Module		<b>Device</b> - Connect AC Coupling cap 0.1uF <b>Slot</b> - Connect to PCIE Conn pin	PCI Express Differential Receive Pairs 0
PCIE_RX0-	B69					
PCIE_TX1+	A64	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Differential Transmit Pairs 1
PCIE_TX1-	A65			AC Coupling capacitor		
PCIE_RX1+	B64	I PCIE	AC coupled off Module		<b>Device</b> - Connect AC Coupling cap 0.1uF <b>Slot</b> - Connect to PCIE Conn pin	PCI Express Differential Receive Pairs 1
PCIE_RX1-	B65					
PCIE_TX2+	A61	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Differential Transmit Pairs 2
PCIE_TX2-	A62			AC Coupling capacitor		
PCIE_RX2+	B61	I PCIE	AC coupled off Module		<b>Device</b> - Connect AC Coupling cap 0.1uF <b>Slot</b> - Connect to PCIE Conn pin	PCI Express Differential Receive Pairs 2
PCIE_RX2-	B62					
PCIE_TX3+	A58	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Differential Transmit Pairs 3
PCIE_TX3-	A59			AC Coupling capacitor		
PCIE_RX3+	B58	I PCIE	AC coupled off Module		<b>Device</b> - Connect AC Coupling cap 0.1uF <b>Slot</b> - Connect to PCIE Conn pin	PCI Express Differential Receive Pairs 3
PCIE_RX3-	B59					
PCIE_TX4+	A55	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Differential Transmit Pairs 4
PCIE_TX4-	A56			AC Coupling capacitor		
PCIE_RX4+	B55	I PCIE	AC coupled off Module		<b>Device</b> - Connect AC Coupling cap 0.1uF <b>Slot</b> - Connect to PCIE Conn pin	PCI Express Differential Receive Pairs 4
PCIE_RX4-	B56					
PCIE_TX5+	A52	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Differential Transmit Pairs 5
PCIE_TX5-	A53			AC Coupling capacitor		
PCIE_RX5+	B52	I PCIE	AC coupled off Module		<b>Device</b> - Connect AC Coupling cap 0.1uF <b>Slot</b> - Connect to PCIE Conn pin	PCI Express Differential Receive Pairs 5
PCIE_RX5-	B53					
PCIE_TX6+	D19	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Differential Transmit Pairs 6
PCIE_TX6-	D20			AC Coupling capacitor		
PCIE_RX6+	C19	I PCIE	AC coupled off Module		<b>Device</b> - Connect AC Coupling cap 0.1uF <b>Slot</b> - Connect to PCIE Conn pin	PCI Express Differential Receive Pairs 6
PCIE_RX6-	C20					
PCIE_TX7+	D22	O PCIE	AC coupled on Module	NA	NA	PCI Express Differential Transmit Pairs 7 (Optional with on board LAN, Default setting as NC)
PCIE_TX7-	D23			NA		
PCIE_RX7+	C22	I PCIE	AC coupled off Module	NA	NA	PCI Express Differential Receive Pairs 7 (Optional with on board LAN, Default setting as NC)
PCIE_RX7-	C23			NA		
PCIE0_CLK_REF+	A88	O PCIE	PCIE		Connect to PCIE device, <b>PCIE CLK Buffer</b> or slot	Reference clock output for all PCI Express and PCI Express Graphics lanes.
PCIE0_CLK_REF-	A89					

PEG Signals Descriptions						
Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
PEG_TX0+	D52	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 0
PEG_TX0-	D53			AC Coupling capacitor		
PEG_RX0+	C52	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 0
PEG_RX0-	C53					
PEG_TX1+	D55	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 1
PEG_TX1-	D56			AC Coupling capacitor		
PEG_RX1+	C55	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 1
PEG_RX1-	C56					
PEG_TX2+	D58	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 2
PEG_TX2-	D59			AC Coupling capacitor		
PEG_RX2+	C58	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 2
PEG_RX2-	C59					
PEG_TX3+	D61	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 3
PEG_TX3-	D62			AC Coupling capacitor		
PEG_RX3+	C61	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 3
PEG_RX3-	C62					
PEG_TX4+	D65	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 4
PEG_TX4-	D66			AC Coupling capacitor		
PEG_RX4+	C65	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 4
PEG_RX4-	C66					
PEG_TX5+	D68	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 5
PEG_TX5-	D69			AC Coupling capacitor		
PEG_RX5+	C68	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 5
PEG_RX5-	C69					
PEG_TX6+	D71	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 6
PEG_TX6-	D72			AC Coupling capacitor		
PEG_RX6+	C71	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 6
PEG_RX6-	C72					
PEG_TX7+	D74	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 7
PEG_TX7-	D75			AC Coupling capacitor		
PEG_RX7+	C74	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 7
PEG_RX7-	C75					
PEG_TX8+	D78	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 8
PEG_TX8-	D79			AC Coupling capacitor		
PEG_RX8+	C78	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 8
PEG_RX8-	C79					
PEG_TX9+	D81	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 9
PEG_TX9-	D82			AC Coupling capacitor		
PEG_RX9+	C81	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 9
PEG_RX9-	C82					
PEG_TX10+	D85	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 10
PEG_TX10-	D86			AC Coupling capacitor		
PEG_RX10+	C85	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 10
PEG_RX10-	C86					
PEG_TX11+	D88	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 11
PEG_TX11-	D89			AC Coupling capacitor		
PEG_RX11+	C88	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 11
PEG_RX11-	C89					
PEG_TX12+	D91	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 12
PEG_TX12-	D92			AC Coupling capacitor		
PEG_RX12+	C91	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 12
PEG_RX12-	C92					
PEG_TX13+	D94	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 13
PEG_TX13-	D95			AC Coupling capacitor		
PEG_RX13+	C94	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 13
PEG_RX13-	C95					
PEG_TX14+	D98	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 14
PEG_TX14-	D99			AC Coupling capacitor		
PEG_RX14+	C98	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 14
PEG_RX14-	C99					
PEG_TX15+	D101	O PCIE	AC coupled on Module	AC Coupling capacitor	Connect to PCIE device or slot	PCI Express Graphics transmit differential pairs 15
PEG_TX15-	D102			AC Coupling capacitor		
PEG_RX15+	C101	I PCIE	AC coupled off Module		Connect AC Coupling cap 0.22uF	PCI Express Graphics receive differential pairs 15
PEG_RX15-	C102					
PEG_LANE_RV#	D54	I CMOS	3.3V / 3.3V			PCI Express Graphics lane reversal input strap. Pull low on the Carrier board to reverse lane order.

**ExpressCard Signals Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail / Tolerance	HR908	Carrier Board	Description
EXCD0_CPPE#	A49	I CMOS	3.3V / 3.3V	PU 10k to 3.3V		PCI ExpressCard: PCI Express capable card request, active low, one per card
EXCD1_CPPE#	B48			PU 10k to 3.3V		
EXCD0_PERST#	A48					
EXCD1_PERST#	B47	O CMOS	3.3V / 3.3V			PCI ExpressCard: reset, active low, one per card

**DDI Signals Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail / Tolerance	HR908	Carrier Board	Description
DDI1_PAIR0+/SDVO1_RED+	D26	O PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	DDI 1 Pair 0 differential pairs/Serial Digital Video B red output differential pair
DDI1_PAIR0-/SDVO1_RED-	D27				Connect AC Coupling Capacitors 0.1uF to Device	
DDI1_PAIR1+/SDVO1_GRN+	D29	O PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	DDI 1 Pair 1 differential pairs/Serial Digital Video B green output differential pair
DDI1_PAIR1-/SDVO1_GRN-	D30				Connect AC Coupling Capacitors 0.1uF to Device	
DDI1_PAIR2+/SDVO1_BLU+	D32	O PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	DDI 1 Pair 2 differential pairs/Serial Digital Video B blue output differential pair
DDI1_PAIR2-/SDVO1_BLU-	D33				Connect AC Coupling Capacitors 0.1uF to Device	
DDI1_PAIR3+/SDVO1_CK+	D36	O PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	DDI 1 Pair 3 differential pairs/Serial Digital Video B clock output differential pair.
DDI1_PAIR3-/SDVO1_CK-	D37				Connect AC Coupling Capacitors 0.1uF to Device	
DDI1_PAIR4+/SDVO1_INT+	C25	I PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	Serial Digital Video B interrupt input differential pair.
DDI1_PAIR4-/SDVO1_INT-	C26				Connect AC Coupling Capacitors 0.1uF to Device	
DDI1_PAIR5+/SDVO1_TVCLKIN+	C29	I PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	Serial Digital Video TVOUT synchronization clock input differential pair.
DDI1_PAIR5-/SDVO1_TVCLKIN-	C30				Connect AC Coupling Capacitors 0.1uF to Device	
DDI1_PAIR6+/SDVO1_FLDSTALL+	C15	I PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	Serial Digital Video Field Stall input differential pair.
DDI1_PAIR6-/SDVO1_FLDSTALL-	C16				Connect AC Coupling Capacitors 0.1uF to Device	
DDI1_CTRLCLK_AUX+/SDVO1_CTRLCLK	D15	I/O PCIE	AC coupled on Module	PD 49.9K to GND (S/W IC between	Connect to DP AUX+	DP AUX+ function if DDI1_DDC_AUX_SEL is no connect
		I/O OD CMOS	3.3V / 3.3V	PU 2.2K to 3.3V, PD 49.9K to GND	Connect to HDMI/DVI I2C CTRLCLK	HDMI/DVI I2C CTRLCLK if DDI1_DDC_AUX_SEL is pulled high
DDI1_CTRLCLK_AUX-/SDVO1_CTRLDATA	D16	I/O PCIE	AC coupled on Module	PU 100K to 3.3V (S/W IC between	Connect to DP AUX-	DP AUX- function if DDI1_DDC_AUX_SEL is no connect
		I/O OD CMOS	3.3V / 3.3V	PU 2.2K to 3.3V/PU 100K to 3.3V (S/W IC between	Connect to HDMI/DVI I2C CTRLDATA	HDMI/DVI I2C CTRLDATA if DDI1_DDC_AUX_SEL is pulled high
DDI1_HPDP	C24	I CMOS	3.3V / 3.3V		PD 1M and Connect to device Hot Plug Detect	DDI Hot-Plug Detect
DDI1_DDC_AUX_SEL	D34	I CMOS	3.3V / 3.3V	PD 1M	PU 100K to 3.3V for DDC(HDMI/DVI)	Selects the function of DDI1_CTRLCLK_AUX+ and DDI1_CTRLDATA_AUX-. DDI[n]_DDC_AUX_SEL shall be pulled to 3.3V on the Carrier with a 100K Ohm resistor to configure the DDI[n]_AUX pair as the DDC channel. Carrier DDI[n]_DDC_AUX_SEL should be connected to pin 13 of the DisplayPort
DDI2_PAIR0+	D39	O PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	DDI 2 Pair 0 differential pairs
DDI2_PAIR0-	D40				Connect AC Coupling Capacitors 0.1uF to Device	
DDI2_PAIR1+	D42	O PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	DDI 2 Pair 1 differential pairs
DDI2_PAIR1-	D43				Connect AC Coupling Capacitors 0.1uF to Device	
DDI2_PAIR2+	D46	O PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	DDI 2 Pair 2 differential pairs
DDI2_PAIR2-	D47				Connect AC Coupling Capacitors 0.1uF to Device	
DDI2_PAIR3+	D49	O PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	DDI 2 Pair 3 differential pairs
DDI2_PAIR3-	D50				Connect AC Coupling Capacitors 0.1uF to Device	
DDI2_CTRLCLK_AUX+	C32	I/O PCIE	AC coupled on Module	PD 49.9K to GND (S/W IC between	Connect to DP AUX+	DP AUX+ function if DDI2_DDC_AUX_SEL is no connect
		I/O OD CMOS	3.3V / 3.3V	PU 2.2K to 3.3V, PD 49.9K to GND	Connect to HDMI/DVI I2C CTRLCLK	HDMI/DVI I2C CTRLCLK if DDI2_DDC_AUX_SEL is pulled high
DDI2_CTRLCLK_AUX-	C33	I/O PCIE	AC coupled on Module	PU 100K to 3.3V (S/W IC between	Connect to DP AUX-	DP AUX- function if DDI2_DDC_AUX_SEL is no connect
		I/O OD CMOS	3.3V / 3.3V	PU 2.2K to 3.3V/PU 100K to 3.3V (S/W IC between	Connect to HDMI/DVI I2C CTRLDATA	HDMI/DVI I2C CTRLDATA if DDI2_DDC_AUX_SEL is pulled high
DDI3_HPDP	D44	I CMOS	3.3V / 3.3V		PD 1M and Connect to device Hot Plug Detect	DDI Hot-Plug Detect
DDI3_DDC_AUX_SEL	C34	I CMOS	3.3V / 3.3V	PD 1M to GND	PU 100K to 3.3V for DDC(HDMI/DVI)	Selects the function of DDI2_CTRLCLK_AUX+ and DDI2_CTRLDATA_AUX-. DDI[n]_DDC_AUX_SEL shall be pulled to 3.3V on the Carrier with a 100K Ohm resistor to configure the DDI[n]_AUX pair as the DDC channel. Carrier DDI[n]_DDC_AUX_SEL should be connected to pin 13 of the DisplayPort
DDI3_PAIR0+	C39	O PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	DDI 3 Pair 0 differential pairs
DDI3_PAIR0-	C40				Connect AC Coupling Capacitors 0.1uF to Device	
DDI3_PAIR1+	C42	O PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	DDI 3 Pair 1 differential pairs
DDI3_PAIR1-	C43				Connect AC Coupling Capacitors 0.1uF to Device	
DDI3_PAIR2+	C46	O PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	DDI 3 Pair 2 differential pairs
DDI3_PAIR2-	C47				Connect AC Coupling Capacitors 0.1uF to Device	
DDI3_PAIR3+	C49	O PCIE	AC coupled off Module		Connect AC Coupling Capacitors 0.1uF to Device	DDI 3 Pair 3 differential pairs
DDI3_PAIR3-	C50				Connect AC Coupling Capacitors 0.1uF to Device	

DDI Signals Descriptions						
Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
DDI3_CTRLCLK_AUX+	C36	I/O PCIE	AC coupled on Module	PD 49.9K to GND <b>(S/W IC between</b>	Connect to DP AUX+	DP AUX+ function if DDI3_DDC_AUX_SEL is no connect
		I/O OD CMOS	3.3V / 3.3V	PU 2.2K to 3.3V, PD 49.9K to GND <b>(S/W IC between Rpu/Rpd</b>	Connect to HDMI/DVI I2C CTRLCLK	HDMI/DVI I2C CTRLCLK if DDI3_DDC_AUX_SEL is pulled high
DDI3_CTRLCLK_AUX-	C37	I/O PCIE	AC coupled on Module	PU 100K to 3.3V <b>(S/W IC between</b>	Connect to DP AUX-	DP AUX- function if DDI3_DDC_AUX_SEL is no connect
		I/O OD CMOS	3.3V / 3.3V	PU 2.2K to 3.3V/PU 100K to 3.3V	Connect to HDMI/DVI I2C CTRLDATA	HDMI/DVI I2C CTRLDATA if DDI3_DDC_AUX_SEL is pulled high
DDI3_HPD	C44	I CMOS	3.3V / 3.3V		PD 1M and Connect to device Hot Plug Detect	DDI Hot-Plug Detect
DDI3_DDC_AUX_SEL	C38	I CMOS	3.3V / 3.3V	PD 1M to GND	PU 100K to 3.3V for DDC(HDMI/DVI)	Selects the function of DDI3_CTRLCLK_AUX+ and DDI3_CTRLDATA_AUX-. DDI[n]_DDC_AUX_SEL shall be pulled to 3.3V on the Carrier with a 100K Ohm resistor to configure the DDI[n]_AUX pair as the DDC channel. Carrier DDI[n]_DDC_AUX_SEL should be connected to pin 13 of the DisplayPort

**Important:**

Ivy Bridge CPU+QM67 does not support active 3 display ports, only support active 2 display ports.

**USB Signals Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
USB0+	A46	I/O USB	3.3V Suspend/3.3V		Connect 90Ω @100MHz Common Choke in series and ESD suppressors to GND to USB connector	USB differential pairs 0
USB0-	A45					
USB1+	B46	I/O USB	3.3V Suspend/3.3V		Connect 90Ω @100MHz Common Choke in series and ESD suppressors to GND to USB connector	USB differential pairs 1
USB1-	B45					
USB2+	A43	I/O USB	3.3V Suspend/3.3V		Connect 90Ω @100MHz Common Choke in series and ESD suppressors to GND to USB connector	USB differential pairs 2
USB2-	A42					
USB3+	B43	I/O USB	3.3V Suspend/3.3V		Connect 90Ω @100MHz Common Choke in series and ESD suppressors to GND to USB connector	USB differential pairs 3
USB3-	B42					
USB4+	A40	I/O USB	3.3V Suspend/3.3V		Connect 90Ω @100MHz Common Choke in series and ESD suppressors to GND to USB connector	USB differential pairs 4
USB4-	A39					
USB5+	B40	I/O USB	3.3V Suspend/3.3V		Connect 90Ω @100MHz Common Choke in series and ESD suppressors to GND to USB connector	USB differential pairs 5
USB5-	B39					
USB6+	A37	I/O USB	3.3V Suspend/3.3V		Connect 90Ω @100MHz Common Choke in series and ESD suppressors to GND to USB connector	USB differential pairs 6
USB6-	A36					
USB7+	B37					
USB7-	B36	I/O USB	3.3V Suspend/3.3V		Connect 90Ω @100MHz Common Choke in series and ESD suppressors to GND to USB connector	USB differential pairs 7, USB7 may be configured as a USB client or as a host, or both, at the Module designer's discretion.(CR901-B default set as a host)
USB_0_1_OC#	B44	I CMOS	3.3V Suspend/3.3V	PU 10k to 3.3VSB	Connect to Overcurrent of USB Power Switch	USB over-current sense, USB channels 0 and 1. A pull-up for this line shall be present on the Module. An open drain driver from a USB current monitor on the Carrier Board may drive this line low. Do not pull this line high on the Carrier Board.
USB_2_3_OC#	A44	I CMOS	3.3V Suspend/3.3V	PU 10k to 3.3VSB	Connect to Overcurrent of USB Power Switch	USB over-current sense, USB channels 2 and 3. A pull-up for this line shall be present on the Module. An open drain driver from a USB current monitor on the Carrier Board may drive this line low. Do not pull this line high on the Carrier Board.
USB_4_5_OC#	B38	I CMOS	3.3V Suspend/3.3V	PU 10k to 3.3VSB	Connect to Overcurrent of USB Power Switch	USB over-current sense, USB channels 4 and 5. A pull-up for this line shall be present on the Module. An open drain driver from a USB current monitor on the Carrier Board may drive this line low. Do not pull this line high on the Carrier Board.
USB_6_7_OC#	A38	I CMOS	3.3V Suspend/3.3V	PU 10k to 3.3VSB	Connect to Overcurrent of USB Power Switch	USB over-current sense, USB channels 6 and 7. A pull-up for this line shall be present on the Module. An open drain driver from a USB current monitor on the Carrier Board may drive this line low. Do not pull this line high on the Carrier Board.

**LVDS Signals Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
LVDS_A0+	A71	O LVDS	LVDS		Connect to LVDS connector	LVDS Channel A differential pairs Ther LVDS flat panel differential pairs (LVDS_A[0:3]+/-, LVDS_B[0:3]+/-, LVDS_A_CK+/-, LVDS_B_CK+/-) shall have 100Ω terminations across the pairs at the destination. These terminations may be on the Carrier Board if the Carrier Board implements a LVDS deserializer on-board
LVDS_A0-	A72					
LVDS_A1+	A73	O LVDS	LVDS		Connect to LVDS connector	
LVDS_A1-	A74					
LVDS_A2+	A75	O LVDS	LVDS		Connect to LVDS connector	LVDS Channel A differential clock
LVDS_A2-	A76					
LVDS_A3+	A78	O LVDS	LVDS		Connect to LVDS connector	
LVDS_A3-	A79					
LVDS_A_CK+	A81	O LVDS	LVDS		Connect to LVDS connector	LVDS Channel B differential pairs Ther LVDS flat panel differential pairs (LVDS_A[0:3]+/-, LVDS_B[0:3]+/-, LVDS_A_CK+/-, LVDS_B_CK+/-) shall have 100Ω terminations across the pairs at the destination. These terminations may be on the Carrier Board if the Carrier Board implements a LVDS deserializer on-board
LVDS_A_CK-	A82					
LVDS_B0+	B71	O LVDS	LVDS		Connect to LVDS connector	
LVDS_B0-	B72					
LVDS_B1+	B73	O LVDS	LVDS		Connect to LVDS connector	LVDS Channel B differential clock
LVDS_B1-	B74					
LVDS_B2+	B75	O LVDS	LVDS		Connect to LVDS connector	
LVDS_B2-	B76					
LVDS_B3+	B77	O LVDS	LVDS		Connect to LVDS connector	LVDS panel power enable
LVDS_B3-	B78					
LVDS_B_CK+	B81	O LVDS	LVDS		Connect to LVDS connector	
LVDS_B_CK-	B82					
LVDS_VDD_EN	A77	O CMOS	3.3V / 3.3V	PD 100K to GND	Connect to enable control of LVDS panel power circuit	LVDS panel backlight enable
LVDS_BKLT_EN	B79	O CMOS	3.3V / 3.3V	PD 100K to GND	Connect to enable control of LVDS panel backlight power circuit.	LVDS panel backlight brightness control
LVDS_BKLT_CTRL	B83	O CMOS	3.3V / 3.3V	PD 100K to GND	Connect to brightness control of LVDS panel backlight power circuit.	I2C clock output for LVDS display use
LVDS_I2C_CK	A83	I/O OD CMOS	3.3V / 3.3V	PU 2.2K to 3.3V	Connect to DDC clock of LVDS panel	I2C data line for LVDS display use
LVDS_I2C_DAT	A84	I/O OD CMOS	3.3V / 3.3V	PU 2.2K to 3.3V	Connect to DDC data of LVDS panel	

**LPC Signals Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
LPC_AD0	B4					
LPC_AD1	B5					
LPC_AD2	B6	I/O CMOS	3.3V / 3.3V			LPC multiplexed address, command and data bus
LPC_AD3	B7					
LPC_FRAME#	B3	O CMOS	3.3V / 3.3V		Connect to LPC device	LPC frame indicates the start of an LPC cycle
LPC_DRQ0#	B8	I CMOS	3.3V / 3.3V			LPC serial DMA request
LPC_DRQ1#	B9					
LPC_SERIRQ	A50	I/O CMOS	3.3V / 3.3V	PU 10K to 3.3V		LPC serial interrupt
LPC_CLK	B10	O CMOS	3.3V / 3.3V			LPC clock output - 33MHz nominal

**SPI Signals Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description																																								
SPI_CS#	B97	O CMOS	3.3V Suspend/3.3V		Connect a series resistor 33Ω to Carrier Board SPI Device CS# pin	Chip select for Carrier Board SPI - may be sourced from chipset SPI0 or SPI1																																								
SPI_MISO	A92	I CMOS	3.3V Suspend/3.3V		Connect a series resistor 33Ω to Carrier Board SPI Device SO pin	Data in to Module from Carrier SPI																																								
SPI_MOSI	A95	O CMOS	3.3V Suspend/3.3V		Connect a series resistor 33Ω to Carrier Board SPI Device SI pin	Data out from Module to Carrier SPI																																								
SPI_CLK	A94	O CMOS	3.3V Suspend/3.3V		Connect a series resistor 33Ω to Carrier Board SPI Device SCK pin	Clock from Module to Carrier SPI																																								
SPI_POWER	A91	O	3.3V Suspend/3.3V			Power supply for Carrier Board SPI – sourced from Module – nominally 3.3V. The Module shall provide a minimum of 100mA on SPI_POWER. Carriers shall use less than 100mA of SPI_POWER. SPI_POWER shall only be used to power SPI devices on the Carrier																																								
BIOS_DIS0#	A34					Selection straps to determine the BIOS boot device. The Carrier should only float these or pull them low, please refer to COM Express Module Base Specification Revision 2.1 for strapping options of BIOS disable signals.																																								
BIOS_DIS1#	B88	I CMOS	NA			<table><tr><th>BIOS DIS1#</th><th>BIOS DIS0#</th><th>Chipset SPI CS1# Destination</th><th>Chipset SPI CS0# Destination</th><th>Carrier SPI_CS#</th><th>SPI Descriptbr</th><th>Bios Entry</th><th>Ref Line</th></tr><tr><td>1</td><td>1</td><td>Module</td><td>Module</td><td>High</td><td>Module</td><td>SPI0/SPI1</td><td>0</td></tr><tr><td>1</td><td>0</td><td>Module</td><td>Module</td><td>High</td><td>Module</td><td>Carrier FWH</td><td>1</td></tr><tr><td>0</td><td>1</td><td>Module</td><td>Carrier</td><td>SPI0</td><td>Carrier</td><td>SPI0/SPI1</td><td>2</td></tr><tr><td>0</td><td>0</td><td>Carrier (Default)</td><td>Module (Default)</td><td>SPI1 (Default)</td><td>Module (Default)</td><td>SPI0/SPI1 (Default)</td><td>3</td></tr></table>	BIOS DIS1#	BIOS DIS0#	Chipset SPI CS1# Destination	Chipset SPI CS0# Destination	Carrier SPI_CS#	SPI Descriptbr	Bios Entry	Ref Line	1	1	Module	Module	High	Module	SPI0/SPI1	0	1	0	Module	Module	High	Module	Carrier FWH	1	0	1	Module	Carrier	SPI0	Carrier	SPI0/SPI1	2	0	0	Carrier (Default)	Module (Default)	SPI1 (Default)	Module (Default)	SPI0/SPI1 (Default)	3
BIOS DIS1#	BIOS DIS0#	Chipset SPI CS1# Destination	Chipset SPI CS0# Destination	Carrier SPI_CS#	SPI Descriptbr	Bios Entry	Ref Line																																							
1	1	Module	Module	High	Module	SPI0/SPI1	0																																							
1	0	Module	Module	High	Module	Carrier FWH	1																																							
0	1	Module	Carrier	SPI0	Carrier	SPI0/SPI1	2																																							
0	0	Carrier (Default)	Module (Default)	SPI1 (Default)	Module (Default)	SPI0/SPI1 (Default)	3																																							

**VGA Signals Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
VGA_RED	B89	O Analog	Analog	PD 150R	PD 150R, connect to VGA connector with EMI filter & ESD protect component.	Red for monitor. Analog output
VGA_GRN	B91	O Analog	Analog	PD 150R	PD 150R, connect to VGA connector with EMI filter & ESD protect component.	Green for monitor. Analog output
VGA_BLU	B92	O Analog	Analog	PD 150R	PD 150R, connect to VGA connector with EMI filter & ESD protect component.	Blue for monitor. Analog output
VGA_HSYNC	B93	O CMOS	3.3V / 3.3V		Connect to VGA connector with a 3.3V Buffer IC to isolate PCH & Display Device	Horizontal sync output to VGA monitor
VGA_VSYNC	B94	O CMOS	3.3V / 3.3V		Connect to VGA connector with a 33V Buffer IC to isolate PCH & Display Device	Vertical sync output to VGA monitor
VGA_I2C_CLK	B95	I/O OD CMOS	3.3V / 3.3V	PD 2.2K to 3.3V	Connect to VGA connector with a 3.3V to 5V Level shift circuit.	DDC clock line (I2C port dedicated to identify VGA monitor capabilities)
VGA_I2C_DAT	B96	I/O OD CMOS	3.3V / 3.3V	PD 2.2K to 3.3V	Connect to VGA connector with a 3.3V to 5V Level shift circuit.	DDC data line.

**Serial Interface Signals Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
SER0_TX	A98	O CMOS	3.3V/5V		PD 4.7K	General purpose serial port 0 transmitter (Recommend add Protecting Logic Level Signals on Pins Reclaimed from VCC_12V)
SER0_RX	A99	I CMOS	3.3V/5V		PU 47K to 3.3V	General purpose serial port 0 receiver (Recommend add Protecting Logic Level Signals on Pins Reclaimed from VCC_12V)
SER1_TX	A101	O CMOS	3.3V/5V		PD 4.7K	General purpose serial port 1 transmitter (Recommend add Protecting Logic Level Signals on Pins Reclaimed from VCC_12V)
SER1_RX	A102	I CMOS	3.3V/5V		PU 47K to 3.3V	General purpose serial port 1 receiver (Recommend add Protecting Logic Level Signals on Pins Reclaimed from VCC_12V)

**Miscellaneous Signal Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
I2C_CLK	B33	I/O OD CMOS	3.3V Suspend/3.3V	PU 2.2K to 3.3VSB		General purpose I2C port clock output.
I2C_DAT	B34	I/O OD CMOS	3.3V Suspend/3.3V	PU 2.2K to 3.3VSB		General purpose I2C port data I/O line.
SPKR	B32	O CMOS	3.3V / 3.3V			Output for audio enunciator - the "speaker" in PC-AT systems. This port provides the PC beep signal and is mostly intended for debugging purposes.
WDT	B27	O CMOS	3.3V / 3.3V			Output indicating that a watchdog time-out event has occurred.
FAN_PWNOUT	B101	O OD CMOS	3.3V / 3.3V			Fan speed control. Uses the Pulse Width Modulation (PWM) technique to control the fan's RPM. <b>(Recommend add Protecting Logic Level Signals on Pins Reclaimed from VCC_12V)</b>
FAN_TACHIN	B102	I OD CMOS	3.3V / 3.3V			Fan tachometer input for a fan with a two pulse output. <b>(Recommend add Protecting Logic Level Signals on Pins Reclaimed from VCC_12V)</b>
TPM_PP	A96	I CMOS	3.3V / 3.3V	PD 1M		Trusted Platform Module (TPM) Physical Presence pin. Active high. TPM chip has an internal pull down. This signal is used to indicate Physical Presence to the TPM.

**Power and System Management Signals Descriptions**

Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
PWRBTN#	B12	I CMOS	3.3V Suspend/3.3V	PU 10K to 3.3VSB		A falling edge creates a power button event. Power button events can be used to bring a system out of S5 soft off and other suspend states, as well as powering the system down.
SYS_RESET#	B49	I CMOS	3.3V Suspend/3.3V	PU 10K to 3.3V		Reset button input. Active low request for Module to reset and reboot. May be falling edge sensitive. For situations when SYS_RESET# is not able to reestablish control of the system, PWR_OK or a power cycle may be used.
CB_RESET#	B50	O CMOS	3.3V Suspend/3.3V	PU 10K to 3.3VSB		Reset output from Module to Carrier Board. Active low. Issued by Module chipset and may result from a low SYS_RESET# input, a low PWR_OK input, a VCC_12V power input that falls below the minimum specification, a watchdog timeout, or may be initiated by the Module software.
PWR_OK	B24	I CMOS	3.3V / 3.3V			Power OK from main power supply. A high value indicates that the power is good. This signal can be used to hold off Module startup to allow Carrier based FPGAs or other configurable devices time to be programmed.
SUS_STAT#	B18	O CMOS	3.3V Suspend/3.3V			Indicates imminent suspend operation; used to notify LPC devices.
SUS_S3#	A15	O CMOS	3.3V Suspend/3.3V			Indicates system is in Suspend to RAM state. Active low output. An inverted copy of SUS_S3# on the Carrier Board may be used to enable the non-standby power on a typical ATX supply.
SUS_S4#	A18	O CMOS	3.3V Suspend/3.3V			Indicates system is in Suspend to Disk state. Active low output.
SUS_S5#	A24	O CMOS	3.3V Suspend/3.3V			Indicates system is in Soft Off state.
WAKE0#	B66	I CMOS	3.3V Suspend/3.3V	PU 10K to 3.3VSB		PCI Express wake up signal.
WAKE1#	B67	I CMOS	3.3V Suspend/3.3V	PU 10K to 3.3VSB		General purpose wake up signal. May be used to implement wake-up on PS2 keyboard or mouse activity.
BATLOW#	A27	I CMOS	3.3V Suspend/ 3.3V	PU 10K to 3.3VSB		Indicates that external battery is low. This port provides a battery-low signal to the Module for orderly transitioning to power saving or power cut-off ACPI modes.
LID#	A103	I OD CMOS	3.3V Suspend/12V	PU 10K to 3.3VSB		LID switch. Low active signal used by the ACPI operating system for a LID switch. <b>(Recommend add Protecting Logic Level Signals on Pins Reclaimed from VCC_12V)</b>
SLEEP#	B103	I OD CMOS	3.3V Suspend/12V	PU 10K to 3.3VSB		Sleep button. Low active signal used by the ACPI operating system to bring the system to sleep state or to wake it up again. <b>(Recommend add Protecting Logic Level Signals on Pins Reclaimed from VCC_12V)</b>
THRM#	B35	I CMOS	3.3V / 3.3V	PU 10K to 3.3V		Input from off-Module temp sensor indicating an over-temp situation.
THRMTRIP#	A35	O CMOS	3.3V / 3.3V	PU 10K to 3.3V		Active low output indicating that the CPU has entered thermal shutdown.
SMB_CLK	B13	I/O OD CMOS	3.3V Suspend/3.3V	PU 2.2K to 3.3VSB		System Management Bus bidirectional clock line.
SMB_DAT	B14	I/O OD CMOS	3.3V Suspend/3.3V	PU 2.2K to 3.3VSB		System Management Bus bidirectional data line.
SMB_ALERT#	B15	I CMOS	3.3V Suspend/3.3V	PU 10K to 3.3VSB		System Management Bus Alert – active low input can be used to generate an SMI# (System Management Interrupt) or to wake the system.


GPIO Signals Descriptions						
Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
GPO0	A93	O CMOS	3.3V / 3.3V			General purpose output pins. <b>Upon a hardware reset, these outputs should be low.</b>
GPO1	B54					
GPO2	B57					
GPO3	B63					
GPI0	A54	I CMOS	3.3V / 3.3V			General purpose input pins. <b>Pulled high internally on the Module.</b>
GPI1	A63					
GPI2	A67					
GPI3	A85					

Power and GND Signal Descriptions						
Signal	Pin#	Module Pin Type	Pwr Rail /Tolerance	HR908	Carrier Board	Description
VCC_12V	A104~A109 B104~B109 C104~C109 D104~D109	Power				Primary power input: +12V nominal. All available VCC_12V pins on the connector(s) shall be used.
VCC_5V_SBY	B84~B87	Power				Standby power input: +5.0V nominal. If VCC5_SBY is used, all available VCC_5V_SBY pins on the connector(s) shall be used. Only used for standby and suspend functions. May be left unconnected if these functions are not used in the system design.
VCC_RTC	A47	Power				Real-time clock circuit-power input. Nominally +3.0V.
GND	A1, A11, A21, A31, A41, A51, A57, A60, A66, A70, A80, A90, A100, A110, B1, B11, B21, B31, B41, B51, B60, B70, B80, B90, B100, B110, C1, C2, C5, C8, C11, C14, C21, C31, C41, C51, C60, C70, C73, C76, C80, C84, C87, C90, C93, C96, C100, C103, C110, D1, D2, D5, D8, D11, D14, D21, D31, D51, D60, D67, D70, D73, D76, D80, D84, D87, D90, D93, D96, D100, D103, D110	Power				Ground - DC power and signal and AC signal return path. All available GND connector pins shall be used and tied to Carrier Board GND plane.



## Standby Power LED



This LED will light when the system is in the standby mode.


## Cooling Option

### Heat Sink with Cooling Fan




**Note:**

The system board used in the following illustrations may not resemble the actual board. These illustrations are for reference only.



Top View of the Heat Sink



Bottom View of the Heat Sink

- "1" and "2" denote the locations of the thermal pads designed to contact the corresponding components that are on HR908-B.



**Important:**

Remove the plastic covering from the thermal pads prior to mounting the heat sink onto HR908-B.

## Installing HR908-B onto a Carrier Board




### Important:

The carrier board (COM331-B) used in this section is for reference purpose only and may not resemble your carrier board. These illustrations are mainly to guide you on how to install HR908-B onto the carrier board of your choice.


#### • To download COM331-B datasheet and manual

1. Now install the module and heatsink assembly onto the carrier board. The photo below shows the locations of the mounting holes on carrier board.




Mounting hole

2. Insert the provided mounting screws into the mounting holes - from the bottom through the top of the carrier board.




Mounting screws

3. While supporting the mounting screw at the bottom, from the top side of the board, fasten a bolt into the screw.




Bolts

4. The photo below shows the solder side of the board with the screws already fixed in place.




Mounting screw

5. The photo below shows the component side of the board with the bolts already fixed in place.




Bolts

6. Grasping HR908-B by its edges, position it on top of the carrier board with its mounting holes aligned with the bolts on the carrier board. This will also align the COM Express connectors of the two boards to each other.




COM Express connectors  
on HR908-B



COM Express connectors  
on the carrier board

7. Press HR908-B down firmly until it is completely seated on the COM Express connectors of the carrier board.



HR908-B


Carrier board

8. Use the provided mounting screws to secure HR908-B with heat sink to the carrier board and then connect the cooling fan's cable to the fan connector on HR908-B.

The photo below shows the locations of the long mounting screws.



Long screws



Fan connector

## Chapter 4 - BIOS Setup

### Overview

The BIOS is a program that takes care of the basic level of communication between the CPU and peripherals. It contains codes for various advanced features found in this system board. The BIOS allows you to configure the system and save the configuration in a battery-backed CMOS so that the data retains even when the power is off. In general, the information stored in the CMOS RAM of the EEPROM will stay unchanged unless a configuration change has been made such as a hard drive replaced or a device added. It is possible that the CMOS battery will fail causing CMOS data loss. If this happens, you need to install a new CMOS battery and reconfigure the BIOS settings.


**Note:**

The BIOS is constantly updated to improve the performance of the system board; therefore the BIOS screens in this chapter may not appear the same as the actual one. These screens are for reference purpose only.

### Default Configuration

Most of the configuration settings are either predefined according to the Load Optimal Defaults settings which are stored in the BIOS or are automatically detected and configured without requiring any actions. There are a few settings that you may need to change depending on your system configuration.

### Entering the BIOS Setup Utility

The BIOS Setup Utility can only be operated from the keyboard and all commands are keyboard commands. The commands are available at the right side of each setup screen.

The BIOS Setup Utility does not require an operating system to run. After you power up the system, the BIOS message appears on the screen and the memory count begins. After the memory test, the message "Press DEL to run setup" will appear on the screen. If the message disappears before you respond, restart the system or press the "Reset" button. You may also restart the system by pressing the <Ctrl> <Alt> and <Del> keys simultaneously.

### Legends

KEYs	Function
Right and Left Arrows	Moves the highlight left or right to select a menu.
Up and Down Arrows	Moves the highlight up or down between submenus or fields.
<Esc>	Exits to the BIOS setup utility
+ (plus key)	Scrolls forward through the values or options of the highlighted field.
- (minus key)	Scrolls backward through the values or options of the highlighted field.
Tab	Select a field
<F1>	Displays general help
<Enter>	Press <Enter> to enter the highlighted submenu

### Scroll Bar

When a scroll bar appears to the right of the setup screen, it indicates that there are more available fields not shown on the screen. Use the up and down arrow keys to scroll through all the available fields.


### Submenu

When "►" appears on the left of a particular field, it indicates that a submenu which contains additional options are available for that field. To display the submenu, move the highlight to that field and press <Enter>.

## AMI BIOS Setup Utility

### Main

The Main menu is the first screen that you will see when you enter the BIOS Setup Utility.



#### System Date

The date format is <day>, <month>, <date>, <year>. Day displays a day, from Sunday to Saturday. Month displays the month, from January to December. Date displays the date, from 1 to 31. Year displays the year, from 1980 to 2099.

#### System Time

The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00. Hour displays hours from 00 to 23. Minute displays minutes from 00 to 59. Second displays seconds from 00 to 59.


### Advanced

The Advanced menu allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.




#### Important:

Setting incorrect field values may cause the system to malfunction.



## ACPI Power Management Configuration

This section is used to configure the ACPI Power Management.



### ACPI Sleep State

Selects the highest ACPI sleep state the system will enter when the Suspend button is pressed.

**S1(POS)** Enables the Power On Suspend function.

**S3(STR)** Enables the Suspend to RAM function.

### Resume by PME


Enable this field to use the PME signal to wake up the system (via PCIE and onboard (LAN)).

### Resume by RTC Alarm

When Enabled, the system uses the RTC to generate a wakeup event.

## PC Health Status

This section displays hardware health monitor.





## CPU Configuration

This section is used to configure the CPU. It will also display the detected CPU information.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Advanced		
<b>CPU Configuration</b>		Enabled for Windows XP and Linux (OS optimized for Hyper-Threading Technology) and Disabled for other OS (OS not optimized for Hyper-Threading Technology). When Disabled only one thread per enabled core is enabled.
Intel(R) Core(TM) i3-3217UE CPU @ 1.60GHz		
CPU Signature	306a8	
Microcode Patch	C	
Max CPU Speed	1600 MHz	
Min CPU Speed	800 MHz	
CPU Speed	1500 MHz	
Processor Cores	2	
Intel HT Technology	Supported	
Intel VT-X Technology	Supported	
Intel SMX Technology	Not Supported	
64-bit	Supported	
L1 Data Cache	32 kB x2	
L1 Code Cache	32 kB x2	
L2 Cache	256 kB x2	
L3 Cache	3072 kB	
Hyper-threading	[Enabled]	
Active Process Cores	[All]	
Limit CPUID Maximum	[Disabled]	
Intel Virtualization Technology	[Disabled]	
		→ ←: Select Screen ↑ ↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.		

### Hyper-threading

Enable this field for Windows XP and Linux which are optimized for Hyper-Threading technology. Select disabled for other OSes not optimized for Hyper-Threading technology. When disabled, only one thread per enabled core is enabled.

### Active Process Core

Number of cores to enable in each processor package

### Limit CPUID Maximum

The CPUID instruction of some newer CPUs will return a value greater than 3. The default is Disabled because this problem does not exist in the Windows series operating systems. If you are using an operating system other than Windows, this problem may occur. To avoid this problem, enable this field to limit the return value to 3 or less than 3.

### Intel Virtualization Technology

When this field is set to Enabled, the VMM can utilize the additional hardware capabilities provided by Vanderpool Technology.

## SATA Configuration

This section is used to configure SATA functions.

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Advanced		
SATA Controller(s)	[Enabled]	Enable or disable Device.
SATA Mode Selection	[IDE]	
SATA Test Mode	[Disabled]	
Serial ATA Port 0	Empty	
Software Preserve	Unknown	
Serial ATA Port 1	Empty	
Software Preserve	Unknown	
Serial ATA Port 2	Empty	
Software Preserve	Unknown	
Serial ATA Port 3	Empty	
Software Preserve	Unknown	
		→ ←: Select Screen ↑ ↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit
Version 2.02.1205. Copyright (C) 2010 American Megatrends, Inc.		

### SATA Controller(s)

This field is used to enable or disable the Serial ATA channels.

### SATA Mode Selection

#### IDE Mode

This option configures the Serial ATA drives as Parallel ATA storage devices.

#### AHCI Mode

This option allows the Serial ATA devices to use AHCI (Advanced Host Controller Interface).


#### RAID Mode

This option allows you to create RAID or Intel Matrix Storage configuration on Serial ATA devices.

### SATA Test Mode


This field is used to enable or disable the Serial ATA Test Mode.

## PCH-FW Configuration



## USB Configuration

This section is used to configure USB.



### Legacy USB Support

#### Enabled

Enables legacy USB.

#### Auto

Disables support for legacy when no USB devices are connected.

#### Disabled

Keeps USB devices available only for EFI applications.

### EHCI Hand-off

This is a workaround for OSes that does not support EHCI hand-off. The EHCI ownership change should be claimed by the EHCI driver.

### USB transfer time-out

The time-out value for Bulk and Interrupt transfers.

### Device reset time-out


Selects the USB mass storage device start unit command timeout.




### Device power-up delay

Maximum time the device will take before it properly reports itself to the Host Controller. "Auto" uses default value: for a Root port it is 100 ms, for a Hub port the delay is taken from Hub descriptor.

### Network Stack



### CPU PPM Configuration




### EIST

This field is used to enable or disable the Intel Enhanced SpeedStep Technology.

### Turbo Mode

The options are Enabled and Disabled.

## WatchDog Configuration



### WatchDog function

This field is used to enable or disable the Watchdog timer function.

### Watchdog 1 function


For HR908-B module board (Reset HR908-B by hardware)

### Watchdog 2 function

For carrier board usage.

## Chipset

Configures relevant chipset functions.



## PCH-IO Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Chipset		
Intel PCH RC Version	1.1.0.0	PCI Express Configuration settings.
Intel PCH SKU Name	QM67	
Intel PCH Rev ID	05/B3	
▶ PCI Express Configuration ▶ USB Configuration ▶ PCH Azalia Configuration		
PCH LAN Controller	[Enabled]	
Wake on LAN	[Enabled]	
After G3	[Power on]	→ ←: Select Screen ↑ ↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.		

### PCH LAN Controller

Enable or disable the PCH LAN Controller.

### Wake on LAN Enable

Set this field to Enabled to wake up the system via the onboard LAN or via a LAN card that supports the remote wake up function.

### After G3

#### Power Off / WOL

Power-on the system via WOL after G3.

#### Power On

Power-on the system after G3.

## PCI Express Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.	
Chipset	
PCI Express Configuration	Enable or Disable PCI Express Clock Gating for each root port.
PCI Express Clock Gating [Enabled]	
▶ PCI Express Root Port 1 ▶ PCI Express Root Port 5 ▶ PCI Express Root Port 6 ▶ PCI Express Root Port 7 PCIE Port 8 is assigned to LAN	
	→ ←: Select Screen ↑ ↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.	

### PCI Express Clock Gating

Enables or disables PCI Express Clock Gating for each root port.

### PCI Express Root Port 1, port 5 to PCI Express Root Port 7

Controls the PCI Express Root Port.

## USB Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Chipset		
USB Configuration		Control the USB EHCI (USB2.0) functions. One EHCI controller must always be enabled.
EHCI1	[Enable]	
EHCI2	[Enabled]	
		→ ←: Select Screen ↑ ↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.		

### EHCI1 and EHCI2

These fields are used to enable or disable USB 2.0.

## PCH Azalia Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Chipset		
PCH Azalia Configuration		Control detection of the Azalia device. Disable= Azalia will be unconditionally disabled. Enabled= Azalia will be unconditionally enabled. Auto=Azalia will be enabled if present, disabled otherwise.
Azalia	[Auto]	
Azalia Internal HDMI Codec	[Enabled]	
Azalia HDMI Codec port B	[Enabled]	
Azalia HDMI Codec port C	[Enabled]	
Azalia HDMI Codec port D	[Enabled]	
		→ ←: Select Screen ↑ ↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.		

### Azalia internal HDMI codec

Enable or disable the internal HDMI codec for Azalia.

## System Agent (SA) Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Chipset		
System Agent Bridge Name	IvyBridge	Config Graphics settings.
System Agent RC Version	1.1.0.0	
VT-d Capability	Unsupported	
<ul style="list-style-type: none"> <li>► Graphics Configuration</li> <li>► NB PCIe Configuration</li> <li>► Memory Configuration</li> </ul>		
		→ ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.		

## Graphics Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Chipset		
Graphics Configuration		Select which of IGFX/PEG/PCI Graphics device should be Primary Display or select SG for Switchable Gfx.
IGFX VBIOS Version	2126	
IGfx Frequency	350 MHz	
Primary Display	[Auto]	
DVMT Total Gfx Mem	[256M]	
► LCD Control		
		→ ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.		

## Primary Display

**Auto** When the system boots, it will auto detects the display device.

**IGFX** When the system boots, it will first initialize the onboard VGA.

**PEG** When the system boots, it will first initialize the PCI Express x16 graphics card.

## DVMT Total Gfx Mem

Select DVMT5.0 total graphic memory size used by the internal graphics device.

## LCD Control

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Chipset		
<b>LCD Control</b> Primary IGFX Boot Display [VBIOS Default] LCD Panel Type [VBIOS Default]		Select the Video Device which will be activated during POST. This has no effect if external graphics present. Secondary boot display selection will appear based on your selection. VGA modes will be supported only on primary display.
		→ ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.		

### LCD Panel Type

Select LCD panel used by Internal Graphics Device by selecting the appropriate setup item.

## NB PCIe Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Chipset		
<b>NB PCIe Configuration</b> <b>PEG0</b> PEG0 - Gen X [Gen1] Enable PEG [Auto]		Not Present Configure PEG0 B0:D1:F0 Gen1-Gen3.
		→ ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit
Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.		

### Enabled PEG

To enable or disable the PEG.

## Memory Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.		
Chipset		
Memory Information		DDR3 or DDR3L selection.
Memory RC Version	1.1.0.0	
Memory Frequency	1600 Mhz	
Total Memory	4096 MB (DDR3)	
DIMM#1	4096 MB (DDR3)	
CAS Latency (tCL)	11	
Minimum delay time		
CAS to RAS (tRCDmin)	11	
Row Precharge (tRPmin)	11	
Active to Precharge (tRASmin)	28	
DDR Selection	[DDR3]	→ ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

## DDR Selection


Intel Ivy Bridge mobile CPU supports DDR3/DDR3L.  
 Intel Sandy Bridge mobile CPU only supports DDR3.

## NB PCIe Bifurcation Configuration

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.	
Chipset	
NB PCIe Bifurcation Configuration	
PEG Bifurcation	PEG bifurcation configuration.
[x16]	
<div>           PEG Bifurcation            x8, x4, x4            Reserved            x8, x8            x16         </div>	→ ←: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

## Boot



### Bootup NumLock State

This allows you to determine the default state of the numeric keypad. By default, the system boots up with NumLock on wherein the function of the numeric keypad is the number keys. When set to Off, the function of the numeric keypad is the arrow keys.


### Quiet Boot

Enables or disables the quiet boot option.

### Fast Boot

Enables or disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.

## CSM Parameters



### Launch PXE OpROM policy

Controls the execution of UEFI and legacy PXE OpROM.

### Launch Storage OpROM policy

Controls the execution of UEFI and legacy storage OpROM.



## Security

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
<b>Password Description</b> If ONLY the Administrator's password is set, then this only limits access to Setup and is only asked for when entering Setup. If ONLY the User's password is set, then this is a power on password and must be entered to boot or enter Setup. In Setup the User will have Administrator rights. The password length must be in the following range: Minimum length 3 Maximum length 20 Administrator Password User Password		Set Administrator Password.  → ←: Select Screen ↑ ↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit			

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

### Administrator Password

Sets the administrator password.

### User Password

Sets the user password.

## Save & Exit

Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.					
Main	Advanced	Chipset	Boot	Security	Save & Exit
<b>Save Changes and Reset</b> Discard Changes and Reset  Restore Defaults Save as User Defaults Restore User Defaults  <b>Boot Override</b> Launch EFI Shell from filesystem device		Reset the system after saving the changes.  ← →: Select Screen ↑ ↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults ESC: Exit			

Version 2.14.1219. Copyright (C) 2011 American Megatrends, Inc.

### Save Changes and Reset

To save the changes, select this field and then press <Enter>. A dialog box will appear. Select Yes to reset the system after saving all changes made.

### Discard Changes and Reset

To discard the changes, select this field and then press <Enter>. A dialog box will appear. Select Yes to reset the system setup without saving any changes.

### Restore Defaults

To restore and load the optimized default values, select this field and then press <Enter>. A dialog box will appear. Select Yes to restore the default values of all the setup options.

### Save as User Defaults

To save changes done so far as user default, select this field and then press <Enter>. A dialog box will appear. Select Yes to save values as user default.

### Restore User Defaults

To restore user default to all the setup options, select this field and then press <Enter>. A dialog box will appear. Select Yes to restore user default.

## Clear Administrator or User Password


**Note:**

Using the “Restore Default” function in the “Save & Exit” screen will not clear the old password. Make sure to follow the steps below.

If you forgot the administrator or user password, follow the steps below to clear the old password.

1. Power-off the system or turn off the power supply.
2. Set the Clear CMOS jumper to “Clear CMOS” mode. Wait for a few seconds and set the jumper back to its default setting.
3. Power-on the system. When the “CMOS Checksum Error” message appears, press <Delete> to enter the BIOS.
4. Select “Save & Exit”. In the “Save & Exit” screen, select “Save Change & Reset” and then press Enter.

## Updating the BIOS

To update the BIOS, you will need the new BIOS file and a flash utility, AFUDOS.EXE. Please contact technical support or your sales representative for the files.

To execute the utility, type:

A:> AFUDOS BIOS\_File\_Name /b /p /n  
then press <Enter>.

```
C:\AFU\AFUDOS>afudos filename /B /P /N

+-----+
|               AMI Firmware Update Utility(APTIO) v2.25               |
|               Copyright (C)2008 American Megatrends Inc. All Rights Reserved.               |
+-----+

Reading file ..... done
Erasing flash ..... done
Writing flash ..... done
Verifying flash ..... done
Erasing BootBlock ..... done
Writing BootBlock ..... done
Verifying BootBlock ..... done

C:\AFU\AFUDOS>
```

After finishing BIOS update, please turn off the AC power. Wait about 10 seconds and then turn on the AC power again.

## Notice: BIOS SPI ROM

1. The Intel® Management Engine has already been integrated into this system board. Due to the safety concerns, the BIOS (SPI ROM) chip cannot be removed from this system board and used on another system board of the same model.
2. The BIOS (SPI ROM) on this system board must be the original equipment from the factory and cannot be used to replace one which has been utilized on other system boards.
3. If you do not follow the methods above, the Intel® Management Engine will not be updated and will cease to be effective.


**Note:**

- a. You can take advantage of flash tools to update the default configuration of the BIOS (SPI ROM) to the latest version anytime.
- b. When the BIOS IC needs to be replaced, you have to populate it properly onto the system board after the EEPROM programmer has been burned and follow the technical person's instructions to confirm that the MAC address should be burned or not.



## Chapter 5 - Supported Software

The CD that came with the system board contains drivers, utilities and software applications required to enhance the performance of the system board.

Insert the CD into a CD-ROM drive. The autorun screen (Mainboard Utility CD) will appear. If after inserting the CD, "Autorun" did not automatically start (which is, the Mainboard Utility CD screen did not appear), please go directly to the root directory of the CD and double-click "Setup".



## Auto Run Pages (for Windows 7)



## Microsoft .NET Framework 3.5 (for Windows XP only)



**Note:**

Before installing Microsoft .NET Framework 3.5, make sure you have updated your Windows XP operating system to Service Pack 3.


To install the driver, click “Microsoft .NET Framework 3.5” on the main menu.

1. Read the license agreement carefully.


Click “I have read and accept the terms of the License Agreement” then click Install.



2. Setup is now installing the driver.



3. Click Exit.



## Intel Chipset Device Software

The Intel Chipset Device Software is used for updating Windows® INF files so that the Intel chipset can be recognized and configured properly in the system.

To install the utility, click “Intel Chipset Device Software” on the main menu.

1. Setup is ready to install the utility. Click Next.



2. Read the license agreement then click Yes.



3. Go through the readme document for more installation tips then click Next.



4. After all setup operations are done, click Next.



5. Click “Yes, I want to restart this computer now” then click Finish.


Restarting the system will allow the new software installation to take effect.



## Intel HD Graphics Drivers (for Windows 7)

To install the driver, click “Intel HD Graphics Drivers” on the main menu.


1. Setup is now ready to install the graphics driver. Click Next.




By default, the “Automatically run WinSAT and enable the Windows Aero desktop theme” is enabled. With this enabled, after installing the graphics driver and the system rebooted, the screen will turn blank for 1 to 2 minutes (while WinSAT is running) before the Windows Vista desktop appears. The “blank screen” period is the time Windows is testing the graphics performance.

We recommend that you skip this process by disabling this function then click Next.


2. Read the license agreement then click Yes.



3. Go through the readme document for system requirements and installation tips then click Next.




4. Setup is now installing the driver. Click Next to continue.



5. Click “Yes, I want to restart this computer now” then click Finish.

Restarting the system will allow the new software installation to take effect.




## Intel HD Graphics Drivers (for Windows XP)



**Note:**

Before installing Intel HD Graphics Drivers, make sure you have installed Microsoft .NET Framework 3.5 SP1.


1. Setup is ready to install the graphics driver. Click Next.




2. Read the license agreement then click Yes.



3. Go through the readme document for more installation tips then click Next.




4. Setup is currently installing the driver. After installation has completed, click Next.



5. Click "Yes, I want to restart this computer now." then click Finish.

Restarting the system will allow the new software installation to take effect.







## Intel Management Engine Drivers

To install the driver, click "Intel Management Engine Drivers" on the main menu.


1. Setup is ready to install the driver. Click Next.




2. Read the license agreement then click Yes.



3. Setup is currently installing the driver. After installation has completed, click Next.




4. After completing installation, click Finish.



## Audio Drivers (for COM331-B Carrier Board)


To install the driver, click “Audio Drivers (for COM331-B Carrier Board)” on the main menu.

1. Setup is now ready to install the audio driver. Click Next.
2. Follow the remainder of the steps on the screen; clicking “Next” each time you finish a step.



3. Click “Yes, I want to restart my computer now” then click Finish.


Restarting the system will allow the new software installation to take effect.



## Intel LAN Drivers

To install the driver, click “Intel LAN Drivers” on the main menu.


1. Setup is ready to install the driver. Click Install Drivers and Software.




2. Setup is now ready to install the LAN driver. Click Next.




3. Click “I accept the terms in the license agreement” then click “Next”.




4. Select the program features you want installed then click Next.



5. Click Install to begin the installation.



6. After completing installation, click Finish.



## DFI Utility


DFI Utility provides information about the board, HW Health, Watchdog, DIO, and Backlight. To access the utility, click “DFI Utility” on the main menu.




### Note:

If you are using Windows 7, you need to access the operating system as an administrator to be able to install the utility.


1. Setup is ready to install the DFI Utility driver. Click “Next”.




2. Click “I accept the terms in the license agreement” then click “Next”.




3. Enter "User Name" and "Organization" information then click "Next".



4. Click Install to begin the installation.



5. After completing installation, click Finish.




The DFI Utility icon will appear on the desktop. Double-click the icon to open the utility.




## Microsoft DirectX 9.0C Driver (for Windows XP only)

To install the utility, click “Microsoft DirectX 9.0C Driver” on the main menu.


1. Click “I accept the agreement” then click Next.



2. To start installation, click Next.



3. Click Finish. Reboot the system for DirectX to take effect.



## Intel Rapid Storage Technology


The Intel Rapid Storage Technology is a utility that allows you to monitor the current status of the SATA drives. It enables enhanced performance and power management for the storage subsystem.

To install the driver, click “Intel Rapid Storage Technology” on the main menu.



**Note:**  
Windows Vista is not supported.

1. Setup is now ready to install the utility. Click Next.




2. Read the warning then click Yes.




3. Read the license agreement then click Yes.



4. Go through the readme document for system requirements and installation tips then click Next.




5. Setup is now installing the utility. Click Next to continue.



6. Click "Yes, I want to restart my computer now" then click Finish.

Restarting the system will allow the new software installation to take effect.



7. Run the Intel Matrix Storage Console utility to view the hard drives' configuration.




## Intel Turbo Boost Monitor (for Windows 7 only)

To install the driver, click “Intel Turbo Boost Monitor” on the main menu.

1. The setup program is configuring the new software installation.



2. Click Next.



3. Read the license agreement and then click “I accept the terms in the license agreement”. Click Next.



## F6 Floppy

This is used to create a floppy driver diskette needed when you install Windows® XP using the F6 installation method. This will allow you to install the operating system onto a hard drive when in AHCI mode.

1. Insert a blank floppy diskette.
2. Locate for the drivers in the CD then copy them to the floppy diskette. The CD includes drivers for both 32-bit and 64-bit operating systems. The path to the drivers are shown below.

32-bit

CD Drive:\AHCI\_RAID\F6FLOPPY\6flpy32

64-bit


CD Drive:\AHCI\_RAID\F6FLOPPY\6flpy64




## Adobe Acrobat Reader 9.3

To install the reader, click “Adobe Acrobat Reader 9.3” on the main menu.


1. Click Next to install or click Change Destination Folder to select another folder.



2. Click Install to begin installation.



3. Click Finish to exit installation.





## Appendix A - NLITE and AHCI Installation Guide

### nLite

nLite is an application program that allows you to customize your XP installation disc by integrating the RAID/AHCI drivers into the disc. By using nLite, the F6 function key usually required during installation is no longer needed.


**Note:**

The installation steps below are based on nLite version 1.4.9. Installation procedures may slightly vary if you're using another version of the program.

1. Download the program from nLite's official website.

<http://www.nliteos.com/download.html>


2. Install nLite.


**Important:**

Due to it's coding with Visual.Net, you may need to first install .NET Framework prior to installing nLite.


3. Download relevant RAID/AHCI driver files from Intel's website. The drivers you choose will depend on the operating system and chipset used by your computer.

The downloaded driver files should include iaahci.cat, iaAHCI.inf, iastor.cat, iaStor.inf, iaStor.sys, license.txt and TXTSETUP.OEM.




4. Insert the XP installation disc into an optical drive.

5. Launch nLite. The Welcome screen will appear. Click Next.




6. Click Next to temporarily save the Windows installation files to the designated default folder.


If you want to save them in another folder, click Browse, select the folder and then click Next.




7. Click Next.



8. In the Task Selection dialog box, click Drivers and Bootable ISO. Click Next.




9. Click Insert and then select Multiple driver folder to select the drivers you will integrate. Click Next.




10. Select only the drivers appropriate for the Windows version that you are using and then click OK.

Integrating 64-bit drivers into 32-bit Windows or vice versa will cause file load errors and failed installation.






15. To create an image, select the Create Image mode under the General section and then click Next.




16. Or you can choose to burn it directly to a disc by selecting the Direct Burn mode under the General section and then click Next.

Select the optical device and all other necessary settings and then click Next.



17. You have finished customizing the Windows XP installation disc. Click Finish.

Enter the BIOS utility to configure the SATA controller to RAID/AHCI. You can now install Windows XP.




**AHCI**

The installation steps below will guide you in configuring your SATA drive to AHCI mode.


1. Enter the BIOS utility and configure the SATA controller to IDE mode.
2. Install Windows XP but do not press F6.
3. Download relevant RAID/AHCI driver files supported by the motherboard chipset from Intel's website.

Transfer the downloaded driver files to C:\AHCI.



4. Open Device Manager and right click on one of the Intel Serial ATA Storage Controllers, then select Update Driver.


If the controller you selected did not work, try selecting another one.




5. In the Hardware Update Wizard dialog box, select "No, not this time" then click Next.




6. Select "Install from a list or specific location (Advanced)" and then click Next.




7. Select "Don't search. I will choose the driver to install" and then click Next.




8. Click "Have Disk".




9. Select C:\AHCI\iaAHCI.inf and then click Open.



10. Select the appropriate AHCI Controller of your hardware device and then click Next.




11. A warning message appeared because the selected SATA controller did not match your hardware device.



Ignore the warning and click Yes to proceed.


12. Click Finish.



13. The system's settings have been changed. Windows XP requires that you restart the computer. Click Yes.



14. Enter the BIOS utility and modify the SATA controller from IDE to AHCI. By doing so, Windows will work normally with the SATA controller that is in AHCI mode.



## Appendix B - Watchdog Sample Code

```
#include <stdio.h>
//-----
#define EC_EnablePort 0x66
#define EC_DataPort 0x62
//-----
void WriteEC(char,int);
void SetWDTime(int,int);
int GetWDTime(void);
//-----
main()
{
    unsigned int countdown;
    unsigned int input,count_h,count_l;

    printf("Input WD Time: ");
    scanf("%d",&input);
    printf("\n");
    count_h=input>>8;
    count_l=input&0x00FF;
    SetWDTime(count_h,count_l);

    while(1)
    {
        countdown = GetWDTime();
        delay(100);
        printf("\rTime Remaining: %d ",countdown);
    }
}
//-----
void SetWDTime(int count_H,int count_L)
{
    //Set Count
    WriteEC(0xB7,count_H); //High Byte
    WriteEC(0xB8,count_L); //Low Byte
    //Enable Watch Dog Timer
    WriteEC(0xB4,0x02);
}
//-----
```

```
int GetWDTime(void)
{
    int sum,data_h,data_l;
    //Select EC Read Type
    outportb(EC_EnablePort,0x80);
    delay(5);
    //Get Remaining Count High Byte
    outportb(EC_DataPort,0xF6);
    delay(5);
    data_h=inportb(EC_DataPort);
    delay(5);
    //Select EC Read Type
    outportb(EC_EnablePort,0x80);
    delay(5);
    //Get Remaining Count Low Byte
    outportb(EC_DataPort,0xF7);
    delay(5);
    data_l=inportb(EC_DataPort);
    delay(5);

    data_h<=8;
    data_h&=0xFF00;
    sum=data_h|data_l;
    return sum;
}
//-----
void WriteEC(char EC_Addr, int data)
{
    //Select EC Write Type
    outportb(EC_EnablePort,0x81);
    delay(5);
    outportb(EC_DataPort,EC_Addr);
    delay(5);
    outportb(EC_DataPort,data);
    delay(5);
}
//-----
```

## Appendix C - System Error Message

When the BIOS encounters an error that requires the user to correct something, either a beep code will sound or a message will be displayed in a box in the middle of the screen and the message, PRESS F1 TO CONTINUE, CTRL-ALT-ESC or DEL TO ENTER SETUP, will be shown in the information box at the bottom. Enter Setup to correct the error.

### Error Messages

One or more of the following messages may be displayed if the BIOS detects an error during the POST. This list indicates the error messages for all Awards BIOSes:

#### CMOS BATTERY HAS FAILED

The CMOS battery is no longer functional. It should be replaced.

**Important:**

Danger of explosion if battery incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the battery manufacturer's instructions.

#### CMOS CHECKSUM ERROR

Checksum of CMOS is incorrect. This can indicate that CMOS has become corrupt. This error may have been caused by a weak battery. Check the battery and replace if necessary.

#### DISPLAY SWITCH IS SET INCORRECTLY

The display switch on the motherboard can be set to either monochrome or color. This indicates the switch is set to a different setting than indicated in Setup. Determine which setting is correct, either turn off the system and change the jumper or enter Setup and change the VIDEO selection.



## Appendix D - Troubleshooting

### Troubleshooting Checklist

This chapter of the manual is designed to help you with problems that you may encounter with your personal computer. To efficiently troubleshoot your system, treat each problem individually. This is to ensure an accurate diagnosis of the problem in case a problem has multiple causes.

Some of the most common things to check when you encounter problems while using your system are listed below.

1. The power switch of each peripheral device is turned on.
2. All cables and power cords are tightly connected.
3. The electrical outlet to which your peripheral devices are connected is working. Test the outlet by plugging in a lamp or other electrical device.
4. The monitor is turned on.
5. The display's brightness and contrast controls are adjusted properly.
6. All add-in boards in the expansion slots are seated securely.
7. Any add-in board you have installed is designed for your system and is set up correctly.

### Monitor/Display

#### If the display screen remains dark after the system is turned on:

1. Make sure that the monitor's power switch is on.
2. Check that one end of the monitor's power cord is properly attached to the monitor and the other end is plugged into a working AC outlet. If necessary, try another outlet.
3. Check that the video input cable is properly attached to the monitor and the system's display adapter.
4. Adjust the brightness of the display by turning the monitor's brightness control knob.

#### The picture seems to be constantly moving.

1. The monitor has lost its vertical sync. Adjust the monitor's vertical sync.
2. Move away any objects, such as another monitor or fan, that may be creating a magnetic field around the display.
3. Make sure your video card's output frequencies are supported by this monitor.

#### The screen seems to be constantly wavering.

1. If the monitor is close to another monitor, the adjacent monitor may need to be turned off. Fluorescent lights adjacent to the monitor may also cause screen wavering.

### Power Supply

#### When the computer is turned on, nothing happens.

1. Check that one end of the AC power cord is plugged into a live outlet and the other end properly plugged into the back of the system.
2. Make sure that the voltage selection switch on the back panel is set for the correct type of voltage you are using.
3. The power cord may have a "short" or "open". Inspect the cord and install a new one if necessary.

## Hard Drive

### Hard disk failure.

1. Make sure the correct drive type for the hard disk drive has been entered in the BIOS.
2. If the system is configured with two hard drives, make sure the bootable (first) hard drive is configured as Master and the second hard drive is configured as Slave. The master hard drive must have an active/bootable partition.

### Excessively long formatting period.

If your hard drive takes an excessively long period of time to format, it is likely a cable connection problem. However, if your hard drive has a large capacity, it will take a longer time to format.

## Serial Port

### The serial device (modem, printer) doesn't output anything or is outputting garbled characters.

1. Make sure that the serial device's power is turned on and that the device is on-line.
2. Verify that the device is plugged into the correct serial port on the rear of the computer.
3. Verify that the attached serial device works by attaching it to a serial port that is working and configured correctly. If the serial device does not work, either the cable or the serial device has a problem. If the serial device works, the problem may be due to the onboard I/O or the address setting.
4. Make sure the COM settings and I/O address are configured correctly.

## Keyboard

### Nothing happens when a key on the keyboard was pressed.

1. Make sure the keyboard is properly connected.
2. Make sure there are no objects resting on the keyboard and that no keys are pressed during the booting process.

## System Board

1. Make sure the add-in card is seated securely in the expansion slot. If the add-in card is loose, power off the system, re-install the card and power up the system.
2. Check the jumper settings to ensure that the jumpers are properly set.
3. Verify that all memory modules are seated securely into the memory sockets.
4. Make sure the memory modules are in the correct locations.
5. If the board fails to function, place the board on a flat surface and seat all socketed components. Gently press each component into the socket.
6. If you made changes to the BIOS settings, re-enter setup and load the BIOS defaults.