

MIO-5375

**11th Gen. Intel® Core™ i7/i5/i3/
Celeron U-Series 3.5" SBC w/ MIOe**

ADVANTECH

Enabling an Intelligent Planet

Copyright

The documentation and the software included with this product are copyrighted 2021 by Advantech Co., Ltd. All rights are reserved. Advantech Co., Ltd. reserves the right to make improvements in the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated or transmitted in any form or by any means without the prior written permission of Advantech Co., Ltd. Information provided in this manual is intended to be accurate and reliable. However, Advantech Co., Ltd. assumes no responsibility for its use, nor for any infringements of the rights of third parties, which may result from its use.

Acknowledgments

Intel® is a trademark of Intel® Corporation.

AMI is a trademark of American Megatrends, Inc.

IBM, PC, PS/2 and VGA are trademarks of International Business Machines Corporation.

Microsoft Windows®, DirectX® is a registered trademark of Microsoft Corp.

All other product names or trademarks are properties of their respective owners.

For more information on this and other Advantech products, please visit our websites at:

<http://www.advantech.com>

<http://www.advantech.com/eplatform>

For technical support and service, please visit our support website at:

<http://support.advantech.com/>

This manual is for the MIO-5375.

Product Warranty (2 years)

Advantech warrants to you, the original purchaser, that each of its products will be free from defects in materials and workmanship for two years from the date of purchase.

This warranty does not apply to any products which have been repaired or altered by persons other than repair personnel authorized by Advantech, or which have been subject to misuse, abuse, accident or improper installation. Advantech assumes no liability under the terms of this warranty as a consequence of such events.

Because of Advantech's high quality-control standards and rigorous testing, most of our customers never need to use our repair service. If an Advantech product is defective, it will be repaired or replaced at no charge during the warranty period. For out-of-warranty repairs, you will be billed according to the cost of replacement materials, service time and freight. Please consult your dealer for more details.

If you think you have a defective product, follow these steps:

1. Collect all the information about the problem encountered. (For example, CPU speed, Advantech products used, other hardware and software used, etc.) Note anything abnormal and list any onscreen messages you get when the problem occurs.
2. Call your dealer and describe the problem. Please have your manual, product, and any helpful information readily available.
3. If your product is diagnosed as defective, obtain an RMA (return merchandise authorization) number from your dealer. This allows us to process your return more quickly.
4. Carefully pack the defective product, a fully-completed Repair and Replacement Order Card and a photocopy proof of purchase date (such as your sales receipt) in a shippable container. A product returned without proof of the purchase date is not eligible for warranty service.
5. Write the RMA number visibly on the outside of the package and ship it prepaid to your dealer.

Declaration of Conformity

CE

This product has passed the CE test for environmental specifications. Test conditions for passing included the equipment being operated within an industrial enclosure. In order to protect the product from being damaged by ESD (Electrostatic Discharge) and EMI leakage, we strongly recommend the use of CE-compliant industrial enclosure products.

FCC Class B

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution! *There is a danger of a new battery exploding if it is incorrectly installed. Do not attempt to recharge, force open, or heat the battery. Replace the battery only with the same or equivalent type recommended by the manufacturer. Discard used batteries according to the manufacturer's instructions.*



Technical Support and Assistance

1. Visit the Advantech website at <http://support.advantech.com> where you can find the latest information about the product.
2. Contact your distributor, sales representative, or Advantech's customer service center for technical support if you need additional assistance. Please have the following information ready before you call:
 - Product name and serial number
 - Description of your peripheral attachments
 - Description of your software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

Packing List

Before you begin installing your card, please make sure that the following materials have been shipped:

- 1 x MIO-5375 SBC
- 1 x SATA Cable 30cm (p/n: 1700006291)
- 1 x SATA Power Cable 35cm (p/n: 1700031583-01)
- 1 x USB2.0 Cable 20cm (p/n: 1700030406-01)
- 1 x Audio Cable 20cm (p/n: 1700019584-01)
- 2 x COM RS-232/422/485 Cable 20cm (p/n: 1700030404-01)
- 2 x COM RS-232 Cable 20cm (p/n: 1700031582-01)
- 1 x Cooler (Heatsink) (p/n: 1970004884T001, (1970004794T001))
- 1 x Startup manual (p/n: 2046537500)
- 1 x Mini Jumper(10pcs package)
- 1 x Screw Kit (2sets screws and post for M.2 device & 4sets of screws and stand-off)
- 1 x DeviceOn Package

If any of these items are missing or damaged, contact your distributor or sales representative immediately.

Optional MIOe Module

Part Number	Description
MIOe-260L-00A1	Dual Intel GbE with M.2 B-key & F/S miniPCle
MIOE-210-D6A1E	4 x RS232/422/485, 2 x RS422/485, 8-bit GPIO
MIOe-220-B3A1E	3 x Intel® Gigabit Ethernet with PCle Switch
MIOe-230-L0A1E	48-bit LVDS or DisplayPort, 2 x USB 2.0

Optional Accessories

Part number	Description
1970004833N001	Heat spreader of MIO-5375

Contents

Chapter 1	General Information	1
1.1	Introduction	2
1.2	Specifications	2
1.3	Block Diagram	4
Chapter 2	Mechanical	5
2.1	Introduction	6
2.2	Board Layout: Dimensions	6
	Figure 2.1 MIO-5375 Mechanical Drawing (Top Side)	6
	Figure 2.2 MIO-5375 Mechanical Drawing (Bottom Side)	7
	Figure 2.3 MIO-5375 Mechanical Drawing (Coastline)	7
	Figure 2.4 MIO-5375 Mechanical Drawing (with Cooler)	8
	Figure 2.5 MIO-5375 Mechanical Drawing (with Heatsink)	8
	Figure 2.6 MIO-5375 Mechanical Drawing (with Heat Spreader)	9
2.3	Quick Installation Guide	9
2.3.1	Cooler	9
2.3.2	Heatsink	10
2.3.3	Heatspreader (Option)	10
Chapter 3	Installation	11
3.1	Jumpers & Switches	12
	Table 3.1: Jumpers & Switches	12
3.2	Connectors	12
	Table 3.2: Connectors	12
3.3	Locating connectors	13
	Figure 3.1 MIO-5375 Connector Locations (Top Side)	13
	Figure 3.2 MIO-5375 Connector Locations (Bottom Side)	13
3.4	Setting Jumpers	14
3.4.1	Auto Power On / Load BIOS default (J3)	14
	Table 3.3: Auto Power On / Load BIOS default (J3)	14
3.4.2	LCD Power (VDD1)	15
	Table 3.4: LCD Power (VDD1)	15
3.4.3	CN11 12V Power Input	15
	Table 3.5: CN11 12V Power Input	15
3.4.4	DIMM1 SODIMM DDR4_260 9.2mm	15
	Table 3.6: DIMM1 SODIMM DDR4_260 9.2mm	15
3.4.5	DIMM2 SODIMMDDR4_260 5.2mm	16
	Table 3.7: DIMM2 SODIMMDDR4_260 5.2mm	16
3.4.6	Battery1 RTC Battery	16
	Table 3.8: Battery1 RTC Battery	16
3.4.7	CN4 CAN Bus	16
	Table 3.9: CN4 CAN Bus	16
3.4.8	CN5 Front Panel	17
	Table 3.10: CN5 Front Panel	17
3.4.9	AUDIO1 Audio	17
	Table 3.11: AUDIO1 Audio	17
3.4.10	CN8 I2C	18
	Table 3.12: CN8 I2C	18
3.4.11	COM1	18
	Table 3.13: COM1	18
3.4.12	COM2	19

	Table 3.14: COM2	19
3.4.13	COM3	19
	Table 3.15: COM3	19
3.4.14	COM4	20
	Table 3.16: COM4	20
3.4.15	CN7 GPIO.....	20
	Table 3.17: CN7 GPIO	20
3.4.16	LAN1 RJ45_2x1_W/XFMR&LED.....	21
	Table 3.18: LAN1 RJ45_2x1_W/XFMR&LED	21
3.4.17	BL1 Inverter Power Output.....	21
	Table 3.19: BL1 Inverter Power Output.....	21
3.4.18	LVDS1 48-bit LVDS Panel.....	22
	Table 3.20: LVDS1 48-bit LVDS Panel	22
3.4.19	EDP1 eDP (option).....	24
	Table 3.21: EDP1 eDP (option).....	24
3.4.20	HDMI.....	26
	Table 3.22: HDMI	26
3.4.21	M2_1 M.2 E key.....	26
	Table 3.23: M2_1 M.2 E key	26
3.4.22	M2_2 M.2 M key	27
	Table 3.24: M2_2 M.2 M key.....	28
3.4.23	M2_3 M.2 B key.....	29
	Table 3.25: M2_3 M.2 B key	30
3.4.24	SIM NANO SIM.....	31
	Table 3.26: SIM NANO SIM	32
3.4.25	USB1 USB3.0_13H	32
	Table 3.27: USB1 USB3.0_13H	32
3.4.26	USB2 USB3.0_13H	32
	Table 3.28: USB2 USB3.0_13H	32
3.4.27	USB3 Internal USB	32
	Table 3.29: USB3 Internal USB.....	32
3.4.28	SATAP1 SATA Power	33
	Table 3.30: SATAP1 SATA Power	33
3.4.29	SATA1 SATA_7V.....	33
	Table 3.31: SATA1 SATA_7V	33
3.4.30	CN10 Smart Fan.....	33
	Table 3.32: CN10 Smart Fan	33
3.4.31	MIOE MIOe.....	34
	Table 3.33: MIOE MIOe	34

Chapter 4 AMI BIOS Setup..... 37

4.1	Entering Setup	39
4.1.1	Main Setup.....	39
4.1.2	Advanced BIOS Features Setup.....	40
4.1.3	Chipset Configuration	62
4.1.4	Security.....	73
4.1.5	Boot	74
4.1.6	Save & Exit	75

Appendix A System Assignments..... 77

A.1	System I/O Ports.....	78
	Table A.1: System I/O Ports	78
A.2	DMA Channel Assignments	79
	Table A.2: DMA Channel Assignments	79
A.3	1st MB Memory Map.....	79
	Table A.3: 1st MB Memory Map	79
A.4	Interrupt Assignments	79

Table A.4: Interrupt Assignments.....	79
---------------------------------------	----

Chapter 1

General Information

This chapter gives background information on the MIO-5375.

Sections include:

- Introduction
- Specifications
- Block diagram

1.1 Introduction

MIO-5375 is designed using MI/O Extension form factor (compact series, 146 x 102 mm) and powered by 11th generation of Intel® Core™ U series processors. MIO-5375 offers embedded iManager 3.0, SUSI 4.0 and WISE-PaaS/DeviceOn created by Advantech to monitor and control system operation effectively and remotely.


MIO-5375 adopts the latest 64-bit, multi-core processors built on 10nm process technology for improvements in CPU processing, graphics, security and I/O flexibility.

1.2 Specifications

Platform	Processor	i7-1185G7E	i7-1185GRE	i5-1145G7E	i3-1115G4E
	Max. Frequency	4.40 GHz	4.40 GHz	4.10 GHz	3.90 GHz
	Base Frequency	1.80/ 2.8 GHz	1.80/ 2.8 GHz	1.50/ 2.6 GHz	2.20/ 3.0 GHz
	Core/Tread	4/8	4/8	4/8	4/8
	LLC	12MB	12MB	8MB	6MB
	CPU cTDP-down/ Up/ Nominal	12W/ 15W/ 28W	12W/ 15W/ 28W	12W/ 15W/ 28W	12W/ 15W/ 28W
	Chipset	Intel® 300 Series Chipset (SoC Integrated)			
	BIOS	AMI EFI 256Mbit			
Memory	Technology	DDR4-3200			
	Max. Capacity	Up to 64GB			
	Channel/Socket	Dual Channels / 2 Sockets			
	ECC Support	No	Yes	No	No
Graphics	Controller	Integrated GfX Intel®UHD Graphics 630			
	Max. Frequency	3200MT/s	3200MT/s	3200MT/s	3200MT/s
	Graphics Memory	TBU			
	3D/HW Acceleration	DX12, OGL4.0, OCL1.2, HW Encode: H.265/HEVC, H.264, MPEG2, HW Decode: H.264			
Display I/F	LCD	1 x LVDS: Dual Channel 18/24-bit, up to 1920 x 1200			
		Optional eDP1.4 HBR3, up to 4096x2304x36bpp@60Hz or 5120x3200x24bpp@24Hz			
	HDMI/DP	1 x HDMI 2.0b, up to 4Kx2Kx24bpp@60Hz			
		1 x DP1.4a, up to 4096x2304x36bpp@60Hz or 5120x3200x24bpp@60Hz			
	Multiple Display	4 simultaneous displays with each display interface combinations			
External I/O	Ethernet	2 x GbE, LAN1: Intel i219LM, LAN2: Intel i210AT/IT (for industrial grade)			
	HDMI/DP	1/1			
	USB Type-C	1 x USB3.2 Gen. 2x2 20Gbps, support DP1.4a via Alt. Mode			
	USB3.2	4 x USB3.2 Gen. 2x1 10Gbps			
	LED	Power status, SATA R/W			
	Power DC-Jack	Optional			

Internal I/O	SATA	1 x SATA GenIII 6.0 Gbps
	USB2.0	2
	Serial Bus	I2C (support 400Kbit/s), SMBus
	COM Port	2 x RS-232/422/485 (support 1Mbps), 2 x RS-232 (4-wire, support 1Mbps)
	GPIO	8-bit general purpose input output I/O
	Audio	Realtek ALC888, Line-in/Line-out/MIC
	Inverter	12V/5V/3.3V selectable
	LPC/SPI Bus	-
	CAN Bus	1 x CANBus 2.0
	Fan	4-wire smart fan
	Front Panel Control	Power-on, Reset, Buzzer, SATA LED, CaseOpen
Board Feature	Watchdog Timer	65536 level, 0~65535 sec
	TPM	TPM2.0, Infineon SLB9670
	iManager 3.0	SW API for Hardware Monitor, Smart Fan Control, Brightness Control, I2C, GPIO, WDT
Expansion	M.2 E-Key	1 x E-Key 2230 (PCIe x1, USB2.0)
	M.2 B-Key	1 x B-Key 3042 (USB2.0) w/ Nano-SIM
	M.2 M-Key	1 x M-Key 2280 (PCIe x4 Gen.4 for PCIe SSD), optional SATA
MIOe	PClex1 Port 0	Gen3
	PClex1 Port 1	Gen3
	PClex1 Port 2	Gen3
	PClex1 Port 3	Gen3
	PCIe Bifurcation	x1/x2/x4
	DisplayPort	1
	USB3.0	1
	USB2.0	1
	LPC	Support
	eSPI	-
	SMBus	Support
	Line-out	Support
	Power Supply	12V/5V
Power	Supply Voltage	Vin: DC 12V-24V +/- 5%; RTC Battery: Lithium 3V/210mAH
	Connector	ATX 2x2 pin 90D, optional DC-Jack or ATX 2x2 pin 180D
	Power Management	AT, ATX
Environment	Temperature	Operating: Standard: 0 ~ 60° C (32 ~ 140° F), Extend: -40 ~ 85° C (-40 ~ 185° F)
		Storage: -40 ~ 85° C (-40 ~ 185° F)
	Humidity	Operating: 40° C @ 95% relative humidity, non-condensing
		Storage: 60° C @ 95%relative humidity, non-condensing
	Vibration Resistance	3.5 Grms
Software	OS	Windows10, Linux 20.04, Yocto BSP
	Software& API	WISE-DeviceOn, Edge AI Suite, iManager 3.0
Certification	EMC	CE, FCC Class B
Mechanical	Dimensions	146 x 102 mm (5.7" x 4")

1.3 Block Diagram



Chapter 2

Mechanical

This chapter gives mechanical information on the MIO-5375.

Sections include:

- Mechanical Drawing
- Assembly Drawing

2.1 Introduction

The MI/O compact form factor SBC is a new-generation SBC design with a variety of mechanical improvements. Here is the quick installation guide for our thermal design and MIOe module installation.

This chapter includes board dimensions, our standard thermal solution, and MIOe expansion board assembly.

2.2 Board Layout: Dimensions




Figure 2.1 MIO-5375 Mechanical Drawing (Top Side)




Figure 2.2 MIO-5375 Mechanical Drawing (Bottom Side)




Figure 2.3 MIO-5375 Mechanical Drawing (Coastline)





Figure 2.4 MIO-5375 Mechanical Drawing (with Cooler)





Figure 2.5 MIO-5375 Mechanical Drawing (with Heatsink)





Figure 2.6 MIO-5375 Mechanical Drawing (with Heat Spreader)


2.3 Quick Installation Guide

There is a Heatsink/Cooler (or optional heatspreader) in the white box inside the package. Please assemble it by following the diagrams below. Remember to remove the plastic on the thermal pad before you assemble the mechanical parts.


2.3.1 Cooler



2.3.2 Heatsink



2.3.3 Heatspreader (Option)



Chapter 3

Installation

This chapter explains the setup procedures of the MIO-5375 hardware, including instructions on setting jumpers and connecting peripherals, switches and indicators. Be sure to read all safety precautions before you begin the installation procedure.

3.1 Jumpers & Switches

The MIO-5375 has a number of jumpers that allow you to configure your system to suit your application. The table below lists the functions of the various jumpers.

Table 3.1: Jumpers & Switches

J3	AT mode /Load BIOS default
VDD1	LCD Power

3.2 Connectors

Onboard connectors link the MIO-5375 to external devices such as hard disk drives, mouse and keyboard. The table below lists the function of each of the board's connectors.

Table 3.2: Connectors

Label	Function
CN11	Power Input
DIMM1	SO-DIMM 9.2mm
DIMM2	SO-DIMM 5.2mm
Battery1	RTC Battery
CN4	CAN BUS
CN5	Front Panel
AUDIO1	Audio
CN8	I2C
COM1	COM1
COM2	COM2
COM3	COM3
COM4	COM4
CN7	GPIO
LAN1	RJ45_2x1_W/XFMR&LED
BL1	Inverter Power output
LVDS1	48 bit LVDS
EDP1	eDP/MIPI DSI
HDMI1	HDMI
DP1	DP
TYPEC1	TYPEC
M2_1	M.2 E-key
M2_2	M.2 M-key
M2_3	M.2 B-key
SIM	NANO SIM
USB1	USB2.0+3.0_13H
USB2	USB2.0+3.0_13H
USB3	Internal USB2.0
SATAP1	SATA Power
SATA1	SATA_7V
CN10	Smart FAN

3.3 Locating connectors




Figure 3.1 MIO-5375 Connector Locations (Top Side)





Figure 3.2 MIO-5375 Connector Locations (Bottom Side)

3.4 Setting Jumpers

You may configure your card to match the needs of your application by setting jumpers. A jumper is a metal bridge used to close an electric circuit. It consists of two metal pins and a small metal clip (often protected by a plastic cover) that slides over the pins to connect them. To “close” a jumper, you connect the pins with the clip. To “open” a jumper, you remove the clip. Sometimes a jumper will have three pins, labeled 1, 2 and 3. In this case you would connect either pins 1 and 2, or 2 and 3.

The jumper settings are schematically depicted in this manual as follows:



A pair of needle-nose pliers may be helpful when working with jumpers. If you have any doubts about the best hardware configuration for your application, contact your local distributor or sales representative before you make any changes. Generally, you simply need a standard cable to make most connections.

3.4.1 Auto Power On / Load BIOS default (J3)




Table 3.3: Auto Power On / Load BIOS default (J3)

Part Number	1653003260
Footprint	HD_3x2P_79
Description	PIN HEADER 3x2P 2.0mm 180D(M) SMD 21N22050
Setting	Function
(1-2)*	Auto Power On
(3-4)*	Reserve
(5-6)*	Short: Load BIOS default Open: Normal

3.4.2 LCD Power (VDD1)




Table 3.4: LCD Power (VDD1)

Part Number	1653003260
Footprint	HD_3x2P_79
Description	PIN HEADER 3x2P 2.0mm 180D(M) SMD 21N22050
Setting	Function
(1-3)*	+3.3V
(3-5)	+5V
(3-4)	+12V

3.4.3 CN11 12V Power Input




Table 3.5: CN11 12V Power Input

Part Number	1655003865
Footprint	WF_2x2P_165_BOX_RA_D_740SP
Description	ATX PWRCONN 2x2P 4.2mm 90D(M) DIP 740-77-04TS50
Pin	Pin Name
1	GND
2	GND
3	+12V
4	+12V

3.4.4 DIMM1 SODIMM DDR4_260 9.2mm

Table 3.6: DIMM1 SODIMM DDR4_260 9.2mm

Part Number	1651002909-02
Footprint	SODIMMDDR4_260P_AS0A826-HARB
Description	DDR4 SODIMM 260P/0.5mm/LCP/RA/G10u/S/BK/H9.2/RVS
Pin	Pin Name

3.4.5 DIMM2 SODIMMDDR4_260 5.2mm

Table 3.7: DIMM2 SODIMMDDR4_260 5.2mm

Part Number	1651002908-01
Footprint	SODIMMDDR4_260P_AS0A826-H2RB
Description	DDR4 SODIMM H=5.2mm 260P SMD REV. AS0A826-H2RB-7
Pin	Pin Name

3.4.6 Battery1 RTC Battery



Table 3.8: Battery1 RTC Battery

Part Number	1655005427-01
Footprint	WF_2P_49_53398-0271
Description	WAFER 2P 1.25mm 180D(M) SMD 53398-0271
Pin	Pin Name
1	GND
2	VBAT

3.4.7 CN4 CAN Bus



Table 3.9: CN4 CAN Bus

Part Number	1654903500
Footprint	WHL3VS-125M
Description	WAFER 3P 1.25mm 90D(M) SMD 85205-03001
Pin	Pin Name
1	CAN1_D+
2	CAN1_D-
3	GND

3.4.8 CN5 Front Panel




Table 3.10: CN5 Front Panel

Part Number	1653007728-01
Footprint	WF_10P_49_BOX_53398-1071
Description	Wafer 1x10P/1.25mm/PA/M/VA/WH/Sn/H4.7mm/WO
Pin	Pin Name
1	GND
2	BUZZER-
3	BUZZER+
4	RDC_CASEOPEN
5	SATA_EXT_LED#
6	PSIN#
7	RST#
8	HD LED +3.3V
9	NC
10	Power LED +5V

3.4.9 AUDIO1 Audio





Table 3.11: AUDIO1 Audio

Part Number	1653007480-01
Footprint	HD_5X2P_79_BOX_H245
Description	BOXH 2x5P/2.0mm/LCP/M/VA/G10u/S/BK/H4.83/W
Pin	Pin Name
1	LOUTR
2	LINR
3	GND
4	GND
5	LOUTL
6	LINL
7	GND

Table 3.11: AUDIO1 Audio


8	GND
9	MIC1R
10	MIC1L

3.4.10 CN8 I2C

**Table 3.12: CN8 I2C**

Part Number	1655904020
Footprint	FPC4V-125M
Description	WAFER 4P 1.25mm 180D(M) SMD 85205-04001
Pin	Pin Name
1	GND
2	I2C_DAT
3	I2C_CLK
4	+V5_I2C

3.4.11 COM1

**Table 3.13: COM1**

Part Number	1654011262-01
Footprint	DBCOM-VM5MS
Description	D-SUB 9P 2.77mm 90D(M) DIP G/F DSB5-09M1-KNR0-90
Pin	Pin Name
1	NC
2	COM_RI#
3	COM_DTR#
4	COM_CTS#
5	COM_TXD
6	COM_RTS#
7	COM_RXD
8	COM_DSR#
9	COM_DCD#
10	GND

3.4.12 COM2




Table 3.14: COM2

Part Number	1653007728-01
Footprint	WF_10P_49_BOX_53398-1071
Description	Wafer 1x10P/1.25mm/PA/M/VA/WH/Sn/H4.7mm/WO
Pin	Pin Name
1	NC
2	COM_RI#
3	COM_DTR#
4	COM_CTS#
5	COM_TXD
6	COM_RTS#
7	COM_RXD
8	COM_DSR#
9	COM_DCD#
10	GND

3.4.13 COM3




Table 3.15: COM3

Part Number	1655004032
Footprint	WF_5P_49_BOX_85205
Description	WAFER 5P 1.25mm 180D(M) SMD 85205-05701
Pin	Pin Name
1	COM_TXD
2	COM_RTS#
3	COM_RXD
4	COM_CTS#
5	GND

3.4.14 COM4




Table 3.16: COM4

Part Number	1655004032
Footprint	WF_5P_49_BOX_85205
Description	WAFER 5P 1.25mm 180D(M) SMD 85205-05701
Pin	Pin Name
1	COM_TXD
2	COM_RTS#
3	COM_RXD
4	COM_CTS#
5	GND

3.4.15 CN7 GPIO




Table 3.17: CN7 GPIO

Part Number	1653007728-01
Footprint	WF_10P_49_BOX_53398-1071
Description	Wafer 1x10P/1.25mm/PA/M/VA/WH/Sn/H4.7mm/WO
Pin	Pin Name
1	GND
2	P0_GPIO7
3	P0_GPIO2
4	P0_GPIO6
5	P0_GPIO1
6	P0_GPIO5
7	P0_GPIO0
8	P0_GPIO4
9	+5V
10	P0_GPIO3

3.4.16 LAN1 RJ45_2x1_W/XFMR&LED




Table 3.18: LAN1 RJ45_2x1_W/XFMR&LED

Part Number	1652003274
Footprint	RJ45_28P_RTb-ZZ-0044
Description	RJ45 1x2 28P/PA6T/RA/G-FL/D/BK/W TF/W SP/G,O;G

3.4.17 BL1 Inverter Power Output




Table 3.19: BL1 Inverter Power Output

Part Number	1653007388-01
Footprint	WF_5P_79_BOX_D_H240
Description	Wafer 1x5P/2.0mm/NY66+30GF/(M)/VA/Sn/D/WH/H6.1mm
Pin	Pin Name
1	+12V
2	GND
3	ENABKL
4	VBR
5	+5V

3.4.18 LVDS1 48-bit LVDS Panel




Table 3.20: LVDS1 48-bit LVDS Panel

Part Number	1653006918-01
Footprint	SPH20X2
Description	Wafer 2x20P/1.25mm/(M)/NY9T/VA/GFL/S/WH/W Post
Pin	Pin Name
1	+12V or +5V or +3.3V
2	+12V or +5V or +3.3V
3	GND
4	GND
5	+12V or +5V or +3.3V
6	+12V or +5V or +3.3V
7	LVDS0_D0-
8	LVDS1_D0-
9	LVDS0_D0+
10	LVDS1_D0+
11	GND
12	GND
13	LVDS0_D1-
14	LVDS1_D1-
15	LVDS0_D1+
16	LVDS1_D1+
17	GND
18	GND
19	LVDS0_D2-
20	LVDS1_D2-
21	LVDS0_D2+
22	LVDS1_D2+
23	GND
24	GND
25	LVDS0_CLK-
26	LVDS1_CLK-

Table 3.20: LVDS1 48-bit LVDS Panel

27	LVDS0_CLK+
28	LVDS1_CLK+
29	GND
30	GND
31	LVDS0_DDCCLK_AUX+
32	LVDS0_DDCCLK_AUX-
33	GND
34	GND
35	LVDS0_D3-
36	LVDS1_D3-
37	LVDS0_D3+
38	LVDS1_D3+
39	NC
40	VCON

3.4.19 EDP1 eDP (option)




Table 3.21: EDP1 eDP (option)

Part Number	1655005384-01
Footprint	LVDS_40P_20_20455-040E_MIO-5373
Description	Conn. 40P 0.5mm 90D SMD 20455-040E-12
Pin	Pin Name
1	NC
2	GND
3	eDP_TX3-
4	eDP_TX3+
5	GND
6	eDP_TX2-
7	eDP_TX2+
8	GND
9	eDP_TX1-
10	eDP_TX1+
11	GND

Table 3.21: EDP1 eDP (option)

12	eDP_TX0-
13	eDP_TX0+-
14	GND
15	eDP_AUX+
16	eDP_AUX-
17	GND
18	+12V or +5V or +3.3V
19	+12V or +5V or +3.3V
20	+12V or +5V or +3.3V
21	+12V or +5V or +3.3V
22	NC
23	GND
24	GND
25	GND
26	GND
27	eDP_HDP
28	GND
29	GND
30	GND
31	GND
32	ENABKL
33	PWM
34	DSI_DE_TE_1
35	NC
36	eDP Inverter 12V or 5V
37	eDP Inverter 12V or 5V
38	eDP Inverter 12V or 5V
39	eDP Inverter 12V or 5V
40	NC

3.4.20 HDMI




Table 3.22: HDMI

Part Number	1654014189-02
Footprint	HDMI_19P_365FA19-XN024D-H
Description	HDMI 19P/LCP/RA(F)/G-FL/D/BK/W Flanged

3.4.21 M2_1 M.2 E key




Table 3.23: M2_1 M.2 E key

Part Number	1654012663-01
Footprint	NGFF_75P_APCI0163-P001A
Description	NGFF 75P/0.5mm/(F)/LCP/RA/GFL/S/BK/H8.5mm/E-key
Pin	Pin Name
1	GND
2	+3.3VSB
3	USB_D+
4	+3.3VSB
5	USB_D-
7	GND
8	NC
10	NC
12	NC

Table 3.23: M2_1 M.2 E key

14	NC
18	GND
33	GND
35	PETp0
37	PETn0
39	GND
41	PERp0
43	PERn0
45	GND
47	REFCLK+
49	REFCLK-
50	SUSCLK
51	GND
52	PERESET#
53	CLKREQ#
54	BT_DISABLE#
55	PCIE_WAKE#
56	W_DISABLE#
57	GND
58	NC
60	NC
63	GND
69	GND
72	+3.3VSB
74	+3.3VSB
75	GND

3.4.22 M2_2 M.2 M key




Table 3.24: M2_2 M.2 M key

Part Number	1654014529-01
Footprint	NGFF_75P_AS0BC21-S85BM-7H
Description	M.2 M KEY 75P/0.5/G-FL/RA/S/BK/H8.50/GEN 4
Pin	Pin Name
1	GND
2	+3.3VSB
3	GND
4	+3.3VSB
5	PCIe_RX4-
6	NC
7	PCIe_RX4+
8	NC
9	GND
10	NC
11	PCIe_TX4-
12	+3.3VSB
13	PCIe_TX4+
14	+3.3VSB
15	GND
16	+3.3VSB
17	PCIe_RX3-
18	+3.3VSB
19	PCIe_RX3+
20	NC
21	GND
22	NC
23	PCIe_TX3-
24	NC
25	PCIe_TX3+
26	NC
27	GND
28	NC
29	PCIe_RX2-
30	NC
31	PCIe_RX2+
32	NC
33	GND
34	NC
35	PCIe_TX2-
36	NC
37	PCIe_TX2+
38	NC
39	GND
40	NC
41	PCIe_RX1+ / M2_SATA1_RX+
42	NC

Table 3.24: M2_2 M.2 M key

43	PCle_RX1-/ M2_SATA1_RX-
44	NC
45	GND
46	NC
47	PCle_TX1-/ M2_SATA1_TX-
48	NC
49	PCle_TX1+/ M2_SATA1_TX+
50	PLTRST#
51	GND
52	CLK_REQ#
53	CLK_PCIE-
54	PCIE_WAKE#
55	CLK_PCIE+
56	NC
57	GND
58	NC
59	Key
60	Key
61	Key
62	Key
63	Key
64	Key
65	Key
66	Key
67	NC
68	SUSCLK
69	M2_SSD_PEDT
70	+3.3VSB
71	GND
72	+3.3VSB
73	GND
74	+3.3VSB
75	GND


3.4.23 M2_3 M.2 B key

Table 3.25: M2_3 M.2 B key

Part Number	1654012087-02
Footprint	NGFF_75P_APCI0161-P001A
Description	NGFF 75P/0.5mm/(F)/LCP/RA/GFL/S/BK/H8.50/B-key
Pin	Pin Nam
1	M.2_B_CONFIG_3
2	+3.3VSB
3	GND
4	+3.3VSB
5	GND
6	POWER_OFF#
7	USB7_P+
8	WWAN_DISABLE#
9	USB7_P-
10	NC
11	GND
12	Key
13	Key
14	Key
15	Key
16	Key
17	Key
18	Key
19	Key
20	NC
21	M.2_B_CONFIG_0
22	NC
23	NC
24	NC
25	DPR
26	NC
27	GND
28	NC
29	NC
30	UIM_RESET
31	NC
32	UIM_CLK
33	GND
34	UIM_DATA
35	NC
36	+VUIM_PWR
37	NC
38	NC
39	GND
40	NC
41	NC
42	NC

Table 3.25: M2_3 M.2 B key	
43	NC
44	NC
45	GND
46	NC
47	NC
48	NC
49	NC
50	NC
51	GND
52	NC
53	NC
54	NC
55	NC
56	NC
57	GND
58	NC
59	NC
60	NC
61	NC
62	NC
63	NC
64	NC
65	NC
66	NC
67	PLTRST_BKEY #
68	SUSCLK
69	M.2_B_CONFIG_1
70	+3.3VSB
71	GND
72	+3.3VSB
73	GND
74	+3.3VSB
75	M.2_B_CONFIG_2

3.4.24 SIM NANO SIM




Table 3.26: SIM NANO SIM


Part Number	1654013206-01
Footprint	SIM_6P_N080613-SICR10
Description	Nano SIM Card 6P/1.27/(F)/LCP/RA/GFL/S/BK/H1.37

3.4.25 USB1 USB3.0_13H

Table 3.27: USB1 USB3.0_13H


Part Number	1654013480-01
Footprint	USB_9X2P_USB5-18F5-BNR0-10
Description	USB 3.1 2x9P/2.0mm/PA66/(F)/RA/G30u/D/BU/H15.69

3.4.26 USB2 USB3.0_13H

**Table 3.28: USB2 USB3.0_13H**

Part Number	1654013480-01
Footprint	USB_9X2P_USB5-18F5-BNR0-10
Description	USB 3.1 2x9P/2.0mm/PA66/(F)/RA/G30u/D/BU/H15.69

3.4.27 USB3 Internal USB

**Table 3.29: USB3 Internal USB**

Part Number	1653007480-01
Footprint	HD_5X2P_79_BOX_H245
Description	BOXH 2x5P/2.0mm/LCP/M/VA/G10u/S/BK/H4.83/W

Table 3.29: USB3 Internal USB


Pin	Pin Name
1	+5V
2	+5V
3	A_D-
4	B_D-
5	A_D+
6	B_D+
7	GND
8	GND
9	GND
10	NC

3.4.28 SATAP1 SATA Power

**Table 3.30: SATAP1 SATA Power**


Part Number	1653007538-01
Footprint	WF_2P_79_BOX_D_721-81-02TW00
Description	Wafer 1x2P/2.0mm/NY66+30GF/M/VA/Sn/D/WH/H6.1mm
Pin	Pin Name
1	+5V
2	GND

3.4.29 SATA1 SATA_7V

**Table 3.31: SATA1 SATA_7V**

Part Number	1654013615-01
Footprint	SATA_7P_WATF-07DBN6SB1U
Description	SATA 7P/1.27mm/LCP/F/VA/G15u/S/BK/H8.41/W

3.4.30 CN10 Smart Fan


**Table 3.32: CN10 Smart Fan**

Part Number	1655004347
Footprint	WF_4P_100_D_744-81-04TW30
Description	WAFER 2.54 1*4P 180D(M) DIP 744-81-04TW30

Table 3.32: CN10 Smart Fan

Pin	Pin Name
1	GND
2	+V12_FAN
3	FAN_SPEED
4	FAN_PWM

3.4.31 MIOE MIOe

**Table 3.33: MIOE MIOe**

Part Number	1654006235
Footprint	BB_40x2P_32_1625x285_2HOLD
Description	B/B Conn. 40x2P 0.8mm 180D(F) SMD QSE-040-01-L-D
Pin	Pin Name
1	GND
2	GND
3	PCIE_RX0+
4	PCIE_TX0+
5	PCIE_RX0-
6	PCIE_TX0-
7	GND
8	GND
9	PCIE_RX1+

Table 3.33: MIOE MIOe

10	PCIE_TX1+
11	PCIE_RX1-
12	PCIE_TX1-
13	GND
14	GND
15	PCIE_RX2+
16	PCIE_TX2+
17	PCIE_RX2-
18	PCIE_TX2-
19	GND
20	GND
21	PCIE_RX3+
22	PCIE_TX3+
23	PCIE_RX3-
24	PCIE_TX3-
25	GND
26	GND
27	PCIE_CLK+
28	LOUTL
29	PCIE_CLK-
30	LOUTR
31	GND
32	AGND
33	SMB_CLK
34	NC
35	SMB_DAT
36	NC
37	PCIE_WAKE#
38	NC
39	RESET#
40	NC
41	SLP_S3#
42	CLK24M
43	NC
44	LPC_AD0
45	DDP_HPD
46	LPC_AD1
47	GND
48	LPC_AD2
49	DDP_AUX+
50	LPC_AD3
51	DDP_AUX-
52	NC
53	GND
54	LPC_SERIRQ
55	DDP_D0+
56	LPC_FRAME#


Table 3.33: MIOE MIOe

57	DDP_D0-
58	GND
59	GND
60	USB0_D+
61	DDP_D1+
62	USB0_D-
63	DDP_D1-
64	GND
65	GND
66	NC
67	DDP_D2+
68	NC
69	DDP_D2-
70	GND
71	GND
72	NC
73	DDP_D3+
74	NC
75	DDP_D3-
76	GND
77	GND
78	USB_OC#
79	+12VSB
80	+12VSB
83	GND
84	GND
85	GND
86	GND
87	+5VSB
88	+5VSB
89	+5VSB
90	+5VSB

Chapter 4

AMI BIOS Setup

AMIBIOS has been integrated into many motherboards for over a decade. With the AMIBIOS Setup program, you can modify BIOS settings and control the various system features. This chapter describes the basic navigation of the MIO-5375 BIOS setup screens.



AMI's BIOS ROM has a built-in Setup program that allows users to modify the basic system configuration. This information is stored in battery-backed CMOS so it retains the Setup information when the power is turned off.

4.1 Entering Setup

Turn on the computer and check for the patch code. If there is a number assigned to the patch code, it means that the BIOS supports your CPU. If there is no number assigned to the patch code, please contact an Advantech application engineer to obtain an up-to-date patch code file. This will ensure that your CPU's system status is valid. After ensuring that you have a number assigned to the patch code, press and you will immediately be allowed to enter Setup.

4.1.1 Main Setup

When you first enter the BIOS Setup Utility, you will encounter the Main setup screen. You can always return to the Main setup screen by selecting the Main tab. There are two Main Setup options. They are described in this section. The Main BIOS Setup screen is shown below.



The Main BIOS setup screen has two main frames. The left frame displays all the options that can be configured. Grayed-out options cannot be configured; options in blue can. The right frame displays the key legend.


Above the key legend is an area reserved for a text message. When an option is selected in the left frame, it is highlighted in white. Often a text message will accompany it.

■ System time / System date

Use this option to change the system time and date. Highlight System Time or System Date using the <Arrow> keys. Enter new values through the keyboard. Press the <Tab> key or the <Arrow> keys to move between fields. The date must be entered in MM/DD/YY format. The time must be entered in HH:MM:SS format.

4.1.2 Advanced BIOS Features Setup

Select the Advanced tab from the MIO-5375 setup screen to enter the Advanced BIOS Setup screen. You can select any of the items in the left frame of the screen, such as CPU Configuration, to go to the sub menu for that item. You can display an Advanced BIOS Setup option by highlighting it using the <Arrow> keys. All Advanced BIOS Setup options are described in this section. The Advanced BIOS Setup screens is shown below. The sub menus are described on the following pages.




4.1.2.1 RC ACPI Settings



Low Power S0 Idle Capability

Determine if Enable ACPI Low Power S0 Idle Capability.

4.1.2.2 CPU Configuration



SW Guard Extension (SGX)

Enable/Disable Software Guard Extensions (SGX).

Select Owner EPOCH input type

Choose Owner EPOCH modes.

CPU Flex Ratio Override

Enable/Disable CPU Flex Ratio Programming.

Hardware Prefetcher

This item allows users to enable or disable the hardware prefetcher feature.

Adjacent Cache Line Prefetch

This item allows users to enable or disable the adjacent cache line prefetch feature.

Intel (VMX) Virtualization Technology

When Enabled, a VMM can utilize the additional hardware capability provided by Vanderpool Technology.

Active Processor Cores

This item allows users to set how many processor cores should be active.

AES

Enable/Disable AES (Advanced Encryption Standard).

MachineCheck

Enable/Disable Machine Check.

MonitorMWait

Enable/Disable MonitorMWait.

Intel Trusted Execution Technology

Enables utilization of additional hardware capability provided by Intel® Trusted Execution Technology.

4.1.2.3 Power & Performance




CPU – Power Management Control

CPU – Power Management Control Options.

GT – Power Management Control

GT – Power Management Control Options.

CPU - Power Management Control



Boot Performance mode

Select the performance state that the BIOS will set before OS handoff.

Intel® SpeedStep®

Allows more than two frequency ranges to be supported.

Intel® Speed Shift Technology

Enable/Disable Intel® Speed Shift Technology support.

HDC Control

Enable/Disable Intel HDC.

Turbo Mode

Enable/Disable processor turbo mode.

Platform PL1 Enable

Enable/Disable Platform Power Limit 1 programming.

Platform PL2 Enable

Enable/Disable Platform Power Limit 1 programming.

Power Limit 4 Override

Enable/Disable Power Limit 4 override.

C states

Enable/Disable CPU Power Management.


PowerLimit 3 Settings

Power Limit 3 Settings.

CPU Lock Configuration

CPU Lock Configuration.

View/Configure Turbo Options



Energy Efficient P-state

Enable/Disable Energy Efficient P-state feature.


Package Power Limit MSR Lock

Enable/Disable locking of Package Power Limit settings.

Energy Efficient Turbo

Enable/Disable Energy Efficient Turbo feature.

Config TDP Configurations



Configurable TDP Boot Mode

Configurable TDP Mode as Nominal/Up/Down/Deactivate TDP selection.

Configurable TDP Lock

Configurable TDP Mode Lock sets the Lock bit.

CTDP BIOS Control

Enables CTDP control via runtime ACPI BIOS method.


Power Limit 3 Settings



Power Limit 3 Override

Enable/Disable Power Limit 3 override.

CPU Lock Configuration




CFG Lock

Configure MSR 0xE2[15], CFG Lock bit.

Overclocking Lock

Enable/Disable Overclocking Lock (BIT 20) in FLEX_RATIO(194) MSR.

GT - Power Management Control



RC6(Render Standby)

Check to enable render standby support.

Maximum GT Frequency

Maximum GT frequency limited by user.

Disable Turbo GT Frequency

Enabled/Disabled Turbo GT frequency.

4.1.2.4 PCH-FW Configuration



ME State

When disabled ME will be put ME into temporarily disabled mode.

Manageability Features State

Enable/disable Intel Manageability features.

AMT BIOS Features

When disabled, AMT BIOS Features are no longer supported and user is no longer able to access MEBx setup.

AMT Configuration

Configure Intel® Active Management Technology parameters.

ME Unconfig on RTC Clear

When disabled, ME will not be unconfigured on RTC Clear.

Firmware Update Configuration

Configure management engine technology parameters.

4.1.2.5 ACPI Settings



Enable ACPI Auto Configuration

Enable or disable BIOS ACPI auto configuration.

Enable Hibernation

Enables or disables the ability to hibernate (OS/S4 Sleep State). This option may not be effective with some OS.

ACPI Sleep State

Select the highest ACPI sleep state the system will enter when the SUSPEND button is pressed.


Lock Legacy Resources

Enables or disables lock of Legacy Resources.

S3 Video Repost

Enable or disable S3 Video Repost.

4.1.2.6 iManager Configuration



CPU Shutdown Temperature

Enable/disable CPU Shutdown Temperature.

Backlight Enable Polarity

Switch backlight enable polarity for native or invert.

Backlight Mode Selection

Switch backlight control to PWM or DC mode.

Brightness PWM Polarity

Switch brightness PWM polarity for native or invert.

Power Saving Mode

Enable/disable power saving mode.

Serial Port 1 Configuration

Set parameters of serial port 1.

Serial Port 2 Configuration

Set parameters of serial port 2.

Wake On Ring Control

Enable/disable Wake on Ring Function.

Hardware Monitor

Monitor hardware Status.

Watch Dog Timer Configuration

Watch Dog Timer Configuration page.


Case Open Detection

Enable or disable Case Open Detect function.

GPIO Configuration

GPIO Configuration settings.

Serial Port 1 Configuration



Serial Port

Enable or disable Serial Port (COM).


Change Settings

Select an optimal settings for Super IO device.

COM1 Mode

COM1 port mode select.

Serial Port 2 Configuration



Serial Port

Enable or disable Serial Port (COM).


Change Settings

Select an optimal settings for Super IO device.

COM2 Mode

COM2 port mode select.

Hardware Monitor




Watch Dog Timer Configuration



Watch Dog Timer

Enable or disable Watch Dog Timer function.

GPIO Configuration



GPIO0/1/2/3/4/5/6/7/8/9/10/11/12/13/14/15

Configure GPIO0/1/2/3/4/5/6/7/8/9/10/11/12/13/14/15.

4.1.2.7 Trusted Computing



Security Device Support

Enable or disable BIOS support for security device.

SHA-1 PCR Bank

Enable or disable SHA-1 PCR Bank.

SHA256 PCR Bank

Enable or disable SHA256 PCR Bank.

Pending operation

Schedule an operation for the security device.

Platform Hierarchy

Enable or disable Platform Hierarchy.

Storage Hierarchy

Enable or disable Storage Hierarchy.

Endorsement Hierarchy

Enable or disable Endorsement Hierarchy.

TPM 2.0 UEFI Spec Version

Select the TCG2 Spec Version support.


Physical Presence Spec Version

Select to Tell O.S. to support PPI Spec Version 1.2 or 1.3.

Device Select

TPM 1.2 will restrict support to TPM 1.2 devices, TPM 2.0 will restrict support to TPM 2.0 devices.

4.1.2.8 S5 RTC Wake Settings



Wake system from S5

Enable or disable System wake on alarm event. Select FixedTime, system will wake on the hr:min:sec specified.

4.1.2.9 Serial Port Console Redirection



Console Redirection

This item allows users to enable or disable console redirection for Microsoft Windows Emergency Management Services (EMS).

Console Redirection Settings

This item allows users to configure console redirection detail settings.

4.1.2.10 Intel TXT Information



Intel TXT Information
 Display Intel TXT information.

4.1.2.11 USB Configuration



Legacy USB Support

Enables Legacy USB support. AUTO option disables legacy support if no USB devices are connected. DISABLE option will keep USB devices available only for EFI applications.

XHCI Hand-off

This is a workaround for OS without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.

USB Mass Storage Driver Support

Enable/disable USB Mass Storage Driver Support.

USB Transfer Time-out

Time-out value for control, bulk, and interrupt transfers.


Device Reset Time-out

USB mass storage device start unit command time-out.

Device Power-up Delay

Maximum time the device will take before it properly reports itself to the host controller. 'Auto' uses default value: for a root port it is 100 ms, for a Hub port the delay is taken from hub descriptor.

4.1.2.12 CSM Configuration



CSM Support

Enable/disable CSM Support.

GateA20 Active

UPON REQUEST - GA20 can be disabled using BIOS services. ALWAYS - Do not allow disabling of GA20; this option is useful when any RT code is executed above 1MB.

Option ROM Message

BIOS Set display mode for Option ROM.

INT19 Trap Response

BIOS reaction on INT19 trapping by Option ROM: IMMEDIATE - execute the trap right away; POSTPONED - execute the trap during legacy boot.

Boot Option Filter

This option controls legacy/UEFI ROM priority.

Network

Controls the execution of UEFI and legacy PXE OpROM.

Storage

Controls the execution of UEFI and legacy storage OpROM.

Video

Controls the execution of UEFI and legacy video OpROM.

Other PCI Devices

Determines OpROM execution policy for devices other than network, storage, or video.

4.1.2.13 NVMe Configuration



4.1.2.14 Network Stack Configuration



Network Stack


Enable/disable UEFI Network stack.

4.1.3 Chipset Configuration

Select the Chipset tab from the MIO-5375 setup screen to enter the Chipset BIOS Setup screen. You can display a Chipset BIOS Setup option by highlighting it using the <Arrow> keys. All Plug and Play BIOS Setup options are described in this section. The Plug and Play BIOS setup screen is shown below.



4.1.3.1 System Agent (SA) Configuration



Memory Configuration

Memory Configuration parameters.

Graphics Configuration

Graphics Configuration parameters.

VT-d

VT-D capability.

Above 4GB MMIO BIOS Assignment

Enable/disable above 4GB memory mapped IO BIOS assignment.

X2APIC Opt Out

Enable/disable X2APIC Opt Out bit.

Memory Configuration



Max TOLUD

Maximum value of TOLUD.

Memory Scrambler

Enable/disable Memory Scrambler support.


Force ColdReset

Force ColdReset or choose MrcColdBoot mode.

Memory Remap

Enable/disable Memory Remap above 4GB.

Graphics Configuration



Graphics Turbo IMON Current

Graphics turbo IMON current values supported.

Internal Graphics

Keep IGFX enabled based on the setup options.

GTT Size

Select the GTT Size.

Aperture Size

Select the Aperture Size.

DVMT Pre-Allocated

Select DVMT 5.0 pre-allocated (fixed) graphics memory size used by the Internal Graphics Device.

DVMT Total Gfx Mem

Select DVMT 5.0 Total Graphic Memory size used by the Internal Graphics Device.

Gfx Low Power Mode

This option is applicable for SFF only.

PM Support

Enable/disable PM support.


PAVP Enable

Enable/disable PAVP.

CD Clock Frequency

Select the highest CD clock frequency supported by this platform.

Boot Display Control



NXP Non-EDID Support

NXP non-EDID support.

Color Depth & Data Packing

Color depth and data packing format for Non-EDID support.

Dual LVDS Mode

Select LVDS bus to single bus mode or dual bus mode.

LVDS Panel Type

This item allow user to select LVDS panel type.

4.1.3.2 PCH-IO Configuration



PCI Express Configuration

PCI Express Configuration settings.

SATA And RST Configuration

SATA device options settings.

USB Configuration

USB Configuration settings.

Security Configuration

Security Configuration settings.

HD Audio Configuration

HD Audio subsystem configuration settings.

SerialIO Configuration

SerialIO configuration settings.

PCH LAN Controller

Enable or disable onboard NIC.

LAN1 PXE ROM

Enable or disable onboard LAN's PXE option ROM.

Wake on LAN

Enable or disable Integrated LAN to wake the system from S5.

Onboard LAN2 Controller

Enable or disable onboard NIC.

LAN2 PXE ROM

Enable or disable onboard LAN's PXE option ROM.


PCIE Wake

Enable or disable PCIE to wake the system from S5.

State After S3

Specify what state to go to when power is re-applied after a power failure (G3 state).


PCI Express Configuration



PCI Express Root Port 7/9/10/11/12/17

PCI Express Port 5/6/7/8/12/13 settings.

SATA and RST Configuration



SATA Controller(s)

Enable/disable SATA device.

SATA Mode Selection

Determine how SATA controller operate.

SATA Controller Speed

Indicates the maximum speed the SATA controller can support.

Software Feature Mask Configuration

RST Legacy ROM/RST UEFI driver will refer to the SWFM configuration to enable/disable the storage feature.

Aggressive LPM Support

Enabled PCH to aggressively enter link power state.

USB Configuration




XHCI Disable Compliance mode

Option to disable compliance mode.

USB Port Disable Override

Selectively enable/disable the corresponding USB port from reporting a device connection to the controller.

Security Configuration




RTC Lock

Enable will lock bytes 38h-3Fh in the lower/upper 128-byte bank of RTC RAM.

BIOS Lock

Enable or disable the PCH BIOS Lock enable feature.


HD Audio Configuration



HD Audio

Control detection of the HD-Audio device. Disabled = HDA will be unconditionally disabled. Enabled = HDA will be unconditionally enabled.

Serial IO Configuration



I2C0 Controller

Enable/Disables Serial IO Controller.

4.1.4 Security




Select security setup from the MIO-5375 setup main BIOS setup menu. All Security setup options, such as password protection and virus protection are described in this section. To access the sub menu for the following items, select the item and press <Enter>:

Change Administrator / User Password

Select this option and press <ENTER> to access the sub menu, and then type in the password.

4.1.5 Boot



Setup Prompt Timeout

Number of seconds that the firmware will wait before initiating the original default boot selection. A value of 0 indicates that the default boot selection is to be initiated immediately on boot. A value of 65535(0xFFFF) indicates that firmware will wait for user input before booting. This means the default boot selection is not automatically started by the firmware.

Bootup NumLock State

Select the keyboard NumLock state.

Quiet Boot

Enables or disables Quiet Boot option.

Boot Option #1

Sets the system boot order.


Fast Boot

Enables or disables boot with initialization of a minimal set of devices required to launch active boot option. Has no effect for BBS boot options.

New Boot Option Policy

Controls the placement of newly detected UEFI boot options.

4.1.6 Save & Exit



Save Changes and Exit

This item allows you to exit system setup after saving the changes.

Discard Changes and Exit

This item allows you to exit system setup without saving any changes.

Save Changes and Reset

This item allows you to reset the system after saving the changes.

Discard Changes and Reset

This item allows you to rest system setup without saving any changes.

Save Changes

This item allows you to save changes done so far to any of the options.

Discard Changes

This item allows you to discard changes done so far to any of the options.

Restore Defaults

This item allows you to restore/load default values for all the options.

Save as User Defaults

This item allows you to save the changes done so far as user defaults.

Restore User Defaults

This item allows you to restore the user defaults to all the options.

Boot Override

Boot device select can override your boot priority.

Appendix **A**

System Assignments

This appendix contains information of a detailed nature.

Sections include:

- System I/O Ports
- DMA Channel Assignments
- 1st MB Memory Map
- Interrupt Assignments

A.1 System I/O Ports

Table A.1: System I/O Ports

Addr. Range (Hex)	Device
00h-1Fh	DMA Controller
20h-2Dh	Interrupt Controller
2Eh-2Fh	Motherboard Resources
30h-3Dh	Interrupt Controller
40h-43h	Timer/Counter
4Eh-4Fh	Motherboard Resources
50h-53h	Timer/Counter
60h-6Fh	8042 (keyboard controller)/NMI Controller/Microcontroller
70h-7Fh	Real-time Controller
80h-8Fh	Debug Port/Reserved
90h-9Fh	Debug Port/Reset Generator
A0h-ADh	Interrupt Controller
B0h-B1h	Interrupt Controller
B4h-BDh	Power Management
200h-27Fh	CANBus Controller
280h-28Fh	I2C Controller
290h-29Fh	EC Index Port and Data Port
2A0h-2BFh	GPIO Controller
2C0h-2DFh	SMBus Controller
2E8h-2EFh	Communications Port (COM4)
2F0h-2F7h	EC/PMC Controller
2F8h-2FFh	Communications Port (COM2)
3E8h-3EFh	Communications Port (COM3)
3F8h-3FFh	Communications Port (COM1)
480h-4CFh	Motherboard Resources
4D0h-4D1h	Interrupt Controller
680h-69Fh	Motherboard Resources
A00h-AFFh	Motherboard Resources
164Eh-164Fh	Motherboard Resources
1800h-18FFh	Motherboard Resources
CF9h-CF9h	Reset Generator

A.2 DMA Channel Assignments

Table A.2: DMA Channel Assignments

Channel	Function
0	Available
1	Available
2	Available
3	Available
4	Direct memory access controller
5	Available
6	Available
7	Available

A.3 1st MB Memory Map

Table A.3: 1st MB Memory Map

Addr. Range (Hex)	Device
E0000h - FFFFFh	System board
D0000h - DFFFFh	PCI Bus
C0000h - CFFFFh	System board
A0000h - BFFFFh	PCI Bus
A0000h - BFFFFh	Intel® HD Graphic
00000h - 9FFFFh	System board

A.4 Interrupt Assignments

Table A.4: Interrupt Assignments

Interrupt#	Interrupt source
NMI	Parity error detected
IRQ0	System timer
IRQ1	Using SERIRQ, Keyboard Emulation
IRQ2	Interrupt from controller 2 (cascade)
IRQ3	Communications Port (COM2)
IRQ4	Communications Port (COM1)
IRQ5	EC Watch DOG
IRQ6	CANBus Controller
IRQ7	Available
IRQ8	System CMOS/real time clock
IRQ9	Microsoft ACPI-Compliant System
IRQ10	Available
IRQ11	Display Controller
IRQ12	Available
IRQ13	Numeric data processor
IRQ14	GPIO Controller
IRQ15	Reserved



Enabling an Intelligent Planet

www.advantech.com

Please verify specifications before quoting. This guide is intended for reference purposes only.

All product specifications are subject to change without notice.

No part of this publication may be reproduced in any form or by any means, electronic, photocopying, recording or otherwise, without prior written permission of the publisher.

All brand and product names are trademarks or registered trademarks of their respective companies.

© Advantech Co., Ltd. 2021