

AIER1000 series
Artificial Intelligence Education Solution

User's Manual

Version 1.0
(June 2021)

Copyright

© 2021 IBASE Technology, Inc. All rights reserved.

No part of this publication may be reproduced, copied, stored in a retrieval system, translated into any language or transmitted in any form or by any means, electronic, mechanical, photocopying, or otherwise, without the prior written consent of IBASE Technology, Inc. (hereinafter referred to as "IBASE").

Disclaimer

IBASE reserves the right to make changes and improvements to the products described in this document without prior notice. Every effort has been made to ensure the information in the document is correct; however, IBASE does not guarantee this document is error-free.

IBASE assumes no liability for incidental or consequential damages arising from misuse or inability to use the product or the information contained herein, and for any infringements of rights of third parties, which may result from its use.

Trademarks

All the trademarks, logos and brands mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Compliance

CE

The product described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

FCC

This product has been tested and found to comply with the limits for a Class B device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with manufacturer's instructions, may cause harmful interference to radio communications.

WEEE



This product must not be disposed of as normal household waste, in accordance with the EU directive of for waste electrical and electronic equipment (WEEE - 2012/19/EU). Instead, it should be disposed of by returning it to a municipal recycling collection point. Check local regulations for disposal of electronic products.

Green IBASE



This product complies with the current RoHS directives restricting the use of the following substances in concentrations not to exceed 0.1% by weight (1000 ppm) except for cadmium, limited to 0.01% by weight (100 ppm).

- Lead (Pb)
- Mercury (Hg)
- Cadmium (Cd)
- Hexavalent chromium (Cr6+)
- Polybrominated biphenyls (PBB)
- Polybrominated diphenyl ether (PBDE)

Important Safety Information

Carefully read the following safety information before using this device.

Setting up your system:

- Put the device horizontally on a stable and solid surface.
- Do not use this product near water or any heated source.
- Leave plenty of space around the device and do not block the ventilation openings. Never drop or insert any objects of any kind into the openings.
- Use this product in environments with ambient temperatures between 0°C and 45°C.

Care during use:

- Do not place heavy objects on the top of the device.
- Make sure to connect the correct voltage to the device. Failure to supply the correct voltage could damage the unit.
- Do not walk on the power cord or allow anything to rest on it.
- If you use an extension cord, make sure the total ampere rating of all devices plugged into the extension cord does not exceed the cord's ampere rating.
- Do not spill water or any other liquids on your device.
- Always unplug the power cord from the wall outlet before cleaning the device.
- Only use neutral cleaning agents to clean the device.
- Vacuum dust and particles from the vents by using a computer vacuum cleaner.

Product Disassembly

Do not try to repair, disassemble, or make modifications to the device. Doing so will void the warranty and may result in damage to the product or personal injury.



CAUTION

There is a danger of explosion if the lithium-ion battery is replaced with an incorrect battery. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries by observing local regulations.

Avoid Disassembly

You are not suggested to disassemble, repair or make any modification to the device. Disassembly, modification, or any attempt at repair could generate hazards and cause damage to the device, even bodily injury or property damage, and will void any warranty.

Warranty Policy

- **IBASE standard products:**

24-month (2-year) warranty from the date of shipment. If the date of shipment cannot be ascertained, the product serial numbers can be used to determine the approximate shipping date.

- **3rd-party parts:**

12-month (1-year) warranty from delivery for 3rd-party parts that are not manufactured by IBASE, such as CPU, CPU cooler, memory, storage devices, power adaptor, display panel and touch screen.

* PRODUCTS, HOWEVER, THAT FAIL DUE TO MISUSE, ACCIDENT, IMPROPER INSTALLATION OR UNAUTHORIZED REPAIR SHALL BE TREATED AS OUT OF WARRANTY AND CUSTOMERS SHALL BE BILLED FOR REPAIR AND SHIPPING CHARGES.

Technical Support & Services

1. Visit the IBASE website at www.ibase.com.tw to find the latest information about the product.
2. If you encounter any technical problems and require assistance from your distributor or sales representative, please prepare and send the following information:
 - Product model name
 - Product serial number
 - Detailed description of the problem
 - Error messages in text or screenshots if any
 - The arrangement of the peripherals
 - Software used (such as OS and application software)
3. If repair service is required, please download the RMA form at <http://www.ibase.com.tw/english/Supports/RMAService/>. Fill out the form and contact your distributor or sales representative.

Chapter 1

General Information

The information provided in this chapter includes:

- 1.1 Introduction
- 1.2 Features
- 1.3 Packing List
- 1.4 Specifications
- 1.5 Product View
- 1.6 Dimensions

1.1 Introduction

The AIER1000 series is powered by the 8th Generation LGA1151 Intel® Core™ i7-8700 Processor. The system features two 2.5" SATA SSD bays with RAID 0/1/5 function to ensure security of data and disks and comes with two 8GB DDR4 SO-DIMM memory modules for a total of 16GB capacity, internal 300W power supply and pre-installed Windows 10 & AI recognition software. It is designed for use as an inference computing system for high-performance Artificial Intelligence education applications.

The AIER102E model in the AIER1000 series uses one full-height PCIe capture card and two Full-HD SDI interface cameras to collect and analyze specific data for edge side system deployment.

The AIER100C, another AIER1000 series model, can be built as a centralized management system connecting several AIER102E for central management server.



AIER102E



AIER100C

1.2 Features

- 8th Gen Intel® Core™ i7-8700 processor
- 2x 8G DDR4 SO-DIMM on board
- Dual Intel® Gigabit LAN
- 4x USB3.0, 2x USB2.0, 1x RS232 COM port
- 1x HDMI 1.4

1.3 Packing List

AIER102E	1 x AIER102E system 1 x Power cord 1 x Wall mount kit and screws 4 x Foot pads 1 x Camera kit: (1) AIDA SDI interface Full HD cameras *2 (2) 12V power adaptor and power cables for camera *2 (3) 20M SDI cables *2
----------	--

AIER100C	1 x AIER100C system 1 x Power cord 1 x Wall mount kit and screws 4 x Foot pads
----------	---

1.4 Specifications

Product	AIER102E	AIER100C
System		
Mainboard	MI998AF-AI	
Operating System	Microsoft Windows 10 (64-bit)	
CPU	8th Gen Intel® Core™ i7-8700 Processor 3.20GHz, TDP ≤ 65W	
Chipset	Intel® Q370 PCH	
Memory	2x DDR4 SO-DIMM 2666/2400 MHz up to 32GB, default 2x 8GB	
Graphics	Intel® UHD Graphics P630	
Network	1x Intel® I219LM Gigabit LAN controller 1x Intel® I211AT Gigabit LAN (as 2nd LAN)	
Power Supply	Internal 300W PSU	
Storage	2x 2.5" SATA devices, Default 1x 128G SSD and 1x 500G HDD	2x 2.5" SATA devices Default 1x 128G SSD and 1x 2TB HDD
Expansion	Default 1 x SDI full-height PCIe capture card	N/A
Front Side I/O	<ul style="list-style-type: none"> • 2x USB 2.0 • 1x Reset button • 1 x Power/HDD LED 	

Rear Side I/O	<ul style="list-style-type: none"> • 1x HDMI • 4x USB 3.0 • 2x RJ45 Gigabit LAN • 1x COM port RS232 • 1 x IEC 60320 (C14) AC Inlet 	
Power Requirement	AC 100V~240V	
Watchdog	Watchdog Timer 256 segments, 0, 1, 2...255 sec/min	
Chassis	Aluminum and SGCC, Gray & white	Aluminum and SGCC, Blue & white
Mounting	Standard system bracket	
Dimensions (W x H x D)	406mm(W) x 345mm(D) x 93mm(H) 462.8mm(W) x 345mm(D) x 98mm(H) with desktop mounting kit	
Net Weight	8 kgs (17.64 lbs)	
Compliance	CE/FCC class A	
Temperature	<ul style="list-style-type: none"> • Operating: 0°C ~ 45°C (32°F ~ 113°F) • Storage: -20°C ~ 80°C (-4°F ~ 176°F) 	
Relative Humidity	10 ~ 90% (non-condensing)	


SDI Capture Card	
Video Input	4x SDI
Max. FPS	1920×1080p@60/50fps in → 1920×1080p@60/50fps out
Recording Video Resolution	3G-SDI: 1920 x 1080p @60/50fps HD-SDI: 1920 x 1080p @30/25/24fps, 1920 x 1080i @60/50fps, 1280 x 720p @60/50fps SD-SDI: 720 x 480i @60fps, 720 x 576i @50fps

3G-SDI Full HD Camera	
Image Sensor	1/3 inch Progressive CMOS
Sensor Size	5.346 x 3.003mm (16:9)
Effective Pixels	Horizontal: 1920, Vertical: 1080
Pixel Size	2.75um x 2.75um
Resolution	1080p / 1080i: 1920 x 1080, 720p & 720i: 1280 x 720
Resolution/Rate	1080 60p/ 59.94p/ 50p/ 30p/ 29.97p/ 25p, 1080 60i/ 59.94i/ 50i, 720 60p/ 59.94p/ 50p/ 30p/ 25p
Output	HD-SDI/ 3G-SDI (1 BNC), HDMI 1.3a
Dimension	49mm x 49mm x 71mm (With default 3.6mm lens)
Weight	180g/0.39Lbs (With default 3.6mm Lens)
Power	30W/12VDC

All specifications are subject to change without prior notice.


1.5 Product View

Front View




Rear View

AIER102E




AIER100C



1.6 Dimensions

Unit: mm



Chapter 2


Hardware Installation

This section contains general information about:

- 2.1 Edge Side System Installation
- 2.2 Central Management Server Installation
- 2.3 Mounting Installation

2.1 Edge Side System Installation

1. Install AIER102E in each classroom.



Hardware:

- ① AIER102E AI Education System
- ② Camera 1 → for Students
- ③ Camera 2 → for Students
- ④ Camera 3 → for Students (future feature)
- ⑤ Camera 4 → for Teacher (future feature)

Software:

QDEEP Education


Surroundings:

- ① No. of detection: Max. 35
- ② Detected area space: 6M x 5.5M

Camera setting:

The cameras set up at a distance of 210 cm from the ground and look down at a 45-degree angle

2. Set up two cameras with default 20M SDI cable on the left and right sides of the front of the classroom. Make sure cameras can capture all students' faces.
3. Connect the cameras to the two ports as below. Be sure to connect port 1/2 and select 2 on the CHANNEL_NUMBER page.





If there is only one camera connected (whether on port1 or port2), select 1 on the CHANNEL_NUMBER page.

Then you will see the corresponding image in the UI windows and another one will have a black screen.

In other words, if one camera is connected to Port 1, the image will be shown at Channel 1, and Channel 2 will have a black screen and vice versa.

Port 1 = Channel 1
Port 2 = Channel 2



*If you want to use another camera, choose one with the following specifications:

- (a) Camera maximum resolution: Full HD
- (b) Camera output interface: SDI


iBASE

4. Use an HDMI 1.4 Type A cable to connect the AIER102E to your monitor.
5. Use a USB Type A connector for your keyboard & mouse.
6. After the above connections have been made, plug the power cord and start the system.




2.2 Central Management Server Installation

1. If there are many classrooms that need to be set up with the AIER102E system, prepare one AIER100C central management server at your office to simultaneously manage these AIER102E systems.
2. Connect all AIER102E and AIER100C to the ethernet.
3. Connect an HDMI 1.4 Type A cable to the AIER100C and monitor.
4. Connect the keyboard & mouse with a USB Type A connector.
5. Plug the power cord and start the system.




2.3 Mounting Installation


Before mounting the system, ensure that you have enough space for the power cord and signal cable routing. Use the following methods for mounting your system:




1. Use the embedded handle for ease of grip and handling of the system.



2. Turn your system upside down. Attach the wall-mount kit to the system and secure with the supplied 8 screws.



3. Prepare at least 4 screws (M3) to install the device on the wall as shown.



If you want to let the system stand as a desktop platform, turn your system upside down and attach the foot pads in the four corners as shown in the picture.

Chapter 3

Software Setting

This section contains general information about:

3.1 Edge Side System UI Introduction

3.1.1 User Interface Overview

3.1.2 Account Login

3.1.3 Student Data Registration

3.1.4 Schedule Setting

3.1.5 Live Detection

3.1.6 System Information

3.1.7 Report Export

3.1.8 Video recording

3.1.9 Activity Controls

3.2 Central Management Server UI Introduction

3.2.1 User Interface Overview


3.2.2 Account Login

3.2.3 Connect to Edge side system

3.2.4 Raw Data Export

3.1 Edge Side System UI Introduction

3.1.1 User Interface Overview



Six emotion categories in student's facial recognition


-  Calm
-  Surprised
-  Joyful
-  Disgust
-  Angry
-  Fear

Nine behavior detections of students in the classroom

-  Reading
-  Writing
-  Listening
-  Standing
-  Raising Hand
-  Lying Down
-  Look Up
-  Look Back
-  Head Down


3.1.2 Account Login

Please key in the default user name and password: admin



The image shows a login screen for SmartVDO. The background is black. At the top, the text "SmartVDO" is displayed in a light green font. Below this, there are two input fields, each with a light green background and a yellow border. The first field is labeled "User Name" and contains the text "admin". The second field is labeled "Password" and also contains the text "admin". Below the input fields, there are two buttons: "Exit" and "Enter", both with light green backgrounds and yellow borders.


To create a new user, click the “Setting” and then “Member” at the top left of the Setting page.



3.1.3 Student Data Registration

Prepare the pictures of the students to register information in advance before using this UI.

- Set up the Group information. "Group" means the group of students.



The methods of student registration.

(1) Single Registration

- Fill in the fields as shown in the picture.
- Click Select photo to attach the picture file.

Setting

Member Group **Student** Schedule System

Update Student

Single Batch

Student ID
001

Student Name(First Name-Last Name)
Ray Chang

Group Name
Level 2

Birthday
1980 01 01

Gender
Female

Select Photo


Back to Create Save

001
002
003
004
005
006
007
008
009
010

(2) Batch Registration

- Setting up the filename of the pictures.

The file name format: Student ID_Student First Name-Last Name_Group ID_Birthday_Gender_



- Select photo to attach all files


The screenshot displays the SmartVDO software interface. At the top, it shows "MATH" and a timeline from "Start time: 2021-03-23-20:00" to "End time: 2021-03-23-22:00". The main interface is divided into several sections:

- Member List:** A list of 10 students (001-010) with their IDs and names.
- Emotion Chart:** A pie chart showing the distribution of emotions for 6/10 students. The data is as follows:

Emotion	Percentage
Calm	95%
Surprised	0%
Joyful	0%
Disgust	0%
Angry	3%
Fear	0%
- Behavior Chart:** A pie chart showing the distribution of behaviors for 6/10 students. The data is as follows:

Behavior	Percentage
Reading	31%
Writing	8%
Listening	2%
Standing	2%
Raising Hand	2%
Lying Down	2%
Look Up	1%
Look Back	0%
Head Down	0%
- Registration Form:** A "Create New Student" form with fields for "Student ID", "Student Name (First Name-Last Name)", and "Group Name". The "Batch" radio button is selected.
- Select Photo Window:** A file explorer window showing a folder named "StudentTestPhoto" on the desktop. It contains 10 files with names following the format: "Student ID_Student First Name-Last Name_Group ID_Birthday_Gender_.jpg".
- Emotion Behavior Graph:** A small line graph in the bottom left corner showing percentage over time.

- If you do not have the student picture ready, you can use the camera function to take a photo of the classroom. Double click the area to capture and take a picture. The picture will be automatically saved on the desktop of the computer.




3.1.4 Schedule Setting

- (1) Click "Schedule" at the top of the screen and open the setting page.
- (2) Create "Course Name"



Course name cannot be repeated

- (3) Chose the "Participative Group"



(4) Set up the course start time and end time.

The screenshot shows the 'Setting' window with the 'Schedule' tab selected. A calendar for March 2021 is displayed on the left, with the 23rd highlighted in green. On the right, the course configuration is shown:

- Course Name: MATH
- Participative Group: (empty)
- Level 1: (dropdown)
- Start Time(HH:MM): 20 : 00
- End Time(HH:MM): 22 : 00
- Repeat Period: Daily
- Start Hour: Radio buttons for 00, 01, 02, 03, 04, 05, 06, 07, 08, 09, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23. The '20' option is selected and circled in yellow.

This screenshot is similar to the previous one, but the 'Start Minute' field is expanded to show a list of radio buttons from 00 to 59. The '00' option is selected and circled in yellow. The 'End Time(HH:MM)' field is also visible, showing 22 : 00.

- Course Name: MATH
- Participative Group: (empty)
- Level 1: (dropdown)
- Start Time(HH:MM): 20 : 00
- End Time(HH:MM): 22 : 00
- Repeat Period: Daily
- Start Minute: Radio buttons for 00, 01, 02, 03, 04, 05, 06, 07, 08, 09, 10, 11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59. The '00' option is selected and circled in yellow.


(5) There are two repeat periods: Daily or Weekly.

The screenshot shows the 'Setting' window with a dark theme. At the top, there are tabs for 'Member', 'Group', 'Student', 'Schedule', and 'System'. The 'Schedule' tab is active, displaying a calendar for 'March 2021'. The calendar shows dates from 28 to 31, with the 23rd highlighted in green. To the right of the calendar is a form for course scheduling. The form includes fields for 'Course Name' (MATH), 'Participative Group' (Level 1), 'Start Time(HH:MM)' (20 : 00), 'End Time(HH:MM)' (22 : 00), 'Repeat Period' (Daily), and 'End Date' (0). A yellow box highlights a date picker for the 'End Date' field, and yellow arrows point to the 'Daily' option and the '0' value.

Please choose the end date of this repeat period.

3.1.5 Live Detection



When the system starts to detect, the time period is WHITE.
Otherwise, the time period is RED.



The ICON indicator lights up to indicate that the student is "present"




The ICON indicator lights up to indicate that the student is "absent"




This page shows the personal detection information.

Press the F3 button on the keyboard and the system place the detected student in red frames.



➤ Undetected mode

1. If a person does not want to be detected, do this setting.
2. Create a new group with the name “UNDETECTED”, for example.



The screenshot shows a web application window titled "Setting" with a dark theme. The "Group" tab is selected in the top navigation bar. The main content area is titled "Create Student Group" and contains three input fields: "Group Name" (with "UNDETECTED" entered and highlighted by a red box), "Group Description" (with "UNDETECTED" entered), and "Group ID(Auto Increment)". At the bottom, there are "Clear" and "Save" buttons. On the right side, there is a sidebar with a refresh icon, a trash icon, and a section labeled "IBASE" with a checkbox.

3. Move the students who do not want to be detected into the “UNDETECTED” group.

Setting

Member Group **Student** Schedule System

Update Student

Single Batch

Student ID
011

Student Name(First Name-Last Name)
TONY LAST

Group Name
UNDETECTED

Birthday
1980 01 01

Gender
Male

Select Photo


Back to Create Save

- 001
- 002
- 003
- 004
- 005
- 008
- 009
- 010
- 011
- 012
- 777

4. In the course schedule calendar, do not select the "UNDETECTED" group in the student list.

The screenshot shows the 'Setting' window in iBASE. It features a navigation bar with tabs: Member, Group, Student, Schedule (selected), and System. The main area is split into two panes. The left pane displays a calendar for February 2021, with the date 16 highlighted in green. The right pane contains a form for course details: Course Name (MATH), Participative Group (dropdown menu with 'IBASE' and 'UNDETECTED' options, where 'UNDETECTED' is selected and circled in red), End Time (HH:MM) (00:00), and Repeat Period (Daily, 0).

5. During smart course detection, “UNDETECTED” students will not be included in the output AI data even if they are present in the classroom.



3.1.6 System Information

- (1) Channel Number: The number of cameras connection
- (2) Video Source: Default is "Capture Card"
- (3) Class Name: The name of the classroom
- (4) Grade Name: The group of classrooms
- (5) Database Path: Specify the path where the database is stored
- (6) Record Path: Specify the path where the record is stored
- (7) Server IP: Used to connect to Server-side system
- (8) Max AI FPS: Maximum Frames Per Second


The screenshot shows a web interface with a dark background and light text. At the top, there is a navigation bar with tabs: Member, Group, Student, Schedule, and System (which is highlighted in green). Below the navigation bar, the following system information is displayed:

- Channel Number: 2
- Video Source: File
- Class Name: Class A1
- Grade Name: Grade 0
- Database Path: C:/Program Files/Multimedia/SmartClassroomService/ClassRoom.db
- Record Path: D/
- Server IP: 192.168.0.100
- Max AI FPS: 5


A "Reset" button is located in the bottom right corner of the configuration area.

Click the "Reset" button to rearrange the value of each item. Follow the steps as below.


(1) Click the "Reset" button at the lower right.




(2) Click "Start".




(3) Choose the number of camera connections and click "Next".



(4) The video source default is Capture Card.
"File" is used only for testing purpose.



(5) Rename the classroom name.



SmartVDO


CLASS_NAME

Class A1

Exit Back Next

The screenshot shows a dark-themed interface for 'SmartVDO'. At the top, the text 'SmartVDO' is displayed in a light green font. Below it, the label 'CLASS_NAME' is shown in a light green font. Underneath the label is a text input field containing the text 'Class A1'. At the bottom of the screen, there are three buttons: 'Exit' on the left, 'Back' in the center, and 'Next' on the right. All text and buttons are outlined in a light green color.

(6) Re-define the Grade of the classroom.



SmartVDO



GRADE_NAME

Grade 0


Exit Back Next

The screenshot shows a dark-themed interface for 'SmartVDO'. At the top, the text 'SmartVDO' is displayed in a light green font. Below it, the label 'GRADE_NAME' is shown in a light green font. Underneath the label is a text input field containing the text 'Grade 0'. At the bottom of the screen, there are three buttons: 'Exit' on the left, 'Back' in the center, and 'Next' on the right. All text and buttons are outlined in a light green color.

(7) Reset the database and record file paths.



- (8) Set up the IP of server-side system.
(When the edge side needs to connect to the server side)



SmartVDO


SERVER_IP

192.168.0.100

Exit Back Next

This screenshot shows the SmartVDO configuration interface. The title 'SmartVDO' is at the top. Below it, the label 'SERVER_IP' is displayed in green. A text input field contains the IP address '192.168.0.100'. At the bottom, there are three buttons: 'Exit', 'Back', and 'Next'.

- (9) Set up the frames per second.
Maximum Frames per Second is 5.



SmartVDO

AI_FPS


5

Exit Back Finish

This screenshot shows the SmartVDO configuration interface. The title 'SmartVDO' is at the top. Below it, the label 'AI_FPS' is displayed in green. A text input field contains the value '5'. At the bottom, there are three buttons: 'Exit', 'Back', and 'Finish'.

3.1.7 Report Export


According to the Record Path in the System page, you can find the detection data via CSV file.



The file is named by the course name.

Name	Date	Type
 Math01	2021/3/4 下午 03:29	CSV File

Introduction to the CSV file format



AI code comparison table

AI code	Emotion	Behavior
-1	No Detected	No Detected
0	Calm	Reading
1	Surprised	Writing
2	Joyful	Listening
3	Disgust	Standing
4	Angry	Raising Hand
5	Fear	Lying Down
6		Look Up
7		Look Back
8		Head Down

3.1.8 Video recording

All MP4 video files are saved in the specified path.

Member Group Student Schedule **System**

Channel Number: 2

Video Source: File

Class Name: Class A1

Grade Name: Grade 0

Database Path: C:/Program Files/Multimedia/SmartClassroomService/ClassRoom.db

Record Path: D/

Server IP: 192.168.0.100

Max AI FPS: 5

Reset

Name	Date	Type
Math01	2021/3/4 下午 03:29	CSV File
Math01-1	2021/3/4 下午 03:13	MP4 File
Math01-2	2021/3/4 下午 03:13	MP4 File

3.1.9 Activity Controls

How to find your activity controls?

- Open the AppData file.
- Choose the date file you want. You'll find activity logs in the file.

Name	Date modified	Type	Size
_2.6.2.6_20210512	2021/5/12 下午 06:15	Text Document	
_2.6.2.6_20210513	2021/5/13 上午 12:00	Text Document	

```
[2021-05-31 13:24:40]Info: Viewer Logout "::ffff:127.0.0.1:50320
[2021-05-31 13:24:52]Info: Stop Server
[2021-05-31 13:25:27]Info: Start Server
[2021-05-31 13:25:29]Info: Viewer Login "admin" "::ffff:127.0.0.
[2021-05-31 13:31:11]Info: Add Group "A11" "A11"
[2021-05-31 13:31:11]Info: Add Group "A11" "A11" failed!
[2021-05-31 13:31:18]Info: Add Group "A12" "A12"
[2021-05-31 13:31:18]Info: Add Group "A12" "A12" failed!
[2021-05-31 13:31:25]Info: Add Group "A13" "A13"
[2021-05-31 13:31:25]Info: Add Group "A13" "A13" failed!
[2021-05-31 13:31:48]Info: Add Group "A21" "A21"
[2021-05-31 13:31:48]Info: Add Group "A21" "A21" failed!
[2021-05-31 13:31:56]Info: Add Group "A22" "A22"
[2021-05-31 13:31:56]Info: Add Group "A22" "A22" failed!
[2021-05-31 13:32:02]Info: Add Group "A23" "A23"
[2021-05-31 13:32:02]Info: Add Group "A23" "A23" failed!
[2021-05-31 13:32:18]Info: Add(Update) Student "AMY1" "AMY"
[2021-05-31 13:32:19]Info: Add(Update) Student "CATHY1" "CATHY"
[2021-05-31 13:32:19]Info: Add(Update) Student "GAR1" "GAR"
[2021-05-31 13:32:20]Info: Add(Update) Student "GLEEN1" "GLEEN"
```

3.2 Central Management Server UI Introduction


3.2.1 User Interface Overview

Classroom list of each Grade



3.2.2 Account Login


Please key in the default value for the user name and password: admin




The image shows a login interface for SmartVDO. The title "SmartVDO" is displayed at the top. Below it, there are two input fields: "User Name" and "Password". Both fields contain the text "admin". The input fields are highlighted with a yellow border. At the bottom of the form, there are two buttons: "Exit" and "Enter".

3.2.3 Connect to Edge side system

Please fill in the Server IP address on this page of each edge side system.




When the connection between edge side and server side is successful, a green light will be displayed.
When the connection fails, a red light will be displayed.



3.2.4 Raw Data Export

- Click the export button.
- There are four conditions to filter.
 - (1) Start Date
 - (2) Report Period
 - (3) Rule (Course, Student Group, Student ID)
 - (4) Data Format
- Click "Export" and the CSV file will be saved in the C drive of the computer.



Introduction to the CSV file format

	A	B	C	D
1	English001	2021-05-11-02:00	2021-05-11-02:30	
2	GAR	-1	-1	02:25:54:394
3	GAR	-1	-1	02:25:54:645
4	GAR	-1	-1	02:25:55:396
5	GAR	-1	-1	02:25:56:397
6	GAR	-1	-1	02:25:57:398
7	GAR	-1	-1	02:25:58:400
8	GAR	-1	-1	02:25:58:651
9	GAR	-1	0	02:25:59:402
10	GAR	-1	0	02:25:59:653
11	GAR	-1	-1	02:25:59:902
12	GAR	-1	-1	02:26:02:657
13	GAR	-1	0	02:26:03:411
14	GAR	-1	0	02:26:03:658
15	GAR	-1	-1	02:26:04:413
16	GAR	-1	0	02:26:21:686

AI code comparison table

AI code	Emotion	Behavior
-1	No Detected	No Detected
0	Calm	Reading
1	Surprised	Writing
2	Joyful	Listening
3	Disgust	Standing
4	Angry	Raising Hand
5	Fear	Lying Down
6		Look Up
7		Look Back
8		Head Down